

ServerView Resource Orchestrator Cloud Edition V3.1.0



Operation Guide

Windows/Linux


J2X1-7611-02ENZ0(00)
July 2012

Preface

Resource Orchestrator Documentation Road Map

The documentation road map for Resource Orchestrator is as shown below.

Resource Orchestrator Documentation Road Map



Point

Refer to the user role manuals displayed in the table below for roles that are not in the diagram.

Roles that are not in the diagram	Roles that are in the diagram
Infrastructure operator Infrastructure monitor	Infrastructure administrator
Tenant operator Tenant monitor	Tenant administrator
(Dual-Role) Administrator (Dual-Role) Operator (Dual-Role) Monitor	Infrastructure administrator and Tenant administrator

For information about the documents for Resource Orchestrator, refer to "Chapter 1 Documentation Road Map" in the "Quick Start Guide CE".

Purpose

This manual explains how to operate ServerView Resource Orchestrator (hereinafter Resource Orchestrator).

Target Readers

This manual is written for system administrators who will use Resource Orchestrator to operate the infrastructure in private cloud or data center environments.

When setting up systems, it is assumed that readers have the basic knowledge required to configure the servers, storage, network devices, and server virtualization software to be installed. Additionally, a basic understanding of directory services such as Active Directory and LDAP is necessary.

Organization

This manual is composed as follows:

Section 1 Overview

[Chapter 1 Overview of Operations, Maintenance, and Monitoring](#)

Provides an overview of the operation, maintenance, and monitoring of Resource Orchestrator.

Section 2 Operation

[Chapter 2 Starting and Stopping Managers and Agents](#)

Explains the methods for deliberately starting and stopping managers and agents.

[Chapter 3 Managing User Accounts](#)

Explains the management of user accounts.

[Chapter 4 Managing Tenants](#)

Explains the management of tenants.

[Chapter 5 Managing Templates](#)

Explains the management of templates.

[Chapter 6 Managing Resources and Resource Pools](#)

Explains the management of resources and resource pools.

[Chapter 7 Management of L-Platform](#)

Explains the management of L-Platforms.

[Chapter 8 Changing Settings](#)

Explains how to modify various setting information.

Section 3 Maintenance

[Chapter 9 Hardware Maintenance](#)

Explains the maintenance of hardware.

[Chapter 10 Backup and Restoration of Admin Servers](#)

Explains the operations for backing up and restoring the admin server.

Section 4 Monitoring

[Chapter 11 Monitoring Resources](#)

Explains how to monitor the configuration and status of managed resources.

[Chapter 12 Collecting Power Consumption Data and Displaying Graphs](#)

Explains how to export the power consumption data collected from registered power monitoring targets and how to display it as graphs, and also describes the exported data's format.

Chapter 13 Monitoring Resource Pools (Dashboard)

Explains the monitoring of resource pools.

Chapter 14 Monitoring L-Platforms

Explains the monitoring of L-Platforms.

Chapter 15 Accounting

Explains charging.

Chapter 16 Monitoring Logs

Explains the monitoring of logs.

Section 5 High Availability

Chapter 17 High Availability of Managed Resources

Explains failover.

Chapter 18 Disaster Recovery

Explains the Disaster Recovery function for L-Servers.

Appendix A Notes on Operating ServerView Resource Orchestrator

Gives important reminders for the operation of Resource Orchestrator.

Appendix B Metering Log

Explains metering logs.

Glossary

Explains the terms used in this manual. Please refer to it when necessary.

Notational Conventions

The notation in this manual conforms to the following conventions.

- When using Resource Orchestrator and the functions necessary differ due to the necessary basic software (OS), it is indicated as follows:

[Windows Manager]	Sections related to Windows manager
[Linux Manager]	Sections related to Linux manager
[Windows]	Sections related to Windows (When not using Hyper-V)
[Linux]	Sections related to Linux
[Solaris]	Sections related to Solaris or Solaris Containers
[VMware]	Sections related to VMware
[Hyper-V]	Sections related to Hyper-V
[Xen]	Sections related to RHEL5-Xen
[KVM]	Sections related to RHEL-KVM
[Solaris Containers]	Sections related to Solaris containers
[Oracle VM]	Sections related to Oracle VM
[Physical Servers]	Sections related to physical servers
[VM host]	Sections related to Windows Server 2008 with VMware or Hyper-V enabled

- Unless specified otherwise, the blade servers mentioned in this manual refer to PRIMERGY BX servers.

- References and character strings or values requiring emphasis are indicated using double quotes (").
- Window names, dialog names, menu names, and tab names are shown enclosed by brackets ([]).
- Button names are shown enclosed by angle brackets (< >) or square brackets ([]).
- The order of selecting menus is indicated using []-[] .
- Text to be entered by the user is indicated using bold text.
- Variables are indicated using italic text and underscores.
- The ellipses ("...") in menu names, indicating settings and operation window startup, are not shown.
- The ">" used in Windows is included in usage examples. When using Linux, read ">" as meaning "#".
- The URLs in this manual were correct when the manual was written.

Menus in the ROR console

Operations on the ROR console can be performed using either the menu bar or pop-up menus. By convention, procedures described in this manual only refer to pop-up menus.

Abbreviations

The following abbreviations are used in this manual:

Abbreviation	Products
Windows	Microsoft(R) Windows Server(R) 2008 Standard Microsoft(R) Windows Server(R) 2008 Enterprise Microsoft(R) Windows Server(R) 2008 R2 Standard Microsoft(R) Windows Server(R) 2008 R2 Enterprise Microsoft(R) Windows Server(R) 2008 R2 Datacenter Microsoft(R) Windows Server(R) 2003 R2, Standard Edition Microsoft(R) Windows Server(R) 2003 R2, Enterprise Edition Microsoft(R) Windows Server(R) 2003 R2, Standard x64 Edition Microsoft(R) Windows Server(R) 2003 R2, Enterprise x64 Edition Windows(R) 7 Professional Windows(R) 7 Ultimate Windows Vista(R) Business Windows Vista(R) Enterprise Windows Vista(R) Ultimate Microsoft(R) Windows(R) XP Professional operating system
Windows Server 2008	Microsoft(R) Windows Server(R) 2008 Standard Microsoft(R) Windows Server(R) 2008 Enterprise Microsoft(R) Windows Server(R) 2008 R2 Standard Microsoft(R) Windows Server(R) 2008 R2 Enterprise Microsoft(R) Windows Server(R) 2008 R2 Datacenter
Windows 2008 x86 Edition	Microsoft(R) Windows Server(R) 2008 Standard (x86) Microsoft(R) Windows Server(R) 2008 Enterprise (x86)
Windows 2008 x64 Edition	Microsoft(R) Windows Server(R) 2008 Standard (x64) Microsoft(R) Windows Server(R) 2008 Enterprise (x64)
Windows Server 2003	Microsoft(R) Windows Server(R) 2003 R2, Standard Edition Microsoft(R) Windows Server(R) 2003 R2, Enterprise Edition Microsoft(R) Windows Server(R) 2003 R2, Standard x64 Edition Microsoft(R) Windows Server(R) 2003 R2, Enterprise x64 Edition

Abbreviation	Products
Windows 2003 x64 Edition	Microsoft(R) Windows Server(R) 2003 R2, Standard x64 Edition Microsoft(R) Windows Server(R) 2003 R2, Enterprise x64 Edition
Windows 7	Windows(R) 7 Professional Windows(R) 7 Ultimate
Windows Vista	Windows Vista(R) Business Windows Vista(R) Enterprise Windows Vista(R) Ultimate
Windows XP	Microsoft(R) Windows(R) XP Professional operating system
Linux	Red Hat(R) Enterprise Linux(R) 5 (for x86) Red Hat(R) Enterprise Linux(R) 5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.1 (for x86) Red Hat(R) Enterprise Linux(R) 5.1 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.2 (for x86) Red Hat(R) Enterprise Linux(R) 5.2 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.3 (for x86) Red Hat(R) Enterprise Linux(R) 5.3 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.4 (for x86) Red Hat(R) Enterprise Linux(R) 5.4 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.5 (for x86) Red Hat(R) Enterprise Linux(R) 5.5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.6 (for x86) Red Hat(R) Enterprise Linux(R) 5.6 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.7 (for x86) Red Hat(R) Enterprise Linux(R) 5.7 (for Intel64) Red Hat(R) Enterprise Linux(R) 6.2 (for x86) Red Hat(R) Enterprise Linux(R) 6.2 (for Intel64) SUSE(R) Linux Enterprise Server 11 for x86 SUSE(R) Linux Enterprise Server 11 for EM64T
Red Hat Enterprise Linux	Red Hat(R) Enterprise Linux(R) 5 (for x86) Red Hat(R) Enterprise Linux(R) 5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.1 (for x86) Red Hat(R) Enterprise Linux(R) 5.1 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.2 (for x86) Red Hat(R) Enterprise Linux(R) 5.2 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.3 (for x86) Red Hat(R) Enterprise Linux(R) 5.3 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.4 (for x86) Red Hat(R) Enterprise Linux(R) 5.4 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.5 (for x86) Red Hat(R) Enterprise Linux(R) 5.5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.6 (for x86) Red Hat(R) Enterprise Linux(R) 5.6 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.7 (for x86) Red Hat(R) Enterprise Linux(R) 5.7 (for Intel64) Red Hat(R) Enterprise Linux(R) 6.2 (for x86) Red Hat(R) Enterprise Linux(R) 6.2 (for Intel64)
Red Hat Enterprise Linux 5	Red Hat(R) Enterprise Linux(R) 5 (for x86) Red Hat(R) Enterprise Linux(R) 5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.1 (for x86) Red Hat(R) Enterprise Linux(R) 5.1 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.2 (for x86) Red Hat(R) Enterprise Linux(R) 5.2 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.3 (for x86) Red Hat(R) Enterprise Linux(R) 5.3 (for Intel64)

Abbreviation	Products
	Red Hat(R) Enterprise Linux(R) 5.4 (for x86) Red Hat(R) Enterprise Linux(R) 5.4 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.5 (for x86) Red Hat(R) Enterprise Linux(R) 5.5 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.6 (for x86) Red Hat(R) Enterprise Linux(R) 5.6 (for Intel64) Red Hat(R) Enterprise Linux(R) 5.7 (for x86) Red Hat(R) Enterprise Linux(R) 5.7 (for Intel64)
Red Hat Enterprise Linux 6	Red Hat(R) Enterprise Linux(R) 6.2 (for x86) Red Hat(R) Enterprise Linux(R) 6.2 (for Intel64)
RHEL5-Xen	Red Hat(R) Enterprise Linux(R) 5.4 (for x86) Linux Virtual Machine Function Red Hat(R) Enterprise Linux(R) 5.4 (for Intel64) Linux Virtual Machine Function
RHEL-KVM	Red Hat(R) Enterprise Linux(R) 6.2 (for x86) Virtual Machine Function Red Hat(R) Enterprise Linux(R) 6.2 (for Intel64) Virtual Machine Function
DOS	Microsoft(R) MS-DOS(R) operating system, DR DOS(R)
SUSE Linux Enterprise Server	SUSE(R) Linux Enterprise Server 11 for x86 SUSE(R) Linux Enterprise Server 11 for EM64T
Oracle VM	Oracle VM Server for x86
ESC	ETERNUS SF Storage Cruiser
GLS	PRIMECLUSTER GLS
Navisphere	EMC Navisphere Manager
Solutions Enabler	EMC Solutions Enabler
MSFC	Microsoft Failover Cluster
SCVMM	System Center Virtual Machine Manager 2008 R2 System Center 2012 Virtual Machine Manager
VMware	VMware vSphere(R) 4 VMware vSphere(R) 4.1 VMware vSphere(R) 5
VMware ESX	VMware(R) ESX(R)
VMware ESX 4	VMware(R) ESX(R) 4
VMware ESXi	VMware(R) ESXi(TM)
VMware ESXi 5.0	VMware(R) ESXi(TM) 5.0
VMware Tools	VMware(R) Tools
VMware vSphere 4.0	VMware vSphere(R) 4.0
VMware vSphere 4.1	VMware vSphere(R) 4.1
VMware vSphere 5	VMware vSphere(R) 5
VMware vSphere Client	VMware vSphere(R) Client
VMware vCenter Server	VMware(R) vCenter(TM) Server
VMware vClient	VMware(R) vClient(TM)
VMware FT	VMware(R) Fault Tolerance
VMware DRS	VMware(R) Distributed Resource Scheduler
VMware DPM	VMware(R) Distributed Power Management
VMware vDS	VMware(R) vNetwork Distributed Switch
VMware Storage VMotion	VMware(R) Storage VMotion

Abbreviation	Products
VIOM	ServerView Virtual-IO Manager
ServerView Agent	ServerView SNMP Agents for MS Windows (32bit-64bit) ServerView Agents Linux ServerView Agents VMware for VMware ESX Server
RCVE	ServerView Resource Coordinator VE
ROR	ServerView Resource Orchestrator
ROR VE	ServerView Resource Orchestrator Virtual Edition
ROR CE	ServerView Resource Orchestrator Cloud Edition
Resource Coordinator	Systemwalker Resource Coordinator Systemwalker Resource Coordinator Virtual server Edition

Export Administration Regulation Declaration

Documents produced by FUJITSU may contain technology controlled under the Foreign Exchange and Foreign Trade Control Law of Japan. Documents which contain such technology should not be exported from Japan or transferred to non-residents of Japan without first obtaining authorization from the Ministry of Economy, Trade and Industry of Japan in accordance with the above law.

Trademark Information

- EMC, EMC², CLARiiON, Symmetrix, and Navisphere are trademarks or registered trademarks of EMC Corporation.
- HP is a registered trademark of Hewlett-Packard Company.
- Linux is a trademark or registered trademark of Linus Torvalds in the United States and other countries.
- Microsoft, Windows, MS, MS-DOS, Windows XP, Windows Server, Windows Vista, Windows 7, Excel, Active Directory, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- NetApp is a registered trademark of Network Appliance, Inc. in the US and other countries. Data ONTAP, Network Appliance, and Snapshot are trademarks of Network Appliance, Inc. in the US and other countries.
- Oracle and Java are registered trademarks of Oracle and/or its affiliates in the United States and other countries.
- Oracle is a registered trademark of Oracle Corporation and/or its affiliates.
- Red Hat, RPM and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc. in the United States and other countries.
- SUSE is a registered trademark of SUSE LINUX AG, a Novell business.
- VMware, the VMware "boxes" logo and design, Virtual SMP, and VMotion are registered trademarks or trademarks of VMware, Inc. in the United States and/or other jurisdictions.
- ServerView and Systemwalker are registered trademarks of FUJITSU LIMITED.
- All other brand and product names are trademarks or registered trademarks of their respective owners.

Notices

- The contents of this manual shall not be reproduced without express written permission from FUJITSU LIMITED.
- The contents of this manual are subject to change without notice.

Month/Year Issued, Edition	Manual Code
November 2011, First Edition	J2X1-7611-01ENZ0(00)

Month/Year Issued, Edition	Manual Code
December 2011, 1.1	J2X1-7611-01ENZ0(01)
January 2012, 1.2	J2X1-7611-01ENZ0(02)
February 2012, 1.3	J2X1-7611-01ENZ0(03)
March 2012, 1.4	J2X1-7611-01ENZ0(04)
April 2012, 1.5	J2X1-7611-01ENZ0(05)
July 2012, 2	J2X1-7611-02ENZ0(00)

Copyright FUJITSU LIMITED 2010-2012

Contents

Part 1 Overview.....	1
Chapter 1 Overview of Operations, Maintenance, and Monitoring.....	2
1.1 Operation, Maintenance, and Monitoring by Infrastructure Administrators.....	2
1.2 Operation, Maintenance, and Monitoring by Tenant Administrators.....	3
1.3 Operation, Maintenance, and Monitoring by Tenant Users.....	3
Part 2 Operation.....	4
Chapter 2 Starting and Stopping Managers and Agents.....	5
2.1 Starting and Stopping the Manager.....	5
2.2 Starting and Stopping an Agent.....	7
Chapter 3 Managing User Accounts.....	10
Chapter 4 Managing Tenants.....	11
Chapter 5 Managing Templates.....	12
Chapter 6 Managing Resources and Resource Pools.....	13
6.1 Managing Resource Pools.....	13
6.2 Managing Resources.....	13
6.3 Managing L-Servers.....	13
Chapter 7 Management of L-Platform.....	14
7.1 Review for L-Platform Usage Applications.....	14
7.2 Administration of L-Platform.....	14
7.2.1 Deleting Unnecessary Data.....	14
7.2.2 Updating the Cloning Image.....	14
7.2.3 Importing to L-Platform.....	14
7.2.3.1 Network Information Settings for Converted L-Servers.....	15
7.2.3.2 Importing L-Servers.....	15
7.2.3.3 Releasing L-Servers.....	15
7.2.4 Setting OS with Deployment on RHEL-KVM.....	15
7.2.5 Startup Priority Level Settings.....	16
7.2.6 Action to Take when an Error has Occurred.....	16
7.2.7 Setting Alive Monitoring.....	16
7.2.8 Redundancy Settings.....	16
7.2.9 Automatic Server Release Settings.....	17
Chapter 8 Changing Settings.....	18
8.1 Registering and Deleting Application Process Assessors.....	18
8.1.1 Registering an Application Process Assessor.....	18
8.1.2 Deleting an Application Process Assessor.....	18
8.1.2.1 Deleting an Infrastructure Administrator/dual-role Administrator from IflowUsers Group.....	18
8.2 Settings for Sending Email.....	19
8.3 Settings for Port Number of Management Servers.....	20
8.4 Editing Information in the Home Window.....	22
8.5 Settings for L-Platform Management.....	23
8.5.1 Settings for Permissions to Change L-Platform Templates.....	23
8.5.2 Subnet Settings at Segment Editing.....	23
8.5.3 Settings for the Simplified Reconfiguration Function.....	24
8.5.4 Distribution Ratio Settings.....	24
8.5.5 Application Process Settings.....	25
8.5.5.1 How to Modify the Application Process Settings.....	25
8.5.5.2 How to Modify Application Process to be Used.....	25
8.5.6 Editing the Environment Setup File for the L-Platform API.....	26

8.5.7 Edit the License Agreement.....	26
8.5.8 Settings when RHEL5-Xen is used.....	26
8.5.9 Default Password Setting for Sent Emails.....	26
8.5.10 Settings for the Maximum Number of Connections for the L-Platform Template.....	26
8.5.11 Customizing the User Rights for L-Platform Operations.....	27
8.6 Settings for Tenant Management and Account Management.....	27
8.6.1 Settings for Tenant Management and Account Management.....	27
8.6.2 Editing the User Agreement when Registering a User.....	30
8.7 Accounting Settings.....	30
8.7.1 Display Function Settings for Estimated Price.....	30
8.7.2 Currency Information Settings.....	32
8.7.3 Metering Log Settings.....	32
8.7.4 Usage Charge Calculator Settings.....	34
8.8 System Condition Server List Settings.....	35
8.9 Settings for Event Log Output for CMDDB Agent.....	36
Part 3 Retention.....	38
Chapter 9 Hardware Maintenance.....	39
9.1 Overview.....	39
9.2 Blade Server Maintenance.....	40
9.2.1 Maintenance LED.....	40
9.2.2 Reconfiguration of Hardware Properties.....	41
9.2.3 Replacing the Server.....	42
9.2.4 Replacing Non-Server Hardware.....	44
9.3 Maintenance for Servers Other Than Blade Servers.....	45
9.3.1 Reconfiguration of Hardware Properties.....	45
9.3.2 Replacing the Server.....	47
9.3.3 Replacing and Adding Server Components.....	52
9.3.4 Replacing Non-server Hardware.....	53
9.4 For Servers not Using Server Management Software.....	53
9.5 Network Device Maintenance.....	53
9.5.1 Replacement Procedure of Network Devices.....	54
9.5.2 Regular Maintenance Procedure of Network Devices.....	55
9.5.3 Procedure for Addition of Network Devices.....	56
9.5.3.1 Adding L2 Switches to Handle Insufficient Numbers of Ports when Adding Servers.....	56
9.5.3.2 Adding Firewalls and L2 Switches for Additional Tenants.....	58
9.5.4 Procedure for Addition or Modification of Connection Destinations of Network Devices.....	60
9.6 Storage Device Maintenance.....	61
9.7 Power Monitoring Device (PDU or UPS) Maintenance.....	61
Chapter 10 Backup and Restoration of Admin Servers.....	62
10.1 Mechanism of Backup and Restoration.....	63
10.2 Offline Backup of the Admin Server.....	69
10.2.1 Stopping the Manager.....	69
10.2.2 Back up the Resources of this Product.....	70
10.2.3 Starting the Manager.....	70
10.3 Online Backup of the Admin Server.....	71
10.3.1 Items to be Determined Before Periodic Execution.....	73
10.3.2 Settings for Periodic Execution of Backup.....	73
10.4 Restoring the Admin Server.....	75
10.4.1 Stop the manager.....	76
10.4.2 Restoring the Resources of This Product.....	76
10.4.3 Starting the Manager.....	76
10.4.4 Disabling L-Platform Applications.....	77
10.4.5 Update the configuration information in the operational status information.....	77
10.5 Online Backup Settings for Metering.....	77

Part 4 Monitoring.....	81
Chapter 11 Monitoring Resources.....	82
11.1 Overview.....	82
11.2 Resource Status.....	83
11.3 Addressing Resource Failures.....	85
11.4 Monitoring Networks.....	86
11.4.1 Identification of Error Locations.....	86
11.4.2 Firewall Status Confirmation.....	88
11.4.3 L2 Switch Status Confirmation.....	90
11.4.4 Status Confirmation of Other Network Devices.....	91
11.5 Monitoring Storage.....	91
Chapter 12 Collecting Power Consumption Data and Displaying Graphs.....	93
12.1 Overview.....	93
12.2 Exporting Power Consumption Data.....	93
12.3 Power Consumption Data File (CSV Format).....	93
12.4 Displaying Power Consumption Data Graphs.....	94
Chapter 13 Monitoring Resource Pools (Dashboard).....	95
Chapter 14 Monitoring L-Platforms.....	96
Chapter 15 Accounting.....	97
15.1 Overview.....	97
15.2 Manage Accounting Information.....	98
15.2.1 Information Maintained by Product Master.....	99
15.2.2 Accounting Information File Format.....	102
15.3 Operate Accounting Information.....	105
15.3.1 Register Accounting Information.....	106
15.3.2 Modify Accounting Information Command.....	107
15.3.3 Delete Accounting Information.....	109
15.3.4 Reference Accounting Information.....	110
15.4 Calculation of Usage charges.....	110
15.4.1 Overview of Usage charge Calculation.....	110
15.4.2 Resource Usage Times.....	111
15.4.3 How to Charge for Resources.....	111
15.4.4 Resource Usage Amounts and Times.....	112
15.4.5 Example of Usage charge Calculation.....	112
15.4.6 Sending Usage charges.....	115
15.4.6.1 Usage Charge List File.....	116
15.4.6.2 Usage charge Detail File.....	117
Chapter 16 Monitoring Logs.....	119
16.1 Operation Logs.....	119
16.1.1 Overview.....	119
16.1.2 Usage Method.....	122
16.1.3 Retention.....	123
16.1.4 Scope of Operations Recorded in Operation Logs.....	124
16.2 Audit Logs.....	124
16.2.1 Configuration Management Audit Log.....	124
16.2.2 Audit Logs of Output by the Tenant Management, Accounting, Access Control and System Condition.....	129
16.2.3 Application Process Audit Log.....	135
16.3 Operation Logs (Activity).....	138
16.3.1 Operation Logs for Accounting.....	138
16.4 Investigation Logs.....	138
16.4.1 Investigation Logs on Admin Servers.....	138
Part 5 High Availability and Disaster Recovery.....	141

Chapter 17 High Availability of Managed Resources.....	142
17.1 High Availability of Managed Resources.....	142
17.1.1 High Availability of L-Servers.....	142
17.1.2 Blade Chassis High Availability.....	145
17.1.3 High Availability for Storage Chassis.....	147
17.2 High Availability for Admin Servers.....	152
Chapter 18 Disaster Recovery.....	156
18.1 Installation.....	156
18.2 Normal Operation.....	161
18.3 Switchover Operation During Disasters.....	164
18.4 Operation after the switchover.....	172
18.5 Switchback operation.....	173
Appendix A Notes on Operating ServerView Resource Orchestrator.....	174
Appendix B Metering Log.....	178
B.1 Types of Metering Logs.....	178
B.2 Output Contents of Metering Logs.....	179
B.3 Formats of Metering Log Files.....	184
B.4 Deleting Metering Logs.....	187
Glossary.....	188

Part 1 Overview

Chapter 1 Overview of Operations, Maintenance, and Monitoring.....	2
--	---

Chapter 1 Overview of Operations, Maintenance, and Monitoring

This chapter provides an overview of operation, maintenance, and monitoring of Resource Orchestrator.

For additional information on the operation, maintenance, and monitoring of this product, refer to the configuration information in the "Setup Guide CE".

1.1 Operation, Maintenance, and Monitoring by Infrastructure Administrators

This section explains operation, maintenance, and monitoring by infrastructure administrators when using Resource Orchestrator.

The operations that infrastructure administrators (infra_admin) can perform are as follow.

Refer to the "User's Guide for Infrastructure Administrators (Resource Management) CE" for the [Resource] tab operations.

Refer to the "User's Guide for Infrastructure Administrators CE" for other operations.

- Management of resources and resource pools
 - Registration, modification, and deletion of resources
 - Creation, deletion, modification of global pools and tenant local pools
 - Review and confirmation of application status and L-Platform usage applications
- Management of tenants
 - Creation, modification, and deletion of tenants
 - Create a tenant administrator
 - Creation, modification, and deletion of user accounts
- Management of templates
 - Creation, modification, and deletion of L-Platform templates (*1)
 - Creation, modification, and deletion of L-Server templates

*1: To check subscription requests submitted by using a created L-Platform template, use a dual-role administrator account. For more details, refer to "Appendix B Applying (Subscribe) for L-Platform Usage by Dual-Role Administrators" in "User's Guide for Infrastructure Administrators".

Maintenance operations that infrastructure administrators (infra_admin) can perform are as follow:

- Hardware maintenance
- System maintenance (*2)
- Backup and restoration of admin servers (*2)

*2: OS administrative privileges are necessary for OS maintenance and backup and restore of admin servers.

Monitoring operations that infrastructure administrators (infra_admin) can perform are as follow:

- Monitoring of resource pools using dashboard
- Monitoring of L-Platform operation statuses
- Monitoring of resource capacity (servers, storage and network)
- Monitoring of operation logs and audit logs

1.2 Operation, Maintenance, and Monitoring by Tenant Administrators

For details on operations, maintenance and monitoring by tenant administrators, refer to the "User's Guide for Tenant Administrators CE".

1.3 Operation, Maintenance, and Monitoring by Tenant Users

For details on operations, maintenance and monitoring by tenant users, refer to the "User's Guide for Tenant Users CE".

Part 2 Operation

Chapter 2 Starting and Stopping Managers and Agents.....	5
Chapter 3 Managing User Accounts.....	10
Chapter 4 Managing Tenants.....	11
Chapter 5 Managing Templates.....	12
Chapter 6 Managing Resources and Resource Pools.....	13
Chapter 7 Management of L-Platform.....	14
Chapter 8 Changing Settings.....	18

Chapter 2 Starting and Stopping Managers and Agents

This chapter explains how to manually start or stop managers and agents.


To use Resource Orchestrator, both the manager and agents must be running.

The manager and agent services are configured to start automatically upon startup of their respective servers (admin server, managed server). Normally, there should be no need to manually start or stop either the manager or agents. To start or stop a manager or an agent intentionally, refer to "2.1 Starting and Stopping the Manager" and "2.2 Starting and Stopping an Agent".

Note

When using the HBA address rename function, ensure that the manager is started before starting any managed servers. The power on procedure should be managed as follows: first, start the admin server together with any storage devices, and start the managed servers 10 minutes later.

Managed servers will not boot up properly if they are started before the manager. Make sure that the manager is running before starting managed servers.



Additionally, when using the HBA address rename function, the HBA address rename setup service should be started on a dedicated server (HBA address rename server) and left running continuously. For details on starting, stopping, and confirming the state of the HBA address rename setup service, refer to "Chapter 10 Settings for the HBA address rename Setup Service" in the "Setup Guide CE".

2.1 Starting and Stopping the Manager

The Resource Orchestrator manager starts automatically on the admin server.

This section explains how to manually start or stop the manager and how to check its running state.

[Windows Manager]

The manager is made up of the following two groups of Windows services:

- Manager Services

- Resource Coordinator Manager
- Resource Coordinator Task Manager
- Resource Coordinator Web Server (Apache)
- Resource Orchestrator Sub Web Server (Mongrel)
- Resource Orchestrator Sub Web Server (Mongrel2)
- Resource Coordinator Sub Web Server (Mongrel3)
- Resource Coordinator Sub Web Server (Mongrel4)
- Resource Coordinator Sub Web Server (Mongrel5)
- Resource Coordinator DB Server (PostgreSQL)
- ServerView Resource Orchestrator Service Catalog Manager DB Service(Dashboard)
- ServerView Resource Orchestrator Service Catalog Manager DB Service(Charging)
- ServerView Resource Orchestrator Service Catalog Manager REST Service(Charging)

- Related Services

- Deployment Service
- TFTP Service

PXE Services
DHCP Server (*1)
Systemwalker SQC DCM
Interstage BPM Analytics eRule Engine (EFServer)
Systemwalker MpJobsch9
Systemwalker MpMjes
Systemwalker MpMjes9
Systemwalker Runbook Automation DB Service
Shunsaku Conductor cmdbc
Shunsaku Sorter cmdbo01

*1: Required when managed servers belonging to different subnets from the admin server exist.

From the Windows Control Panel, open [Administrative Tools]. Then, open the [Services] window to check the state of each service.

Services are started and stopped using the rcxmgrctl command (start and stop subcommands).

Using this command, manager services and related services can be started or stopped at the same time.

For details of the command, refer to "5.14 rcxadm mgrctl" in the "Reference Guide (Command/XML) CE".

To start or stop a manager in a clustered configuration, right-click the manager application shown under the failover cluster manager tree, and select either [Bring this service or application online] or [Take this service or application offline].

[Linux Manager]

The manager is made up of the following two groups of Linux services:

- Manager Services

rcvmr

Manager services also include the following daemons.

rcxmanager

rcxtaskmgr

rcxmongrel1

rcxmongrel2

rcxmongrel3

rcxmongrel4

rcxmongrel5

rcxhttpd

- Database (PostgreSQL)

rcxdb

- Related Services

scwdepsvd

scwpxesvd

scwftpd

The status of each of those services can be confirmed from the service command, as shown below.

```
# service rcvmr status <RETURN>
# service scwdepsvd status <RETURN>
# service scwpxesvd status <RETURN>
# service scwftpd status <RETURN>
```

Services are started and stopped using the rcxmgrctl command (start and stop subcommands).

Using this command, manager services and related services can be started or stopped at the same time.

For details of the command, refer to "5.14 rcxadm mgrctl" in the "Reference Guide (Command/XML) CE".

To start or stop a manager in a clustered configuration, use the cluster administration view (Cluster Admin).

For details, refer to the PRIMECLUSTER manual.

Note

- When using ServerView Deployment Manager on an admin LAN, all services related to Resource Orchestrator will be automatically disabled. To prevent conflicts with ServerView Deployment Manager, do not start these services in order. For details, refer to "Appendix B Co-Existence with ServerView Deployment Manager" in the "Setup Guide VE".
- Resource Orchestrator cannot be operated if any of the manager services are stopped. Ensure that all services are running when Resource Orchestrator is running.
- If the manager is unable to communicate on the admin LAN when started up (because of LAN cable disconnections or any other causes), PXE Services may not start automatically. If PXE Services are stopped, investigate the network interface used for the admin LAN and confirm whether it can communicate with other nodes on the admin LAN.

If the manager cannot communicate with admin LAN nodes, restore the admin LAN itself and restart the manager.

- In Basic mode, the following manager services are started.

In Basic mode, the procedure to start and stop the services and the procedure to check their statuses are same as those in standard mode.

[Windows Manager]

- Manager Services
 - Resource Coordinator Manager
 - Resource Coordinator Task Manager
 - Resource Coordinator Web Server (Apache)
 - Resource Orchestrator Sub Web Server (Mongrel)
 - Resource Orchestrator Sub Web Server (Mongrel2)
 - Resource Coordinator DB Server (PostgreSQL)

[Linux Manager]

- Manager Services
 - rcvmr
 - Manager services also include the following daemons.
 - rcxmanager
 - rcxtaskmgr
 - rcxmongrel1
 - rcxmongrel2
 - rcxhttpd

2.2 Starting and Stopping an Agent

The Resource Orchestrator agent starts automatically on managed servers.
This section explains how to manually start or stop an agent and how to check its power state.

Note

To prevent conflicts, related services are uninstalled from the Resource Orchestrator agent when using ServerView Deployment Manager on the admin LAN. In such cases, there is no need to start or stop those services when starting or stopping the Resource Orchestrator agent.

[Windows] [Hyper-V]

The agent consists of the following two Windows services:

- Agent Service
 - Resource Orchestrator Agent

- Related Services
 - Deployment Agent
 - Systemwalker SQC DCM

From the Windows Control Panel, open [Administrative Tools]. Then, open the [Services] window to check the state of each service. The following explains how to start and stop each service.

- Agent Service

Agents can be started and stopped using the start and stop subcommands of the rcxadm agtctl command. For details of the command, refer to "5.3 rcxadm agtctl" in the "Reference Guide (Command/XML) CE".

- Related Services

From the Windows Control Panel, open [Administrative Tools]. Then, open the [Services] window to stop or start the following service.

- Deployment Agent
- Systemwalker SQC DCM

[Linux] [VMware] [Xen] [KVM]

The agent consists of the following services.

- Agent Service
- Related Services
 - Deployment Agent

For VMware vSphere 4.0 or later version, Deployment Agent is not automatically started, as backup and restore, and cloning functions cannot be used. It is not necessary to start up.

[Linux]

- Systemwalker SQC DCM

Execute the following commands to determine whether the agent is running or not. If those commands show that the processes for the agent and deployment services are running, then the agent can be asserted to be running.

- Agent Service

```
# /bin/ps -ef | grep FJSVssagt <RETURN>
```

- Related Services

```
# /bin/ps -ef | grep scwagent <RETURN>
```

To check the running state of the service of Systemwalker SQC DCM, execute the following command:

```
# /etc/rc0.d/K00ssqcdcm <RETURN>
```

The following explains how to start and stop each service.

- Agent Service

Agents can be started and stopped using the start and stop subcommands of the rcxadm agtctl command. For details of the command, refer to "5.3 rcxadm agtctl" in the "Reference Guide (Command/XML) CE".

- Related Services

Execute the following command to start or stop the collection of image files, deployment of image files, and server startup control.

Starting an L-Server

```
# /etc/init.d/scwagent start <RETURN>
# /etc/rc2.d/S99ssqcdcm start <RETURN>
```

Stop

```
# /etc/init.d/scwagent stop <RETURN>
# /etc/rc0.d/K00ssqcdcm stop <RETURN>
```

[Solaris]

The agent consists of the following services.

- Agent Service

Execute the following commands to determine whether the agent is running or not. If those commands show that the processes for the agent and deployment services are running, then the agent can be asserted to be running.

```
# /bin/ps -ef | grep FJSVrcvat <RETURN>
```

The following explains how to start and stop each service.

Agents can be started and stopped using the start and stop subcommands of the rcxadm agtctl command. For details of the command, refer to "5.3 rcxadm agtctl" in the "Reference Guide (Command/XML) CE".

Chapter 3 Managing User Accounts

This chapter explains the management of user accounts.

Creation, Viewing, and Modification of User Accounts

Only users that hold the role of infrastructure administrator, tenant administrator, or administrator can create user accounts.

For details on operations by infrastructure administrators, refer to "Chapter 3 Configuring Users for Infrastructure Administrators" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

For details on operations by tenant administrators, refer to "Chapter 10 Tenant" in the "User's Guide for Tenant Administrators CE".

Viewing and Modification of Information of Logged in Users

To view and modify the information of logged in users, use [Account] on the ROR console for the operation.

For details on [Account], refer to "Chapter 13 Account" in the "User's Guide for Infrastructure Administrators CE".

Chapter 4 Managing Tenants

This chapter explains the management of tenants.

Tenant Creation

The flow of tenant creation is as follows:

1. Register tenants

Input the tenant information and register tenants.

2. Create a tenant administrator

Create a tenant administrator.

3. Create a local pool for tenants

The following two types of resource pool operations can be performed:

- Local Pool

A resource pool which can be used only for tenants.

A resource stored in a local pool cannot be used by a user of another tenant.

- Global Pool

A common resource pool which can be used by the entire system.

For details on how to select resource pools, refer to "Chapter 6 Defining Tenants and Resource Pools" in the "Design Guide CE".

When using a local pool, create a local pool used only by the tenant registered in step 1.

4. Register resources

Register the resources created in 3.in the local pool.

For details, refer to "11.3 Creating a Tenant" of the "User's Guide for Infrastructure Administrators CE".

Tenant Operation

Use the [Tenant] tab in the ROR console for the following operations.

For details on the [Tenant] tab, refer to "Chapter 11 Tenant" of the "User's Guide for Infrastructure Administrators CE".

- Register tenants
- Create a tenant administrator
- Create a tenant resource pool
- Create and delete tenants

Chapter 5 Managing Templates

This chapter explains the management of templates.

- L-Platform Templates

An L-Platform template is the template to define the logical configuration of ICT resources and software.

An L-Platform is composed of an L-Platform template.

Use the [Template] tab to create, modify, and delete L-Platform templates.

For details on the [Template] tab, refer to "Chapter 8 Template" of the "User's Guide for Infrastructure Administrators CE".

- L-Server Templates

An L-Server template is the template defining the specifications of an L-Server (number of CPUs, memory capacity, disk capacity, and number of NICs) used for an L-Platform.

Use the [Resource] tab to create, modify, and delete L-Server templates.

For details on L-Server template operations, refer to "Chapter 15 L-Server Template Operations" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Chapter 6 Managing Resources and Resource Pools

This chapter explains the management of resources and resource pools.

6.1 Managing Resource Pools

This section explains the management of resource pools.

The following resource pool operations are possible:

- Addition and modification of tenants and local pools
- Deletion of local pools within tenants
- Addition, modification, and deletion of global pools

When changing the global pool that can be used by tenants, perform the operation from the [Tenant] tab on the ROR console.

For details on the [Tenant] tab, refer to "Chapter 11 Tenant" of the "User's Guide for Infrastructure Administrators CE".

6.2 Managing Resources

This section explains the management of resources.

Use the [Resource] tab in the ROR console to register, change, or delete resources.

- Register resources

Refer to "Chapter 5 Register Resources" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

- Changing Resources

Refer to "Chapter 7 Changing Resources" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

- Delete Resources

Refer to "Chapter 9 Delete Resources" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

For details on how to add network devices, refer to "[9.5.3 Procedure for Addition of Network Devices](#)", and for details on how to add or modify connection destinations of network devices, refer to "[9.5.4 Procedure for Addition or Modification of Connection Destinations of Network Devices](#)".

6.3 Managing L-Servers

This section explains the management of L-Servers.

L-Server Operations

Refer to "Chapter 17 L-Server Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Use of Physical Servers or Virtual Machines as L-Servers

Configured physical servers or virtual machines can be used as L-Servers.

For details, refer to "Chapter 18 Linking L-Servers with Configured Physical Servers or Virtual Machines" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Chapter 7 Management of L-Platform

This chapter explains how to management of L-Platform.

7.1 Review for L-Platform Usage Applications

Use the [Request] tab of the ROR console to review applications to use from tenant users for operations such as usage application, configuration modification, and cancel of L-Platforms.

For details on the [Request] tab, refer to "Chapter 10 Request" in the "User's Guide for Infrastructure Administrators CE".

7.2 Administration of L-Platform

This section explains how to perform L-Platform operations.

7.2.1 Deleting Unnecessary Data

If an L-Platform or server deployed by this product was accidentally deleted by virtualization software such as VMware, it is possible to delete unneeded information about the system or server remaining in this product.

What is actually done is that the unneeded L-Platform information or server information status is changed to "Finished with return" with the `cfmg_deletesysdata(Unnecessary Data Deletion)` command so that it is no longer displayed in the L-Platform management View.

Refer to "12.3 `cfmg_deletesysdata (Unnecessary Data Deletion)`" in the "Reference Guide (Command/XML) CE" for details on this command.

7.2.2 Updating the Cloning Image

In this product, the resource ID is used when managing the cloning image.

If the cloning image has been updated, the resource ID will be changed, so the image information must be updated in order to return the resource ID back to its previous setting.

If the cloning image has been updated, use an operation from the "Template" window to update the image information.

Refer to "8.3.8 Synchronizing Image Information" in the "User's Guide for Infrastructure Administratorsfor CE" details.

Point

To use both cloning masters (the cloning master before the update and the cloning master after the update) in the L-Platform template, updating a single cloning master will not work. Instead, these cloning masters must be collected separately.

7.2.3 Importing to L-Platform

This section explains how to import physical servers, virtual machines, and L-Servers to an L-Platform.

There are the following two ways of importing physical servers, virtual machines, and L-Servers to the L-Platform Management function:

- Convert configured physical servers or virtual machines into L-Servers, then import the converted L-Servers to the L-Platform

Follow the procedure described below to convert configured physical servers or virtual machines into L-Servers and import to the L-Platform:

- a. Convert the physical servers or virtual machines into L-Servers

Refer to "[Use of Physical Servers or Virtual Machines as L-Servers](#)".

- b. Network Information Settings for Converted L-Servers

Refer to "[7.2.3.1 Network Information Settings for Converted L-Servers](#)".

- c. Importing the L-Server for which network information has been set

Refer to "7.2.3.2 Importing L-Servers".

- Import L-Servers created in the ROR console into the L-Platform

Refer to "7.2.3.2 Importing L-Servers".

7.2.3.1 Network Information Settings for Converted L-Servers

Set the network information for the L-Servers converted in "Use of Physical Servers or Virtual Machines as L-Servers".

Execute the `rcxadm lserver attach -define` command to set network information.

The setting of network information via the command `rcxadm lserver attach -define` can only be performed on the L-Server before it is imported into the L-Platform management function.

Also, the `rcxadm lserver attach -define` command can only be executed if using Solaris container.

If adding multiple network interface cards (NICs), execute the command `rcxadm lserver attach -define` only the same number of times as there are NICs being added.

Refer to "3.6 `rcxadm lserver`" in the "Reference Guide (Command/XML) CE" for details.

7.2.3.2 Importing L-Servers

The Import L-Server command (`cfmg_importlserver`) can be used to import servers that have been deployed, or the VM guests that have been imported using the ROR Console, to the L-Platform Management function.

Refer to "12.4 `cfmg_importlserver` (Import L-Server)" in the "Reference Guide (Command/XML) CE" for details on this command.



- L-Servers can only be imported into L-Platform configurations that have one server per L-Platform.
- Expansion disks with two disk indexes cannot be imported.
- L-Servers without network interface cards (NICs) cannot be imported.
- No initial password information will be set for an L-Server that has been imported without image information being specified. "initial password is [.]" will be displayed on the initial password confirmation window of the system details window of the L-Platform management window.
- An L-Server that is under a tenant cannot be imported to a different tenant.
- When importing an L-Server that is not under a tenant folder, switch the power off for the L-Server targeted for import.

7.2.3.3 Releasing L-Servers

L-Servers that have been imported into the L-Platform management function can be released from the L-Platform by using the L-Server release command (`cfmg_deletelserver`).

Refer to "12.2 `cfmg_deletelserver` (Release L-Server)" in the "Reference Guide (Command/XML) CE" for more information about the command.

7.2.4 Setting OS with Deployment on RHEL-KVM

Windows OS(excluding Microsoft(R) Windows Server(R) 2008 R2)

When the virtualization software is RHEL-KVM, the following OS configuration procedure is necessary on each deployed server with Windows OS to enable the settings of the IP addresses, the default gateway, and the host name.

The infrastructure administrator must look up the IP addresses and the host name in the L-Platform management window and the default gateway in the resource management window, and then connect a console to the deployed server and configure the OS manually.

Users cannot access the server until this configuration is completed.

The administrator should include a description like "The IP address needs to be set by the administrator after deployment" in the description field of the L-Platform template, and notify users that the server has become accessible after the configuration.

Linux OS with SELinux enabled

The administrator must disable SELinux when creating an image, and should include a description like "SELinux needs to be enabled after the deployment has been completed" in the description field of the L-Platform template.

Because Linux OS is deployed with SELinux disabled, ensure that there are procedures in place to advise the user to enable SELinux after deployment.

7.2.5 Startup Priority Level Settings

Any server with a startup priority level set to 0 will not startup or shutdown when performing bundled power supply operations.

An information message will be output to `vsys_trace_log` for any server that did not startup or shutdown.

If any server that either did not startup or shutdown actually needs to be started up or shut down, refer to the information message and use the **StartLServer** or **StopLServer** command to startup or shutdown individually.

Refer to "2.3.5 StartLServer (Starts a Server)" and "2.3.6 StopLServer (Stops a Server)" in the "Reference Guide (API)" for details on this command.

7.2.6 Action to Take when an Error has Occurred

When an error has occurred during a cancellation application by a tenant user, the cancellation application may become impossible.

In that case, confirm the system ID of the L-Platform, and use the **Disable L-Platform Application** command to make the cancellation application possible again for the user.

For information on the **Disable L-Platform Application** command, refer to "12.12 recoverService (Disable L-Platform Application)" in the "Reference Guide (Command/XML) CE".

7.2.7 Setting Alive Monitoring

When using alive monitoring on an L-Platform, it needs to be deployed specifying an L-Server template in which the setting of activity monitoring is enabled.

For information on creating L-Server templates, refer to "Chapter 15 L-Server Template Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

If the settings are changed after deployment, change the "Type of Server(specifications)" by reconfiguring the L-Platform.

Register different L-Server templates where heartbeat settings are enabled and disabled.

Also use L-Server template names that make it easy to distinguish whether heartbeat settings are enabled or disabled.



Example

- L-Server template name where heartbeat settings are disabled

VMware_Small

- L-Server template name where heartbeat settings are enabled

VMware_Small_Monitoring

7.2.8 Redundancy Settings

When deploying a server with redundancy settings to an L-Platform, it is necessary to deploy by specifying an L-Server template that has redundancy settings enabled.

Refer to "Chapter 15 L-Server Template Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE" for information on how to create L-Server templates.

If the settings are changed after deployment, change the "Type of Server(specifications)" by reconfiguring the L-Platform.
Register different L-Server templates where redundancy settings are enabled and disabled.
Also use L-Server template names that make it easy to distinguish whether redundancy settings are enabled or disabled.

Example

- L-Server template name where redundancy settings are disabled
VMware_Small
 - L-Server template name where redundancy settings are enabled
VMware_Small_HA
-

7.2.9 Automatic Server Release Settings

When deploying a server with automatic server release settings to an L-Platform, it is necessary to deploy by specifying an L-Server template that has automatic server release settings enabled.
Refer to "Chapter 15 L-Server Template Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE" for information on how to create L-Server templates.

If the settings are changed after deployment, change the "Type of Server(specifications)" by reconfiguring the L-Platform.
Register different L-Server templates where automatic server release settings are enabled and disabled.
Also use L-Server template names that make it easy to distinguish whether automatic server release settings are enabled or disabled.

Example

- L-Server template name where automatic server release settings are disabled
VMware_Small
 - L-Server template name where automatic server release settings are enabled
VMware_Small_Repurpose
-

Chapter 8 Changing Settings

This chapter explains how to change settings.

8.1 Registering and Deleting Application Process Assessors

This section explains how to register and delete application process assessors.

8.1.1 Registering an Application Process Assessor

This section explains how to register an infrastructure administrator or dual-role administrator as an application process assessor.

Add all infrastructure administrator and dual-role administrator to the directory service IflowUsers group in order to use application processes. Use the LDIF file to register an application process assessor at the directory server. Follow the procedure below to register as application process assessor.

1. Create an infrastructure administrator or dual-role administrator.
2. Add the infrastructure administrator or dual-role administrator as a member of the IflowUsers group.



- Infrastructure administrators and dual-role administrators who have not been registered in the "IflowUsers" group cannot conduct assessment in application processes. Also, if infrastructure administrators and dual-role administrators not registered in the "IflowUsers" group select the **Request** tab in the ROR Console, the following error message appears:

```
Error message : Failed to authenticate the user.
```

- Administrators (dual-role administrators) created during installation are not registered in the "IflowUsers" group. Add them to the "IflowUsers" group.
- If an email address is not set, assessment request emails are not sent, and reservation notification emails are not sent when an error occurs.
- If no infrastructure administrators or dual-role administrators are registered in the IflowUsers group, the following message is displayed after the application is forwarded from the **Forward screen** window when the user subscribes to the service:

```
PCS1002  
An error occurred while processing application.  
Please contact the infrastructure administrators.
```

Refer to "19.2.1 Registering an Application Process Assessor" in the "Setup Guide CE" for information on how to register application process assessor.

8.1.2 Deleting an Application Process Assessor

This section explains how to delete an infrastructure administrator or dual-role administrator from the application process assessors.

8.1.2.1 Deleting an Infrastructure Administrator/dual-role Administrator from IflowUsers Group

Follow the procedure below to delete an infrastructure administrator or dual-role administrator from the IflowUsers group members.

For OpenDS

1. Create an LDIF file.

Edit a sample LDIF file to create the file. An example of an LDIF file is shown below.

```
# Delete manager from IflowUsers
dn: cn=IflowUsers,ou=group,dc=fujitsu,dc=com
changetype: modify
delete: member
member: cn=manager,ou=users,dc=fujitsu,dc=com
```

2. Execute the ldapmodify command.

[Windows Manager]

Specify the created LDIF file, and then execute the ldapmodify command.

```
OpenDS Installation_folder\bat\ldapmodify.bat" -p <port number> -f <ldif file> -D <administrator
user DN> -w <password>
```

An execution example is shown below.

```
c:\> c:\Program Files (x86)\Fujitsu\ServerView Suite\opens\bat\ldapmodify -p 1473 -D
"cn=Directory Manager" -w admin -f c:\ldif\deleteuserfromgroup.ldif
Processing MODIFY request for cn=IflowUsers,ou=group,dc=fujitsu,dc=com
MODIFY operation successful for DN cn=IflowUsers,ou=group,dc=fujitsu,dc=com
```

[Linux Manager]

Specify the created LDIF file, and then execute the ldapmodify command.

```
# OpenDS Installation_folder/bin/ldapmodify" -p <port number> -f <ldif file> -D <administrator
user DN> -w <password>
```

An execution example is shown below.

```
# /opt/fujitsu/ServerViewSuite/opens/bin/ldapmodify -p 1473 -D "cn=Directory Manager" -f /tmp/
ldif/adduser2group.ldif -w admin
Processing MODIFY request for cn=IflowUsers,ou=group,dc=fujitsu,dc=com
MODIFY operation successful for DN cn=IflowUsers,ou=group,dc=fujitsu,dc=com
```

Note

- In the command input line, enter the command as one line without entering any line feeds.
- For the directory service port number, administrator DN, and administrator DN password, enter the values that were set during installation.

For Active Directory

1. From the Start menu, open [Control Panel]-[Administrative Tools]-[Active Directory Users and Computers].
2. Select the name of a domain that is managed by Active Directory.
3. Right-click "IflowUsers" of the organizational unit "Group", and select [Property].
4. Select the [Members] tab, and select the members to delete from the member list, and click the [Remove] button.
5. A confirmation dialog will be displayed. Click [Yes].
6. After returning to the property window of the group, confirm that the members have been deleted correctly, and click the [OK] button.

8.2 Settings for Sending Email

This section explains how to change settings for sending an email.

Settings for the Email Sent from Tenant Management

Email sent from the tenant management will be enabled only if the tenant has set the Performing tenant management setting.

When an operation such as registering a tenant or adding or changing a user has been performed, notification to that effect is sent to the tenant administrators, tenant users, and tenant email addresses within that same tenant.

Refer to "19.1 Settings for Sending Email" in the "Setup Guide CE" for information on how to change settings for e-mail sent from tenant administrators.

Settings for Email Sent from the L-Platform Management Window

Email sent from the L-Platform management window notifies the end or failure of processing to the tenant administrators and the tenant users when the tenant users have used the ROR Console to perform an application to use L-Platform, an L-Platform modification, or an application to cancel L-Platform.

Refer to "19.1 Settings for Sending Email" in the "Setup Guide CE" for information on how to change settings for email sent from the L-Platform Management window.

Email Sent from the Usage Charge Calculator

Email will be enabled if the calculator for charges is used.

A usage charge file is sent to the set email address with the monthly usage charges for each tenant.

Refer to "19.1.4 Email Sent from the Usage Charge Calculator" in the "Setup Guide CE" for information on the email settings used for the usage charge calculator.

Email Sent via an Application Process

An email will be sent via the application process when changes or requests have been made.

The following notification will be sent for an application to use L-Platform, an L-Platform modification, or an application to cancel L-Platform from the L-Platform management window:

- Notification of acceptance of application, rejection of application, and dismissal of application to the tenant users
- Notification of request for approval and dismissal of application to the tenant administrators
- Notification of request for assessment to the infrastructure administrators

Refer to "19.1.6 Settings for Email Sent via the Application Process" in the "Setup Guide CE" for information on how to change settings for email sent from an application process."

Settings for the Email Sent from the Dashboard

Email sent from the Dashboard will be enabled only if using the dashboard alert function.

The dashboard sends notifications to e-mail address setting in Customizing Email Send Settings if the global pool use rate exceeds the threshold value.

Refer to "19.1.7 Settings for Email Sent from the Dashboard" in the "Setup Guide CE" for information on how to set settings for email sent from the dashboard alert function.

8.3 Settings for Port Number of Management Servers

This section explains how to change the port number of the Management Server as follows:

- ROR console server port number
- L-Platform management port number

Stop the manager before changing the port number. Restart the manager after changing the port number.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to start and stop the manager.

Note that there is no need to stop and start the manager for each port number.

Changing the Port Number of the ROR Console Server

The procedure for changing the port number is as follows.

1. Modify the portal.properties file.

Open the following file:

[Windows Manager]

```
Installation_folder\RCXCTMG\SecurityManagement\conf\portal.properties
```

[Linux Manager]

```
/etc/opt/FJSVctsec/conf/portal.properties
```

Change the port numbers specified in the following URLs. Set the same values in the port numbers:

- portalSsl.url
- authedPortal.url
- sendmail.auth.url

2. Start the Interstage Management Console.

The procedure for starting the Interstage Management Console is as follows:

[Windows Manager]

From the **Start** menu, select **All Programs > Interstage > Application Server > Interstage Management Console**.

[Linux Manager]

1. Start the Web browser.
2. Specify the URL of the Interstage Management Console.

The URL format is as follows:

(If SSL encrypted communication is not being used)

`http://[Host name]:[Port number]/IsAdmin/`

(If SSL encrypted communication is being used)

`https://[Host name]:[Port number]/IsAdmin/`

3. Login to the Interstage Management Console.

3. Change the port number.

Select **System** > Services > Web Server > **RCXCT-ext** > Web Server Settings to change the port number.

Changing the port number of L-Platform management

The procedure for changing the port number is as follows.

1. Modify the portal.properties file.

Open the following file:

[Windows Manager]

```
Installation_folder\RCXCTMG\SecurityManagement\conf\portal.properties
```

[Linux Manager]

```
/etc/opt/FJSVctsec/conf/portal.properties
```

Change the port numbers specified in the following URL:

- vsys.host

An example is shown below. The parts in italics show the information that is changed.

```
vsys.host = http://192.168.11.22:8013/vsys/services/VSYS/
```

2. Modify the `managerview_config.xml` file.

Open the following file.

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\managerview_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/managerview_config.xml
```

Modify the value of the entry tag with `vsys-port` as the key value.

- The entry tag with `vsys-port` as the key value

An example is shown below. The section in italics is the information to be modified.

```
<entry key="vsys-port">8013</entry>
```

8.4 Editing Information in the Home Window

This section explains how to edit the information that is displayed on the lower part of the home window of the ROR Console.



Point

- The information can also be used to notify tenant administrators and tenant users of who to contact.
- The messages can also be edited in the home window. Refer to "3.1 Editing the Home Messages" in the "User's Guide for Infrastructure Administrators CE" for details.

Information are divided into those for infrastructure administrators and those for tenant administrators and tenant users, so use the following respective text files to edit them:

For infrastructure administrators

[Windows Manager]

```
Installation_folder\SVROR\Manager\etc\customize_data\home_tab\home_infra_mes.txt
```

[Linux Manager]

```
/etc/opt/FJSVrcvmr/customize_data/home_tab/home_infra_mes.txt
```

For tenant administrators and tenant users

[Windows Manager]

```
Installation_folder\SVROR\Manager\etc\customize_data\home_tab\home_tenant_mes.txt
```

[Linux Manager]

```
/etc/opt/FJSVrcvmr/customize_data/home_tab/home_tenant_mes.txt
```

Settings

Enter the message, line by line, in the following format:

```
date, message
```

- UTF-8 must be used as the character code in the text file.
- There is no schedule format specified. If no schedule is required, use a comma at the start of the line, and then subsequently enter the message.

- Enter a string of up to 30 characters for the schedule. Commas (,) cannot be included.
- Enter a string of up to 250 characters for the message. Commas (,) can be included.

Example of settings

```
2011/11/11,Maintenance is scheduled for the Kanto network on the weekend.
,Upgraded the operation management software.
```

8.5 Settings for L-Platform Management

This section explains how to change the settings for L-Platform management.

8.5.1 Settings for Permissions to Change L-Platform Templates

Specify whether to permit modification of the value specified in the L-Platform template when an L-Platform usage application is made in the L-Platform Management window.

Note that if modification is not permitted, it is not possible to modify the configuration of L-Platforms that have already been deployed.

Stopping the manager

Stop the manager.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to stop the manager.

Changing L-Platform templates

The procedure for changing the settings for whether or not changes to the L-Platform templates in the L-Platform management window are to be permitted is as follows:

Open the following file.

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\custom_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/custom_config.xml
```

The following information must be modified:

- The entry tag with no-configuration as the key value

Modify the value of the entry tag with no-configuration as the key value. The section in italics is the information to be modified.

Specify "false" to allow the L-Platform template to be modified. Specify "true" to not allow it to be modified. The default value is "false".

```
<entry key="no-configuration">false</entry>
```

Starting the manager

Start the manager.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to start the manager.

8.5.2 Subnet Settings at Segment Editing

It is possible to change the method for setting up the subnets that are allocated to segments when performing an application to use L-Platform. Use the following procedure to use network resource names rather than IP addresses to select which subnets to allocate to segments during subnet setup.

Refer to "8.3.11 L-Platform Reconfiguration" in the "User's Guide for Tenant Administrators" for details on changing the configuration.

1. Open the Manager View settings file in a text editor.

The Manager View settings file is stored in the following location:

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\managerview_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/managerview_config.xml
```

2. Add the following key and value.

Key name	Content
network-list-show-resource-name	false: Uses the IP address to select a subnet. (This is the default value. This is applicable even when this key is not defined.) true: Uses the network resource name to select a subnet.

3. Save the file.
4. Restart the manager.
Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to Restart the manager.

8.5.3 Settings for the Simplified Reconfiguration Function

The simplified reconfiguration function is a function that allows specification changes to be performed for a server, when a new system is being created or when a configuration is being changed after deployment, simply by selecting a server type.

When this function is enabled, individual values cannot be changed directly.

To change the settings for this function, perform the following procedure.

Refer to "8.3.11 L-Platform Reconfiguration" in the "User's Guide for Tenant Administrators" for details on changing the configuration.

1. Open the settings file in a text editor.

The settings file is stored in the following location:

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\managerview_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/managerview_config.xml
```

2. Add the following key and value:

Key name	Content
enable-easy-reconfigure	false: Disables the function. (This is the default value. This is applicable even when this key is not defined.) true : Enables the function

3. Save the file.
4. Restart the manager.
Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to Restart the manager.

8.5.4 Distribution Ratio Settings

The distribution ratio settings set a simple selection method for the distribution ratios of CPUs and memory that correspond to the distribution ratio settings of VMware.

Note that the settings are enabled only if the simplified reconfiguration function has been disabled.

To change the settings, implement the following procedure:

Refer to "8.3.11 L-Platform Reconfiguration" in the "User's Guide for Tenant Administrators" for details on changing the configuration.

1. Use the editor to open the settings file.

The settings file is stored in the following location:

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\managerview_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/managerview_config.xml
```

2. Add the following keys and values:

Key name	Content
share-easy-setting	false: Directly edits values. (This is the default value. This is applicable even when this key is not defined.) true: Selects from a list box the values to be set that show the distribution ratio of memory. The values to be set are as follows:

Value	Distribution ratio (share)
Low (500)	500
Standard (1,000)	1,000
High (2,000)	2,000

3. Save the file.
4. Restart the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

8.5.5 Application Process Settings

This section explains how to modify the application process settings.

8.5.5.1 How to Modify the Application Process Settings

This section explains how to modify the setting whether to use the application process.



Note

The setting to "use" application process cannot be modified to "not use" once the operation has started.

Refer to "19.2 Application Process Settings" in the "Setup Guide CE" for information on how to change the setting for whether or not an application process is used.

8.5.5.2 How to Modify Application Process to be Used

This section explains how to modify the application process to be used.



Note

If the application process to be used is being changed after the manager starts its operation, make sure that there are no pending processes before changing it. If there are pending processes, finish all of them by cancelling, approving, rejecting, accepting, or dismissing each of them.

Refer to "19.2 Application Process Settings" in the "Setup Guide CE" for information on how to change the application process to be used.

8.5.6 Editing the Environment Setup File for the L-Platform API

Refer to "19.7 Editing the Environment Setup File for the L-Platform API" in the "Setup Guide CE" for information on how to change the environment settings for the L-Platform API.

8.5.7 Edit the License Agreement

Refer to "19.12 Edit the License Agreement" in the "Setup Guide CE" for information on how to edit the license displayed in the L-Platform Management window.

8.5.8 Settings when RHEL5-Xen is used

Refer to "19.8 Settings when RHEL5-Xen is used" in the "Setup Guide CE" for information on the settings for when RHEL5-Xen is to be used.

8.5.9 Default Password Setting for Sent Emails

Refer to "19.1 Settings for Sending Email" in the "Setup Guide CE" for information on how to set whether to include the deployed server's default password in the emails sent when an L-Platform is deployed or a server is added to an L-Platform.

8.5.10 Settings for the Maximum Number of Connections for the L-Platform Template

The maximum number of L-Servers that can be placed in an L-Platform Template and the maximum number of NICs in a segment of an L-Platform Template can be modified.

1. Use the editor to open the settings file.

The settings file is stored in the following location:

[Windows Manager]

```
Installation_folder\RCXCTMG\MyPortal\config\managerview_config.xml
```

[Linux Manager]

```
/etc/opt/FJSVctmyp/config/managerview_config.xml
```

2. Add the following keys and values:

Key name	Content
maximum-number-of-connections-in-template	Specify the maximum number of L-Servers that can be placed in the L-Platform Template. Without a key, the default value is 30.
maximum-number-of-connections-in-segment	Specify the maximum number of NICs in the segment of the L-Platform Template. Without a key, the default value is 30.

Note

.....
If there is a firewall, the maximum number of connections in the segment defined in the rule set will be the smaller value out of the maximum number of servers in the ruleset and the configured value of the "maximum-number-of-connections-in-segment". Segments that are not defined in the firewall rule set will use the configured value.
.....

3. Save the file.
4. Restart the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

8.5.11 Customizing the User Rights for L-Platform Operations

It is possible to customize the user rights in the L-Platform management window to suit the role of the user (tenant administrator or tenant user).

Customize user rights according to the design changes made in "5.2 Customizing Access Authority for L-Platform Operations" in the "Design Guide CE".

You can use a command to customize user rights.

Refer to "Chapter 11 Access Authority Customize Commands" in the "Reference Guide(Command/XML) CE" for information on the command to customize user rights.

8.6 Settings for Tenant Management and Account Management

This section explains how to change the settings for the tenant management and the account management, and explains how to edit the user agreement that is displayed when registering a user.

8.6.1 Settings for Tenant Management and Account Management

This section explains how to change the settings for the tenant management and the account management.

- Display setting for user list
This section explains the procedure for changing the setting for whether or not tenant users are to be displayed, when an infrastructure administrators has used the tenant management to display the user list.
- Setting for registration format of tenant users
This section explains the procedure for changing the setting for whether a provisional account of a tenant user is to be registered or whether the tenant user is to be registered directly, when a tenant administrator registers a tenant user.
- Setting for execution authority of the tenant management
This section explains the procedure for changing the setting for whether or not a tenant administrator can perform the following tenant management:
 - Add users
 - Delete users
 - Delegate user privileges
 - Set user password
- Password change notification email settings
This section explains the procedure for modifying the settings when determining whether or not to include a new password within the body of the password change notification email that is sent once password settings are complete, in the event that a tenant administrator sets the user's password.
- Setting for execution authority of the account management
This section explains the procedure for changing the setting for whether or not a tenant administrator or tenant user can perform the following account management:
 - Changing the user's own information
 - Changing the user's own password
- Directory service operation setting
This section explains the procedure for changing the setting for whether or not registration to directory service can be performed and for whether or not password modification is to be allowed, when an infrastructure administrators or a tenant administrator registers a user.

Stopping the manager

Stop the manager.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to stop the manager.

Tenant Management Settings

The procedure for changing the setting of the tenant management is as follows.

1. Open the following file.

[Windows Manager]

```
Installation_folder\RCXCTMG\SecurityManagement\conf\portal.properties
```

[Linux Manager]

```
/etc/opt/FJSVctsec/conf/portal.properties
```

2. The following information must be modified:

Setting item	Settings	
visible.tenantuser	Setting for infrastructure administrators operation	Specify "on" if both tenant administrators and tenant users are to be displayed in the user list for the tenant management, and specify "off" if only tenant administrators are to be displayed. The initial value is "on". If "off" has been specified, the tenant users will not be displayed in the User List window of the tenant management.
provisional.account	Setting for tenant administrator operation	Specify "on" if a provisional account of a tenant user is to be created when the tenant management is to be used to register the tenant user, and specify "off" if the tenant user is to be registered directly. The initial value is "on". If "off" has been specified, the window for directly registering a tenant user will be displayed when registering a tenant user.
allowUpdate		Specify "on" if the tenant management is to be performed, and specify "off" if it is not to be performed. The initial value is "off". If "off" has been specified, the Tenant tab will not be displayed on the ROR Console.
setPassword.tenantadmin.mailwithpasswd		When setting the user's password in tenant management, configure the settings to "on" to include the new password in the body of the password change notification email, or to "off" when not including the password in the email. The default value is set to "on". A new password will be included in the body of the password change notification email in the event that this value is omitted and/or the key is undefined.
leftMenu.modifyUser.admin.visible		Specify "on" if changing user account is to be performed using the account management, and specify "off" if it is not to be performed. The initial value is "on".

Setting item	Settings	
		If "off" has been specified, the Change user account button will not be displayed in the Account window of the account management.
leftMenu.changePassword.admin.visible		Specify "on" if changing user password is to be performed using the account management, and specify "off" if it is not to be performed. The initial value is "on". If "off" has been specified, the Change user password button will not be displayed in the Account window of the account management.
leftMenu.modifyUser.user.visible	Setting for tenant user operation	Specify "on" if changing user account is to be performed using the account management, and specify "off" if it is not to be performed. The initial value is "on". If "off" has been specified, the Change user account button will not be displayed in the Account window of the account management.
leftMenu.changePassword.user.visible		Specify "on" if changing user password is to be performed using the account management, and specify "off" if it is not to be performed. The initial value is "on". If "off" has been specified, the Change user password button will not be displayed in the Account window of the account management.

A setting example is shown below.

If the line in red font below is missing, please add it.

```

... omitted
allowUpdate = on
setPassword.tenantadmin.mailwithpasswd=off
... omitted
leftMenu.modifyUser.admin.visible=on
leftMenu.changePassword.admin.visible=on
leftMenu.modifyUser.user.visible=on
leftMenu.changePassword.user.visible=on

visible.tenantuser=on
provisional.account=on

```

3. Open the following directory service operation definition file.

[Windows Manager]

```
Installation_folder\ROR\SVROR\Manager\etc\customize_data\ldap_attr.rcxprop
```

[Linux Manager]

```
/etc/opt/FJSVrcxmr/customize_data/ldap_attr.rcxprop
```

4. The following information must be modified:

Setting item	Settings	
directory_service	Setting for infrastructure administrators, tenant administrator, and tenant user operation	<p>Specify "true" if user registration to directory service can be performed and password modification is to be allowed when the tenant management is to be used to register a user, and specify "false" if no user registration to directory service is to be performed and no password modification is to be allowed. The initial value is "true".</p> <p>If "false" has been specified, the Set password button will not be displayed in the User List window of the tenant management. In addition, the Change user password button will not be displayed in the Account window of the account management.</p> <p>Note that, if "false" is specified, users must already be registered in the directory service.</p> <p>Perform user registration according to the directory service to be used.</p>

Edit only the "directory_service" line in the definition file.

A setting example is shown below.

```
directory_service=true
```

Starting the manager

Start the manager.

Refer to "2.1 Starting and Stopping the Manager" for information on how to start the manager.

8.6.2 Editing the User Agreement when Registering a User

Refer to "19.13 Editing the User Agreement when Registering a User" in the "Setup Guide CE" for information on how to edit the agreement displayed in the "Registering Users" window when new tenant users perform the registration procedure.

8.7 Accounting Settings

This section explains how to modify the accounting settings.

8.7.1 Display Function Settings for Estimated Price

Usage fee (the estimated price) for the L-Platform template can be displayed in the L-Platform Management window based on L-Platform template accounting information.

This section describes how to modify settings according to whether usage fee (the estimated price) for the L-Platform template will be displayed.

Procedures to modify the settings are as follows:

1. Open the following file.

[Windows Manager]

```
Installation_folder\RCXCFMG\config\vsys_config.xml
```

[Linux Manager]

/etc/opt/FJSVcfmg/config/vsys_config.xml

2. The following information must be modified:

Key	Description	Default value
use-charge	Specifies whether usage fee (the estimated price) for the L-Platform template will be displayed. - yes: Display - no: Do not display	no

A setting example is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE properties SYSTEM "http://java.sun.com/dtd/properties.dtd">
<properties>
  ... omitted
  <entry key="use-charge">yes</entry>
  <entry key="charge-host">localhost</entry>
  <entry key="charge-port">3550</entry>
  <entry key="charge-uri">/resource/ver1.0</entry>
  ... omitted
</properties>
```

3. Open the following file.

[Windows Manager]

Installation_folder\RCXCTMG\MyPortal\config\custom_config.xml

[Linux Manager]

/etc/opt/FJSVctmyp/config/custom_config.xml

4. The following information must be modified:

Key	Description	Default value
estimation-mode	Specifies whether usage fee (the estimated price) for the L-Platform template will be displayed. - 3: Display - 0: Do not display Set to "3" if use-charge in vsys_config.xml is set to "yes", or to "0" if use-charge is set to "no".	0
compatible-estimation (*1)	When overcommit is enabled, specify whether to calculate usage fee (the estimated price) using the operating value or the reserved value. - true: Calculate using operating value (CPU performance and/or memory capacity) - false: Calculate using reserved value (reserved CPU performance and/or reserved memory capacity)	false

*1) These settings are only valid when the overcommit function is enabled. Refer to "19.6 Settings for the Overcommit Function" in the "Setup Guide CE" for further details.

Note also that these settings are only valid when either VMware or Hyper-V is used as the virtual software. If any other virtual software is used, the usage fee (the estimated price) will be calculated using the operating value regardless of whether or not overcommit is enabled or disabled.

A setting example is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<properties>
  <entry key="estimation-mode">3</entry>
  <entry key="compatible-estimation">true</entry>
  ... omitted
</properties>
```

5. Restart the manager.

Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

8.7.2 Currency Information Settings

Currency information can be changed. Default setting is USD (\$).

The currency that can be used is shown below.

Currency	Currency sign	Number of decimal places
United States Dollar	\$	2
Japanese Yen	¥	0
Euro	EUR	2
Singapore dollar	S\$	2

To change the currency information, perform the following procedure:

1. Stop the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to stop the manager.
2. Execute the Change currency information setting command to change the currency information.
Refer to "10.3 currencyset (Change Currency Information Setting)" in the "Reference Guide(Command/XML) CE for information on how to use the Change currency information setting command.
3. Start the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to start the manager.



Note

Determine the currency used when installing the system.
Do not change the currency information once the operation starts.

8.7.3 Metering Log Settings

This section explains how to change the metering log operational settings.

Follow the steps below to change the metering log operational settings.

1. Open the following operational settings file for metering logs:

[Windows Manager]

```
Installation_folder\RCXCTMG\Charging\conf\metering_log.properties
```

[Linux Manager]

```
/etc/opt/FJSVctchg/conf/metering_log.properties
```

2. Change the relevant items in the operational settings file for metering logs:

Key	Description	Default value
retention_period	<p>Retention period of log entries Logs will be deleted once their retention period has passed.</p> <p>Use the following format to specify the retention period: YYYY-MM-DD</p> <p>Example: 0000-03-00: Retain logs for 3 months. 0005-00-00: Retain logs for 5 years.</p>	0000-03-00
periodic_log_use (*1)	<p>Specify whether or not to use the periodic log function:</p> <ul style="list-style-type: none"> - yes: Use - no: Do not use 	yes
periodic_log_schedule_time (*1)	<p>Output time of periodic log Use the following format to specify the output time: HH:mm</p>	00:00
periodic_log_schedule_type (*1)	<p>Output frequency of periodic log Specify one of the following strings:</p> <ul style="list-style-type: none"> - DAILY: Every day - WEEKLY: Every week - MONTHLY: Every month 	DAILY
periodic_log_schedule_day (*1)	<p>Output day of periodic log If periodic_log_schedule_type is WEEKLY or MONTHLY, this item is mandatory.(*2)</p> <ul style="list-style-type: none"> - If periodic_log_schedule_type is WEEKLY: Use the following strings to specify the day of the week: <ul style="list-style-type: none"> - MON - TUE - WED - THU - FRI - SAT - SUN <p>Commas can be used as delimiters to specify a number of days of the week.</p> <ul style="list-style-type: none"> - If periodic_log_schedule_type is MONTHLY: Use one of the following methods to specify a date: <ul style="list-style-type: none"> - Numerics from 1 to 28 indicating the date - LASTDAY string indicating the last day of the month <p>A number of days cannot be specified with this method.</p>	No specification

*1: Changes to this setting are enabled by executing the Change periodic log schedule settings command after changing the settings file.

*2: If periodic_log_schedule_type is DAILY, the periodic_log_schedule_day value will be ignored.

An example of setting the operational settings file is shown below:

```
# delete setting of meteringlog database
# YYYY-MM-DD
# ex. 3 months ago      0000-03-00

retention_period=0000-03-00

# schedule of periodlog insert

periodic_log_use=yes

periodic_log_schedule_time=00:00

periodic_log_schedule_type=DAILY

periodic_log_schedule_day=
```

3. If an item other than retention_period has been changed, execute the Change periodic log schedule settings command. Refer to "10.1 ctchg_chgschedule (Change Periodic Log Schedule Settings)" in the "Reference Guide(Command/XML) CE for information on the Change periodic log schedule settings command.



Note

Points to note when using the usage charge calculator

- Specify either the default value (3 months) or a period longer than the default value for retention_period.
- Do not change the values for the following keys from the default:
 - periodic_log_use
 - periodic_log_schedule_time
 - periodic_log_schedule_type
 - periodic_log_schedule_day

8.7.4 Usage Charge Calculator Settings

This section describes how to change the settings for the usage charge calculator function.

The procedure for changing the settings is as follows:

1. Open the following operating environment file:

[Windows Manager]

```
Installation_folder\RCXCTMG\Charging\conf\accounting.properties
```

[Linux Manager]

```
/etc/opt/FJSVctchg/conf/accounting.properties
```

2. Set the following items in the operating environment file:

Key	Description	Default value
accounting.use	Specify whether to use the usage charge calculator. - yes: Use the usage charge calculator.	no

Key	Description	Default value
	- no: Do not use the usage charge calculator.	
gui.cutoffdate	Specify the default for the cut-off date displayed in the tenant management window of the ROR console. Specify a value between 1 and 31. In cases where the specified date does not exist, the cut-off date will be the end of the month. For example, if 31 is specified, but the month only contains 30 days, then the 30th will be the cut-off date.	31
gui.sendmailaddress	Specify the default for the address to send the usage fee displayed in the tenant management window of the ROR console.	None
usedtime.metering.cpu.perf.vserver	When overcommit is enabled, specify whether to calculate the CPU clock of the virtual server using CPU performance or CPU reserve performance. - cpu_perf: Calculate with CPU performance - cpu_reserve: Calculate with CPU reserve performance	cpu_reserve
usedtime.metering.memory.vserver	When overcommit is enabled, specify whether to calculate the memory usage of the virtual server using memory or memory reserve. - memory_size: Calculate with memory - memory_reserve: Calculate with memory reserve	memory_reserve

An example is shown below:

```
accounting.use = yes
... omitted
gui.cutoffdate = 20
gui.sendmailaddress = example@xxx.com
... omitted
usedtime.metering.cpu.perf.vserver = cpu_reserve
usedtime.metering.memory.vserver = memory_reserve
... omitted
```

- Restart the Manager.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to restart the manager.

8.8 System Condition Server List Settings

This section explains how to change the System Condition Server List settings.

If the L-Platform Management overcommit function is enabled, the CPU and memory settings displayed in the System Condition Server List can be changed. Refer to "19.6 Settings for the Overcommit Function" in the "Setup Guide CE" for information on the L-Platform Management overcommit function settings.



Note

If the overcommit function is used, the settings must match those of the L-Platform Management overcommit function.

Use the procedure below to change the System Condition Server List settings.

1. Open the following file:

[Windows Manager]

```
Installation_folder\SWRBAM\CMDB\FJSVcmdbm\CMDBConsole\WEB-INF\classes\viewlist_en.xml
```

[Linux Manager]

```
/opt/FJSVcmdbm/CMDBConsole/WEB-INF/classes/viewlist_en.xml
```

2. Set the following items:

Settings item	Explanation
serverByOrg_ROR.bottom.column.11.isEnabled	Set "true" to display the CPU Reserve Clock Rate. Set "false" to hide it. The default value is "false".
serverByOrg_ROR.bottom.column.14.isEnabled	Set "true" to display the Memory Reserve Size. Set "false" to hide it. The default value is "false".

A settings example is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<properties>
  ... omitted
<entry key="serverByOrg_ROR.bottom.column.11.isEnabled">false</entry>
<entry key="serverByOrg_ROR.bottom.column.11.label">Reserved CPU clock speed(GHz)</entry>
<entry key="serverByOrg_ROR.bottom.column.11.path">/cmdb:item/cmdb:record[@type='observed']/rc:LogicalServer/@reservedCPUClock</entry>
<entry key="serverByOrg_ROR.bottom.column.11.width">135</entry>
  ... omitted
<entry key="serverByOrg_ROR.bottom.column.14.isEnabled">false</entry>
<entry key="serverByOrg_ROR.bottom.column.14.label">Reserved memory size(GB)</entry>
<entry key="serverByOrg_ROR.bottom.column.14.path">/cmdb:item/cmdb:record[@type='observed']/rc:LogicalServer/@reservedMemorySize</entry>
<entry key="serverByOrg_ROR.bottom.column.14.width">140</entry>
  ... omitted
</properties>
```

 **Note**

- If the L-Platform Management overcommit function is disabled, when the viewlist_en.xml overcommit setting is enabled, the CPU Reserve Clock Rate and the Memory Reserve Size columns are displayed but the values are not displayed.
- When editing the viewlist_en.xml file, do not change any settings items other than serverByOrg_ROR.bottom.column.11.isEnabled and serverByOrg_ROR.bottom.column.14.isEnabled.
- Save the viewlist_en.xml file before you edit the file. If any settings other than serverByOrg_ROR.bottom.column.11.isEnabled and serverByOrg_ROR.bottom.column.14.isEnabled are changed, restore the saved file.

8.9 Settings for Event Log Output for CMDB Agent

This section explains how to change the settings that determine whether the start/end messages for CMDB agent information collection are output to event logs.

Use the following procedure to change the settings that determine whether to prevent start/end messages from being output to event logs or not.

1. Open the following files

[Windows Manager]

```
Installation_folder\SWRBAM\CMDB\FJSVcndbm\axis2\WEB-INF\services\mdr_cfm\cmdb.properties
Installation_folder\SWRBAM\CMDB\FJSVcndbm\axis2\WEB-INF\services\mdr_ror\cmdb.properties
```

[Linux Manager]

```
/opt/FJSVcndbm/axis2/WEB-INF/services/mdr_cfm/cmdb.properties
/opt/FJSVcndbm/axis2/WEB-INF/services/mdr_ror/cmdb.properties
```

2. Set the following items:

- schedule.syslog.disable

Change the value above. A modification example is shown below. Change the part in italics.

Set this item to "true" to prevent start/update messages from being output to event logs, or "false" otherwise.

```
schedule.syslog.disable=true
```

3. Restart the CMDDB.

Open a command prompt and execute the following commands:

[Windows Manager]

```
Installation_folder\SWRBAM\CMDB\FJSVcndbm\bin\cmdbstop
Installation_folder\SWRBAM\CMDB\FJSVcndbm\bin\cmdbstart
```

[Linux Manager]

```
/opt/FJSVcndbm/bin/cmdbstop.sh
/opt/FJSVcndbm/bin/cmdbstart.sh
```

Part 3 Retention

Chapter 9 Hardware Maintenance.....	39
Chapter 10 Backup and Restoration of Admin Servers.....	62

Chapter 9 Hardware Maintenance


This chapter explains how to perform hardware maintenance.

9.1 Overview

This section explains how to perform maintenance on the hardware devices managed by Resource Orchestrator.

The following flowchart shows the procedure for maintaining hardware when failures occur on registered servers.

Figure 9.1 Hardware Maintenance Flow



*1: For details on how to identify failures, refer to "11.3 Addressing Resource Failures".

*2: For details on how to configure and release the maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

*3: For details on server switchover, failback, and takeover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

*4: For details on backing up and restoring system images, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

*5: For details on maintenance LED operations, refer to "9.2.1 Maintenance LED". Please note that maintenance LED operations are only supported for PRIMERGY BX servers.

*6: For details on re-configuring hardware properties, refer to "9.3.1 Reconfiguration of Hardware Properties".

*7: For details on power control, refer to "Chapter 14 Power Control" in the "User's Guide VE".

The following hardware replacements can be performed:

- Replacing servers

Replace a server that has been registered in Resource Orchestrator.
For details on replacing servers, refer to "[9.3.2 Replacing the Server](#)".

- Replacing server components

Replace hardware components (such as a NIC, HBA, or hard disk) of a registered server.
For details on replacing or adding server components, refer to "[9.3.3 Replacing and Adding Server Components](#)".

- Replacing Non-Server Hardware

Replace registered chassis, management blades, or any other hardware components external to servers.
For details on replacing non-server hardware, refer to "[9.3.4 Replacing Non-server Hardware](#)".

9.2 Blade Server Maintenance

This section explains the maintenance of blade servers.

9.2.1 Maintenance LED

This section explains how to operate maintenance LEDs.

Activating a server blade's maintenance LED make it easy to identify a server from others. When replacing servers, it is recommended to use this function to identify which server blade should be replaced.

To activate the maintenance LED of a managed server running either a physical OS or a VM host, the server should be placed into maintenance mode first.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".



- Maintenance LED control is only available for PRIMERGY BX servers. The actual LED used as an identification LED differs between server models.
 - For PRIMERGY BX600 servers, the power LED is used (blinks when activated).
 - For PRIMERGY BX900 servers, the ID indicator is used (lit when activated).
 - If SNMP agent settings within the management blade configuration are incorrect, maintenance LED operations in Resource Orchestrator will end successfully, but the state of the identification LED will not change. Configure the settings correctly, referring to "8.2 Configuring the Server Environment" in the "Design Guide CE".
-

Activating a Maintenance LED

Use the following procedure to activate a server blade's maintenance LED.

1. In the ROR console server resource tree, right-click the target server, and select [LED]-[ON] from the popup menu.

The [Turning on Maintenance LED] dialog is displayed.

2. Click <OK>.

Selecting the [Automatically turn off] checkbox will automatically shut down the server after activating its maintenance LED.

Note

Once the maintenance LED of a server blade is activated, new errors detected in that server cannot be checked from its LED anymore. Check the server status directly from the ROR console.

Deactivating a Maintenance LED

Use the following procedure to deactivate a server blade's maintenance LED.

1. In the ROR console server resource tree, right-click the target server, and select [LED]-[OFF] from the popup menu.

The [Turning off Maintenance LED] dialog is displayed.

2. Click <OK>.

The maintenance LED is turned off.

9.2.2 Reconfiguration of Hardware Properties

This section explains how to re-configure hardware properties for replaced hardware.

After hardware replacement, it is necessary to re-configure Resource Orchestrator with the new hardware properties.

For PRIMERGY BX servers, the hardware properties are automatically re-configured.

Note

- Ensure this operation is performed only after the replacement of one of the following: a server itself, the NIC used for either the admin or public LAN, or the HBA.
If it is not, there is a possibility that operations on the server will not run correctly.
- After replacing the hardware, the server status becomes "unknown". The appropriate status can be restored by re-configuring the hardware properties from the server.

Prerequisites

The following prerequisites must be satisfied before this operation can be performed:

- Both the replaced server and replacement server must be the same model
A warning message is shown if the model of the replacement server differs from that of the replaced server.
- When replacing a PRIMERGY BX server, the replacement server must be inserted into the same slot as used for the replaced server
Hardware properties cannot be re-configured from a server inserted in a different slot. An error occurs if no server is inserted in the slot occupied by the previous server.
- The replaced server and replacement server must both be of the same blade type
If the blade types of the replaced and replacement servers are different, an error will occur.

To move a server to a different slot within a chassis, the server must be deleted first, and then registered again after being inserted in its new slot.

Pre-Configuration

For PRIMERGY BX servers, the hardware properties are automatically re-configured.

If automatic re-configuration is not necessary for PRIMERGY BX servers, delete the following file, and then restart the manager.

Placeholder for the Definition File

[Windows Manager]
Installation_folder\SVROR\Manager\etc\customize_data

[Linux Manager]
/etc/opt/FJSVrcvnr/customize_data

Name of the Definition File

auto_replace.rcxprop

Re-configuring Hardware Properties after Server Replacement

If the definition file has already been created, there is no need to set the hardware information again.

If the definition file has not been created, use the following procedure to re-configure properties for replaced hardware.

1. After hardware replacement, insert the server and check that the following message is displayed in the event log.

Server blade added

After the message is displayed, shut down the server if it is still powered on.

2. After approximately 30 seconds, right-click the target server in the ROR console server resource tree, and select [Hardware Maintenance]-[Re-configure] from the popup menu.

The [Re-configure Hardware Properties] dialog is displayed.

3. Click <OK>.

The original hardware properties of the selected managed server are updated with new hardware properties obtained from the replacement server. If the maintenance LED is on it will be turned off automatically.

Note

When registering an agent and performing backups of system images or cloning images, perform one of the following.

- Restart the managed server after reconfiguring the hardware properties
- Restart the related services described in "2.2 Starting and Stopping an Agent"

9.2.3 Replacing the Server

This section details the procedure to follow when replacing servers.

Information

- Follow the same procedure when replacing servers where VM hosts are running.
- No specific action is required in Resource Orchestrator when replacing admin servers or HBA address rename setup service servers.

- Replacing a server assigned with spare servers

Use the following procedure to switch applications over to a spare server and replace a server with minimal interruption.

1. Perform server switchover

Switch over the server to replace with its spare server.

For server switchover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

After the server has been switched over, its maintenance LED is automatically activated, and the server is powered down.

2. Replace the server

Replace the server whose maintenance LED is activated.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

After hardware properties have been re-configured, the maintenance LED is automatically turned off in the ROR console.

4. Perform post-server switchover operations

For details on the operations that must be performed after server switchover, refer to "4.3 Post-Switchover Operations" in the "Operation Guide VE".

- Replacing a server with no spare server assigned

Use the following procedure to smoothly replace a server and resume its applications.

1. Place the server into maintenance mode

Place the primary server to replace into maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

2. Create a system image backup

For local boot servers, create a system image backup when possible.

For details on backing up system images, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

In SAN boot environments, the boot disk can be restored without having to back up and restore a system image.

3. Activate the maintenance LED

Activate the maintenance LED on the server that is to be replaced before shutting it down.

For details on how to activate maintenance LEDs, refer to "[9.2.1 Maintenance LED](#)".

4. Replace the server

Replace the server whose maintenance LED is activated.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

5. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

After hardware properties have been re-configured, the maintenance LED is automatically turned off in the ROR console.

6. Restore the boot disk

- Local boot

There is no need to restore the boot disk if the original disk is installed on the replaced server. Simply power on the replacement server.

If the boot disk was replaced and a system image backup was collected, restore that backup.

Refer to "16.3 Restoring a System Image" in the "User's Guide VE" for details on how to restore a system image. After the system image is restored, the server will be automatically powered on.

If there is no backup of the system image, run the installation program again.

- SAN boot

As the replaced server can be easily configured to access the original boot disk using HBA address rename there is no need to restore the boot disk. Simply power on the replacement server.

7. Release maintenance mode

Release the replaced server from maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

- Servers with no agent registered

Use the following procedure to replace servers on which no Resource Orchestrator agent was registered.

1. Activate the maintenance LED

Activate the maintenance LED on the server that is to be replaced and shut down the server if it is still powered on.

For details on how to activate maintenance LEDs, refer to "9.2.1 Maintenance LED".

2. Replace the server

Replace the server whose maintenance LED is activated.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "9.3.1 Reconfiguration of Hardware Properties".

After hardware properties have been re-configured, the maintenance LED is automatically turned off in the ROR console.

9.2.4 Replacing Non-Server Hardware

This section explains how to replace hardware external to servers.

- Replacing chassis

No specific action is required in Resource Orchestrator.

- Replacing management blades

No specific action is required in Resource Orchestrator.

- Replacing LAN switch blades

No specific action is required for PRIMERGY BX900/BX400 LAN switch blades in IBP mode.

For other LAN switch blades of PRIMERGY BX models, after replacing a switch blade, update the new LAN switch blade with the VLAN settings that were previously configured in Resource Orchestrator.

Use the following procedure to replace a LAN switch blade.

1. Replace the faulty LAN switch blade.

2. Restore the LAN switch blade configuration backup (which includes all of the LAN switch blade settings) to the new LAN switch blade.

If the LAN switch blade configuration was not been backed up in advance, it has to be restored by configuring each setting (except VLAN settings) to the same values set during the initial installation.

Refer to the manual of the LAN switch blade used for details on how to back up and restore LAN switch blade configurations.

3. Update the new LAN switch blade with the latest VLAN settings configured in Resource Orchestrator.

- a. In the ROR console server resource tree, right-click the target LAN switch, and select [Restore] from the popup menu.

The [Restore LAN Switch] dialog is displayed.

- b. Click <OK>.

VLAN settings are applied to the specified LAN switch blade.

Note

To replace LAN switch blades with different models, first delete the registered LAN switch blade, and then register the replacement LAN switch blade.

After the LAN switch blade is registered, the VLAN settings must be configured for the internal and external ports.

For details on the VLAN settings, refer to "5.4.4 Configuring VLANs on LAN Switch Blades" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

When changing from IBP to another mode, or vice versa, when using a PRIMERGY BX900/BX400 series LAN switch blade, delete the registered LAN switch blade and register it again.

- Replacing Fibre Channel switch blades

No specific action is required in Resource Orchestrator.

In Resource Orchestrator, the settings for Fibre Channel switch blades are not restored.

Restore the settings for Fibre Channel switch blades based on the information in hardware manuals.

- Replacing storage blades

No specific action is required in Resource Orchestrator when replacing a storage blade that does not contain the boot disk of a server blade.

Use the following procedure to replace a storage blade that contains the boot disk of a server blade.

1. Replace the storage blade.
2. Insert the server blade's boot disk in the new storage blade.
3. If the boot disk's content was backed up, restore it.

Information

The backup and restore functions available in Resource Orchestrator can be used to restore the boot disk contents.

For details, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

9.3 Maintenance for Servers Other Than Blade Servers

This section explains server maintenance for other than blade servers.

9.3.1 Reconfiguration of Hardware Properties

This section explains how to re-configure hardware properties for replaced hardware.

After hardware replacement, it is necessary to re-configure Resource Orchestrator with the new hardware properties.

Note

- Ensure this operation is performed only after the replacement of one of the following: a server itself, the NIC used for either the admin or public LAN, or the HBA.
If it is not, there is a possibility that operations on the server will not run correctly.
- When the system board or GSPB of a PRIMEQUEST server has been changed, ensure that this operation is performed.
If it is not, there is a possibility that operations on the server will not run correctly.
- After replacing the hardware, the server status becomes "unknown". The appropriate status can be restored by re-configuring the hardware properties from the server.

Prerequisites

The following prerequisites must be satisfied before this operation can be performed:

- Both the replaced server and replacement server must be the same model

A warning message is shown if the model of the replacement server differs from that of the replaced server.

- The replaced server and replacement server must both be of the same blade type

If the blade types of the replaced and replacement servers are different, an error will occur.

To move a server to a different slot within a chassis, the server must be deleted first, and then registered again after being inserted in its new slot.

Pre-Configuration

For SPARC Enterprise servers, the hardware properties are automatically re-configured.

Re-configuring Hardware Properties after Server Replacement

- For Rack Mount and Tower Servers

Use the following procedure to re-configure properties for replaced hardware.

1. If the agent or ServerView Agents has already been registered, power on the server.
2. In the ROR console server resource tree, right-click the target server and select [Hardware Maintenance]-[Re-configure] from the popup menu.

The [Re-configure Hardware Properties] dialog is displayed.

3. Enter MAC addresses for the network interfaces used on the admin LAN.

This step can be skipped if no network interface was replaced.

- Admin LAN MAC Address (NIC1)

Required only if the agent is not registered.

- MAC address (NIC2) under SAN Boot/admin LAN redundancy

This item is only required for the following cases:

- When using the HBA address rename setup service
- When using GLS for admin LAN redundancy on the target server
- For the spare server of a managed server using admin LAN redundancy

4. Click <OK>.

The original hardware properties of the selected managed server are updated with new hardware properties obtained from the replacement server.

- For PRIMEQUEST Servers

Use the following procedure to re-configure properties for replaced hardware.

1. Replace the system board or GSPB, and insert the server.
2. After approximately 30 seconds, right-click the target server in the ROR console server resource tree, and select [Hardware Maintenance]-[Re-configure] from the popup menu.

The [Re-configure Hardware Properties] dialog is displayed.

3. Click <OK>.

The original hardware properties of the selected managed server are updated with new hardware properties obtained from the replacement server.

- For SPARC Enterprise Servers

Note that in this case there is no need to set the hardware information again.

Note

When registering an agent and performing backups of system images or cloning images, perform one of the following.

- Restart the managed server after reconfiguring the hardware properties
- Restart the related services described in "[2.2 Starting and Stopping an Agent](#)"

9.3.2 Replacing the Server

This section details the procedure to follow when replacing servers.

Information

- Follow the same procedure when replacing servers where VM hosts are running.
- No specific action is required in Resource Orchestrator when replacing admin servers or HBA address rename setup service servers.

For Rack Mount and Tower Servers

- Replacing a server assigned with spare servers

Use the following procedure to switch applications over to a spare server and replace a server with minimal interruption.

1. Perform server switchover

Switch over the server to replace with its spare server.

For server switchover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

The server to replace is automatically powered off after switchover.

2. Replace the server

Replace the server.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

Configure the remote management controller of the replacement server with the same IP address, user name, password, and SNMP trap destination as those set on the original server.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

4. Perform post-server switchover operations

For details on the operations that must be performed after server switchover, refer to "4.3 Post-Switchover Operations" in the "Operation Guide VE".

- Replacing a server with no spare server assigned

Use the following procedure to smoothly replace a server and resume its applications.

1. Place the server into maintenance mode

Place the primary server to replace into maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

2. Create a system image backup

For local boot servers, create a system image backup when possible.

For details on backing up system images, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

In SAN boot environments, the boot disk can be restored without having to back up and restore a system image.

3. Power OFF

Shut down the server to replace if it is still powered on.

For details on shutting down servers, refer to "Chapter 14 Power Control" in the "User's Guide VE".

4. Replacing the Server

Replace the server.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

Configure the remote management controller of the replacement server with the same IP address, user name, password, and SNMP trap destination as those set on the original server.

5. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

6. Restore the boot disk

- Local boot

There is no need to restore the boot disk if the original disk is installed on the replaced server. Simply power on the replacement server.

If the boot disk was replaced and a system image backup was collected, restore that backup.

Refer to "16.3 Restoring a System Image" in the "User's Guide VE" for details on how to restore a system image. After the system image is restored, the server will be automatically powered on.

If there is no backup of the system image, run the installation program again.

- SAN boot

The replaced server can be easily configured to access the original boot disk using I/O virtualization. Therefore, there is no need to restore the boot disk. Simply power on the replacement server.

7. Release maintenance mode

Release the replaced server from maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

- Servers with no agent registered

Use the following procedure to replace servers on which no Resource Orchestrator agent was registered.

1. Power OFF

Shut down the server to replace if it is still powered on.

For details on shutting down servers, refer to "Chapter 14 Power Control" in the "User's Guide VE".

2. Replacing the Server

Replace the target server.

Change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

Configure the remote management controller of the replacement server with the same IP address, user name, password, and SNMP trap destination as those set on the original server.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

For SPARC Enterprise Servers

- Replacing a server assigned with spare servers

Use the following procedure to switch applications over to a spare server and replace a server with minimal interruption.

- When replacing an HBA

1. Perform server switchover

Switch over the server to replace with its spare server.

For server switchover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

The server to replace is automatically powered off after switchover.

2. Replace the server

Replace the HBA of the server.

Change the OBP settings of the replacement server to match the operating environment.

For details on OBP settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing OBP settings.

Configure the remote management controller of the replacement server with the same IP address, user name, password, and SNMP trap destination as those set on the original server.

3. Change the WWN information settings

Change the WWN information settings for after server replacement to the WWN value of the HBA after server replacement.

Leave the value of the target CA as the one before changes were made.

4. Perform post-server switchover operations

For details on the operations that must be performed after server switchover, refer to "4.3 Post-Switchover Operations" in the "Operation Guide VE".



.....
If takeover was performed before replacement of the HBA, release the spare server settings. Change the WWN information settings following the procedure in "Replacing a server with no spare server assigned".
.....

- When not replacing an HBA

1. Perform server switchover

Switch over the server to replace with its spare server.

For server switchover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

The server to replace is automatically powered off after switchover.

2. Replace the server

Replace components (other than the HBA) of the server.

Change the OBP settings of the replacement server to match the operating environment.

For details on OBP settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing OBP settings.

Configure the remote management controller of the replacement server with the same IP address, user name, password, and SNMP trap destination as those set on the original server.

3. Perform post-server switchover operations

For details on the operations that must be performed after server switchover, refer to "4.3 Post-Switchover Operations" in the "Operation Guide VE".

- Replacing a server with no spare server assigned

When WWN information has been configured, use the following procedure to change the WWN information to that of the WWPN value of the replaced HBA.

1. Delete the target CA

When there are target CA settings in the WWN information, stop the server and then delete the target CA settings (set them as hyphens ("-")).

2. Replace the server

Replace the HBA of the server.

Change the OBP settings of the replacement server to match the operating environment.

For details on OBP settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing OBP settings.

When the target CA was deleted in step 1., configure zoning and host affinity settings in the WWPN value of the replacement HBA.

For details, refer to the ESC users guide.

3. Change the WWN information settings

Change the WWN information settings for after server replacement to the WWN value of the HBA after server replacement.

When the target CA was deleted in step 1., configure a new target CA.

After configuration, restart the server.

After starting the server, check the status of the server's HBA from ESC.

When the HBA status is "unknown", delete it.

When the HBA status is displayed as "access path inheritance is required" (yellow icon), perform access path inheritance.

For details, refer to the ESC users guide.

When the target CA was not deleted in step 1., configure the target CA as a hyphen ("-").

For PRIMEQUEST Servers

- Replacing a server assigned with spare servers

Use the following procedure to switch applications over to a spare server and replace a server with minimal interruption.

1. Perform server switchover

Switch over the server to replace with its spare server.

For server switchover, refer to "Chapter 4 Server Switchover" in the "Operation Guide VE".

The server is automatically powered off after switchover.

2. Replace the server

Replace the server.

Use the Maintenance Wizard of the Management Board Web-UI to perform replacement.

For details on the Maintenance Wizard, refer to the PRIMEQUEST manual.

Also, change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

4. Perform post-server switchover operations

For details on the operations that must be performed after server switchover, refer to "4.3 Post-Switchover Operations" in the "Operation Guide VE".

- Replacing a server with no spare server assigned

Use the following procedure to smoothly replace a server and resume its applications.

1. Place the server into maintenance mode

Place the primary server to replace into maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

2. Create a system image backup

For local boot servers, create a system image backup when possible.

For details on backing up system images, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

In SAN boot environments, the boot disk can be restored without having to back up and restore a system image.

3. Power OFF

Shut down the server to replace if it is still powered on.

For details on shutting down servers, refer to "Chapter 14 Power Control" in the "User's Guide VE".

4. Replacing the Server

Replace the server.

Use the Maintenance Wizard of the Management Board Web-UI to perform replacement.

For details on the Maintenance Wizard, refer to the PRIMEQUEST manual.

Also, change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

5. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

6. Restore the boot disk

- Local boot

There is no need to restore the boot disk if the original disk is installed on the replaced server. Simply power on the replacement server.

If the boot disk was replaced and a system image backup was collected, restore that backup.

Refer to "16.3 Restoring a System Image" in the "User's Guide VE" for details on how to restore a system image. After the system image is restored, the server will be automatically powered on.

If there is no backup of the system image, run the installation program again.

- SAN boot

As the replaced server can be easily configured to access the original boot disk using HBA address rename there is no need to restore the boot disk. Simply power on the replacement server.

7. Release maintenance mode

Release the replaced server from maintenance mode.

For details on maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

- Servers with no agent registered

Use the following procedure to replace servers on which no Resource Orchestrator agent was registered.

1. Power OFF

Shut down the server to replace if it is still powered on.

For details on shutting down servers, refer to "Chapter 14 Power Control" in the "User's Guide VE".

2. Replacing the Server

Replace the server.

Use the Maintenance Wizard of the Management Board Web-UI to perform replacement.

For details on the Maintenance Wizard, refer to the PRIMEQUEST manual.

Also, change the BIOS settings of the replacement server to match the operating environment.

For details on BIOS settings, refer to "8.2 Configure the Server Environment" in the "Design Guide CE".

Shut down the server after completing BIOS settings.

3. Re-configure hardware properties after replacement

After replacing the server, re-configure Resource Orchestrator with the latest hardware properties.

For details on how to re-configure hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".

9.3.3 Replacing and Adding Server Components

This section explains how to replace and add server components.

- Replacing and Adding Network Interfaces (Admin LAN, Public LAN)

The procedure used to replace and add network interfaces is the same as that described in "9.3.2 Replacing the Server". For details, refer to "9.3.2 Replacing the Server".

When adding or removing network interfaces, if the target server is running Red Hat Enterprise Linux 5 or Citrix XenServer, after completing the steps described in "9.3.2 Replacing the Server", log in with administrative privileges on the managed server and execute the following command.

```
# /usr/local/sbin/macbindconfig create <RETURN>
```

[Xen]

When using Citrix XenServer, reinstall XenServer referring to the Citrix XenServer manual.

When using Red Hat Enterprise Linux 5 Virtualization (Xen-Based), perform the following procedure.

1. Execute the following command to temporarily disable automatic startup of the xend daemon and then restart the managed server.

```
# chkconfig xend off <RETURN>
```

2. Once the server has restarted, execute the following commands to update MAC address bindings, re-enable automatic startup of the xend daemon, and restart the xend daemon itself.

```
# /usr/local/sbin/macbindconfig create <RETURN>
# chkconfig xend on <RETURN>
# service xend start <RETURN>
```

[Linux]

When the configuration of server components has been changed, check the configuration file of the OS, and make any necessary corrections. For details, refer to "Configuration File Check" in "2.1.1.1 Software Preparation and Checks" in the "Setup Guide CE".

[Red Hat Enterprise Linux 6]

When adding or removing network interfaces, if the target server is running Red Hat Enterprise Linux 6, after completing the steps described in "9.3.2 Replacing the Server", modify the configuration file.

For details, refer to "Configuration File Check" in "2.2.1.1 Software Preparation and Checks" in the "Setup Guide CE".

- Replacing a GSPB

The procedure used to replace a GSPB is the same as that described in "Replacing a network interface". Replace NIC with GSPB in the procedure.

- Replacing an HBA

The procedure used to replace an HBA is the same as that described in "9.3.2 Replacing the Server".

- When using I/O virtualization, the replacement HBA will automatically inherit the WWN originally set on the replaced HBA. Therefore, there is no need to re-configure access paths on the storage side.
- When configuring WWN information, it is necessary to change WWN information settings to the replaced HBA WWN values. Refer to "9.1.12 Changing WWN Settings for ETERNUS SF Storage Cruiser Integration" in the "User's Guide VE" for details on how to change WWN information.

- Replacing a boot disk (in local boot environments)

Use the following procedure to replace a boot disk.

1. Replace the faulty boot disk with a new one.
2. If the boot disk's content was backed up, restore it.

Information

The backup and restore functions available in Resource Orchestrator can be used to restore the boot disk contents. For details, refer to "Chapter 16 Backup and Restore" in the "User's Guide VE".

- **Replacing a system board**

The procedure used to replace a system board is the same as that described in "[9.3.2 Replacing the Server](#)".

- **Replacing an IO board**

No specific action is required in Resource Orchestrator when replacing an IO board.

- **Replacing other server components**

No specific action is required in Resource Orchestrator when replacing onboard server components like memory modules or other parts.

9.3.4 Replacing Non-server Hardware

This section explains how to replace hardware external to servers.

- **Replacing management blades**

No specific action is required in Resource Orchestrator.

- **Replacing management boards**

No specific action is required in Resource Orchestrator.

- **Replacing LAN switches**

No specific action is required in Resource Orchestrator when replacing a LAN switch.

9.4 For Servers not Using Server Management Software

This section explains how to maintain servers not using server management software.

When replacing an entire server, a CPU, or memory, if there are differences in the CPU or memory specifications before and after the replacement, reflect the new CPU and memory specifications of the replaced server in the definition file before reconfiguring hardware information.

- For virtual L-Servers

For details on definition files, refer to "[C.1.4 Configuration when Creating a Virtual L-Server Using a Server which cannot Use ServerView Agents](#)" in the "Setup Guide CE".

- For physical L-Servers

For details on definition files, refer to "[B.1.6 Configuration when Creating a Physical L-Server without Specifying a Model Name in the L-Server Template](#)" in the "Setup Guide CE".

In the following cases, reflect the correct value on the definition file before reconfiguring the hardware information.

- When defining the configuration information (CPU core count, CPU clock speed, memory capacity, etc.) of the target server after registering it with Resource Orchestrator
- When modifying the configuration information (CPU core count, CPU clock speed, memory capacity, etc.) of a server that has been registered with Resource Orchestrator, in the definition file

For details on re-configuring hardware properties, refer to "[9.3.1 Reconfiguration of Hardware Properties](#)".


9.5 Network Device Maintenance

This section explains how to maintain network devices that are the target of management in Resource Orchestrator.

9.5.1 Replacement Procedure of Network Devices

This section explains the procedure to replace network devices when it becomes necessary due to failure.

Figure 9.2 Image of Network Device Replacement



Use the following procedure, when performing replacement while continuing operations using the network devices of redundancy configurations to switch active or standby.

When there is no description, the following operations are performed by an infrastructure administrator.

1. Announcement of planned maintenance operations.
2. Log in the network device directly to check if the target network device of replacement is in active status or standby status.
When the target network device of replacement is in active status, switch over the device with the standby network device of redundancy configuration, and change the status of target network device for replacement from active status to standby status.
3. Change the target network device to the "maintenance mode".
4. Back up the current environment (such as definitions) from the network devices that are switched to "maintenance mode".
5. Replace the network devices. (Hardware maintenance person)
6. Restore the environment backed up in 4. to the network device after replacement.
7. Back up the current definitions from the network devices with operational status.
8. Check that there are no differences in the definitions in the redundancy configurations using environments backed up in 7. and environment definitions backed up in 4.

When there is difference that is a problem, log in to the network device directly after replacement, and resolve the difference.

9. Release the "maintenance mode" of network devices, when problems with network devices after replacement have been solved.
10. Notification that maintenance operations are complete.



See

For details on how to configure and release the maintenance mode, refer to "22.1 Switchover of Maintenance Mode" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".



Note

- Replacement using the same model is a prerequisite when replacing network devices.
- Confirm the following items, using the manuals of network devices, in advance.
 - The replacement procedure when using redundancy configurations
 - The operations for network devices (status switchover, backup methods and restore methods)
 - Environmental differences which become problems when configuring redundancy configurations
- When using the network devices of redundancy configurations, replace network devices in the following order.
 1. Replace network devices with standby status
 2. Set the status of the network device before replacement to standby, and replace the device

When replacing multiple network devices of redundancy configurations simultaneously, perform replacement operations in units of the same redundancy configurations.

- When the network device to replace has failed, step 4. cannot be performed. It is recommended to back up environments regularly in preparation for failures of network devices.

When performing regular backup of environments, the load of restoration operations after replacement of network devices can be reduced, by using the latest backup environment.

9.5.2 Regular Maintenance Procedure of Network Devices

This section explains the procedure of regular maintenance (patch application or firmware update) of network devices.

Use the following procedure when performing maintenance operations while continuing operations using the network devices of redundancy configurations by switching between active and standby.

When there is no description, the following operations are performed by an infrastructure administrator.

1. Announce that regular maintenance operations are being started.
2. Confirm that the network device that is the target of regular maintenance is in standby status, by directly logging in to the network device.
3. Back up the current definitions from the network device with standby status.
4. Change the target network device in standby status to "maintenance mode".
5. A hardware maintenance person performs the regular maintenance operations for network devices (batch application or firmware update).
6. Back up the current definitions from the network devices with operational status.
7. Check that there are no differences between the definitions backed up in 3. and the definitions backed up in 6. When there is difference that is a problem, log in to the network device with standby status, and resolve the difference.
8. Release the network device from "maintenance mode", after checking that problems with network devices with standby status have been solved.
9. Switch over the network device in active status that is the target of regular maintenance and the network device of the redundancy configuration which is in standby status.
10. Then change the status of the remaining network device that is the target of regular maintenance from operational status to standby status, and perform steps 3. to 8.

11. Announce that maintenance operations are complete.



See

.....
For details on how to configure and release the maintenance mode, refer to "22.1 Switchover of Maintenance Mode" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".
.....



Note

-
- Regular maintenance may not be able to be performed using the described procedure depending on the maintenance details for individual network devices. Before performing regular maintenance operations, ensure you check the information provided from the network device vendors regarding the maintenance operations of network devices.
 - Confirm the following items, using the manuals of network devices, in advance.
 - The operations for network devices (status switchover or backup methods)
 - Environmental differences which become problems due to redundancy configurations
 - When performing regular maintenance for multiple network devices of redundancy configurations simultaneously, perform replacement operations in units of the same redundancy configurations.
-

9.5.3 Procedure for Addition of Network Devices

This section explains the operation for adding network devices.


9.5.3.1 Adding L2 Switches to Handle Insufficient Numbers of Ports when Adding Servers

This section explains the procedure for addition, assuming a case where it is necessary to add L2 switches, since the LAN ports of the L2 switch to connect to are insufficient when adding servers.

The explanation is mainly about operations related to L2 switches.

When there is no description, the following operations are performed by an infrastructure administrator.

Figure 9.3 Image of L2 Switches to Add



1. Design additional configurations. (Network device administrator)
 2. Provide the additional network device information to the infrastructure administrator. (Network device administrator)
- Add a network device in the state where the following operations have been completed.

- Initial configuration
- Operation test
- Integration of the device into a physical network configuration

3. Register the resources of the server.

It is necessary to register chassis or LAN switch blades for a blade server.

4. Create network configuration information (XML definition) using the acquired network device information.
5. Register an additional L2 switch as a network device.

Use the `rcxadm netdevice create` command to register as a network device.

6. When the following applies to the additional network device, create and register rulesets.

- When adding an L2 switch of a model for which sample scripts are not prepared, or an L2 switch of a model that has not been used in the system until now.

In this case, it is necessary to create a directory to allocate rulesets to.

- When using a model for which sample scripts are not prepared, or even when using a model which has been used in the system until now, by configuring definitions using the different rules (scripts)
- Even when using a model for which sample scripts are prepared, and when using a model with definitions configured using different rules (scripts)

Note

Details of sample scripts may be reviewed and modified. When using rulesets modified from prepared sample scripts, the modified details will be cleared by replacing the modified scripts with the sample scripts, when updating sample scripts.

In order to prevent this type of problem, when creating scripts by referring to sample scripts, create the new rulesets after copying the rulesets of the sample script, and perform necessary modifications.

7. Change all resources using the additional network devices.

It is necessary to add the information about uplink ports of the added chassis, when adding a blade server.

Use the `rcxadm network modify` command to modify a network resource.

8. Register the added server as a resource in the necessary resource pool.

See

- For details on the initial configurations of network devices, refer to "9.2.3 Settings for Managed Network Devices" in the "Design Guide CE".
- For details on how to create network configuration information (XML definition), refer to "13.6 Network Configuration Information" in the "Reference Guide (Command/XML) CE".
- For details on the `rcxadm netdevice` command, refer to "3.8 `rcxadm netdevice`" in the "Reference Guide (Command/XML) CE".
- For details on ruleset creation and the registration destinations, refer to "Creating a Folder for Registering Rulesets" in "9.4.9 When Automatically Configuring Network Devices" in the "Setup Guide CE".
- For details on the `rcxadm network` command, refer to "3.9 `rcxadm network`" in the "Reference Guide (Command/XML) CE".
- For details on how to register a resource in a resource pool, refer to "Chapter 19 Resource Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".


9.5.3.2 Adding Firewalls and L2 Switches for Additional Tenants

This section explains the procedure for addition, assuming a case where it is necessary to add a network device or a server in order to add a tenant.

The explanation is mainly about operations related to firewalls and L2 switches.

When there is no description, the following operations are performed by an infrastructure administrator.

Figure 9.4 Image of Tenants to Add



1. Design additional configurations. (Network device administrator)
2. Provide the additional network device information to the infrastructure administrator. (Network device administrator)

Add a network device in the state where the following operations have been completed.

- Initial configuration
 - Operation test
 - Integration of the device into a physical network configuration
3. Register the resources of the server.
It is necessary to register chassis or LAN switch blades for a blade server.
 4. Create network configuration information (XML definition) using the acquired network device information.
 5. Register an additional firewall and L2 switch as network devices.
Use the `rxadm netdevice create` command to register as a network device.
 6. When the following applies to the additional network device, create and register rulesets.
 - When adding a firewall or an L2 switch of a model for which sample scripts are not prepared or a firewall or an L2 switch of a model which has not been used in the system until now.
In this case, it is necessary to create a directory to allocate rulesets to.
 - When using a model for which sample scripts are not prepared, or even when using a model which has been used in the system until now, by configuring definitions using the different rules (scripts)
 - Even when using a model for which sample scripts are prepared, and when using a model with definitions configured using different rules (scripts)

Note

Details of sample scripts may be reviewed and modified. When using rulesets modified from prepared sample scripts, the modified details will be cleared by replacing the modified scripts with the sample scripts, when updating sample scripts.

In order to prevent this type of problem, when creating scripts by referring to sample scripts, create the new rulesets after copying the rulesets of the sample script, and perform necessary modifications.

7. Create a tenant and register a tenant administrator.
8. Back up environments using the functions provided by the firewall.
The backup can be used for restoration, when replacing firewall devices due to failure.
For details on how to back up environments, refer to the manual of the firewall.
9. Register an additional server and firewall in a resource pool for tenant as resources.

See

- For details on the initial configurations of network devices, refer to "9.2.3 Settings for Managed Network Devices" in the "Design Guide CE".
- For details on how to create network configuration information (XML definition), refer to "13.6 Network Configuration Information" in the "Reference Guide (Command/XML) CE".
- For details on the rcxadm netdevice command, refer to "3.8 rcxadm netdevice" in the "Reference Guide (Command/XML) CE".
- For details on ruleset creation and the registration destinations, refer to "Creating a Folder for Registering Rulesets" in "9.4.9 When Automatically Configuring Network Devices" in the "Setup Guide CE".
- For details on how to create a tenant, refer to "11.3 Creating Tenants" in the "User's Guide for Infrastructure Administrators CE".
- For details on how to register tenant administrators, refer to "Chapter 3 Operating User Accounts" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".
- For details on how to register a resource in a resource pool, refer to "Chapter 19 Resource Operations" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

9.5.4 Procedure for Addition or Modification of Connection Destinations of Network Devices

This section explains the procedure for adding or modifying destinations for network device connection.

When there is no description, the following operations are performed by an infrastructure administrator.

1. Notify your infrastructure administrator about the addition or modification of the destination for network device connection. (Network device administrator)
2. Create network configuration information (XML definition) using the acquired network device information.
3. Confirm there are no differences besides the link information (under Links tag) regarding the added or modified destinations for connection, by comparing the network configuration information of network devices registered in Resource Orchestrator and the network configuration information created in 2.

If there is any difference, check with the system administrator that network device configurations have not been modified, and change the network configuration information if necessary.

The network configuration information of network devices registered in Resource Orchestrator can be obtained using the rcxadm netconfig export command.

4. Modify the network device by setting the confirmed network configuration information as the input information.
Use the rcxadm netdevice modify command to modify network devices.
5. Confirm from the ROR console that the network device information has changed, and the status is normal.



- For details on how to create network configuration information (XML definition), refer to "13.6 Network Configuration Information" in the "Reference Guide (Command/XML) CE".
- For details on the rxadm netconfig command, refer to "3.7 rxadm netconfig" in the "Reference Guide (Command/XML) CE".
- For details on the rxadm netdevice command, refer to "3.8 rxadm netdevice" in the "Reference Guide (Command/XML) CE".

9.6 Storage Device Maintenance

This section explains how to maintain storage devices.

- Replacing storage devices

No specific action is required in Resource Orchestrator.

In Resource Orchestrator, the settings for storage devices are not restored.

Restore the settings for storage devices based on the information in hardware manuals.

- Replacing Fibre Channel switches

No specific action is required in Resource Orchestrator.

In Resource Orchestrator, the settings for Fibre Channel switches are not restored.

Restore the settings for Fibre Channel switches based on the information in hardware manuals.

9.7 Power Monitoring Device (PDU or UPS) Maintenance

This section explains how to maintain power monitoring devices (PDU or UPS).

- Replacing power monitoring devices (PDU or UPS)

After replacing a power monitoring device, re-configure the power monitoring device's (PDU or UPS) hardware properties.

Use the following procedure to replace a power monitoring device.

1. Replace the faulty power monitoring device.
2. Set the admin LAN IP address and SNMP community on the replacement device to the same values as those that were set on the faulty device.
3. Re-configure the power monitoring device's hardware properties.
 - a. In the ROR console server resource tree, right-click the target power monitoring device (PDU or UPS), and from the popup menu, select [Hardware Maintenance]-[Re-configure].
The [Re-configure Hardware Properties] dialog is displayed.
 - b. Click <OK>.

The target power monitoring device's hardware properties are re-configured.

Chapter 10 Backup and Restoration of Admin Servers

This chapter describes how to operate the backup and restoration of the admin server of ServerView Resource Orchestrator Cloud Edition (referred to as "this product" in this guide).

Backing up the Admin Server

The two methods of backing up the Management Server are shown below.

With either method, backup can be performed by executing one command (the `rcxmgrbackup` command).

For details on the `rcxmgrbackup` command, refer to "6.6 `rcxmgrbackup`" in the "Reference Guide (Command/XML) CE".

- Offline backup

The manager of this product is stopped and then resources are backed up. A backup is taken at the following times:

- When installation of this product has completed

When using an offline backup, backup of the following resource is not performed:

- Audit log

- Online backup

Resources are backed up without the manager of this product being stopped. Backing up periodically is recommended for online backups.

To save time when restoring configuration information at operation, take an online backup if configuration information is to be updated.

When using an online backup, backup of the following resources is not performed:

- Dashboard information
- Operational status information
- Audit log
- Application information
- Definition file
 - Some L-Platform management settings
 - Tenant management and account management settings
 - Operational status server list settings
 - CMDB agent event log output settings

Online backup uses the PostgreSQL Point-In-Time Recovery (PITR) mechanism.

There are two online backup methods, each with a different database collection range, as follows:

- Base backup

Base backup is the backup of the entire database cluster (file group in which database data is recorded). A base backup is taken by executing the `rcxmgrbackup -base` command.

Refer to "[Base backup](#)" in "[10.3 Online Backup of the Admin Server](#)" for details.

- Differential backup

With differential backup, the contents of updates to the database are output to multiple files in 16 MB-sized lots. These files are called Write-Ahead Logging (WAL) files.

Usually, for each 16 MB written, the WAL file being written to is switched, and the WAL file for which writing has completed is saved to the "wal" directory under the backup directory.

Periodically executing the `rcxmgrbackup` command allows the contents of updates to the database that are recorded in saved WAL files to be maintained for a certain period of time. For example, when the `rcxmgrbackup` command is executed every hour, the contents of updates performed in the most recent one-hour period will be saved.

Refer to "[Differential backup](#)" in "[10.3 Online Backup of the Admin Server](#)" for details.

Restoring the Admin Server

Database restoration restores by applying to the base backup the contents of updates to the database in WAL files that have been output after the base backup was taken. The `rcxmgrrestore` command is used for restoration.

Refer to Section "[10.4 Restoring the Admin Server](#)" for details.

10.1 Mechanism of Backup and Restoration

This section describes the mechanism of backup and restoration, including environment requirements, points to note, and the restart position after restoration, in a system in which this product is installed.

Backup and restoration environment requirements

The following conditions must be satisfied in the environments to be backed up and restored:

- The operating systems match.
Note that this does not include operating system version differences.
- The host information (host name or IP address) matches.
- The character code systems match.
- The directory services match.
- The product installation folders match.

Points to note at backup and restoration

This section describes the points to note when backup and restoration is being performed.

- Administrator privileges are required in order to execute the commands.
- If, and only if, resources backed up using online backup are to be restored, execute the command that disables a service application for which an application process no longer exists (`recoverAllService` command).
- Perform backup and restore operations as described below for ServerView Operations Manager, which is mandatory software. Refer to a ServerView Operations Manager manual for details.
 - Backup operations
Perform system backup in accordance with Management Server system backup operations.
When a registration or update of user information has occurred, perform backup again
 - Restoration operations
 - a. Perform restoration of the entire Management Server system.
 - b. Use the restoration procedure described in this document to perform restoration.
- If systems backed up using offline and online backup are to be restored, perform restoration in the following order:
 1. Restoration of systems backed up using offline backup
 2. Restoration of systems backed up using online backup
- When moving backup resources, move the folder specified in the backup destination as well as all folders and files under that folder.
- Do not delete backup resources during execution of the restore command.
- To delete backup resources, delete the folder specified in the backup destination as well as all folders and files under that folder.

- Backup to the following media cannot be performed using the backup command:
 - Backup to optical disks such as CD-R and DVD-R
To back up user resources to optical disks, back up once to local disks, and then write to the media.
 - Backup to folders that include spaces.
- Restoration from the following folders cannot be performed using the restore command:
 - Restoration from folders that include spaces.

Resources managed by this product and timing of update

The resource files managed by Resource Orchestrator are as shown below: When an operation described in the 'timing of update column' has been performed, a backup should be made.

Table 10.1 Resources to be backed up and timing of update

Target Resources	When Backup is Necessary	Necessity of Stopping Managers	Remarks
Certificates	None	Not Required	
Session encryption keys	After password saving (after execution of the rcxlogin -save command)	Not Required	
System images and cloning images	After addition, deletion, and modification of Physical L-Server images	Not Required	Backup of system images and cloning images of virtual L-Servers are performed as a part of virtual machine backup operations. Perform backup operations of virtual machines using the corresponding functions of VM management software.
Configuration definition information	After creation, registration, modification, unregistration, and deletion of L-Servers and resources	Not Required	
Information related to image files	Physical L-Server registration, deletion, movement, usage changes, power operations, conversion, and reversion After the registration and unregistration of VM hosts	Not Required	
Definition files	Modification of definition files	No (Note)	Note) If the following definition files are to be backed up, the Manager must be stopped and offline backup must be performed. - Some L-Platform management settings - Tenant management and account management settings - Operational status server list settings - CMDB agent event log output settings

Target Resources	When Backup is Necessary	Necessity of Stopping Managers	Remarks
Image management information	After rcxadm imagemgr command operations	Not Required	
Metering information	Creation, change, deletion, move, or power operation of an L-Platform or L-Server	Not Required	
Home window announcement information	Announcement change	Yes	
License agreement when users are added	License agreement change	Yes	
Dashboard information	As required	Yes	Because it is updated as needed, stop the Manager and take a backup as required.
Operational status information	As required	Yes	Because it is updated as needed, stop the Manager and take a backup as required.
Application information	Application to use, modify, or cancel an L-Platform, or approval, assessment, dismissal, or cancellation of application	Yes	
Terms of use or terms of cancellation of L-Platform	Change to terms of use or terms of cancellation	Yes	

Disk space necessary for the backup

Disk space necessary for the backup is as follows.

Table 10.2 Resource to be backed up and disk space necessary for the backup

Target Resources	Disk space necessary for the backup
Configuration definition information	The file size of backup files varies depending on the number of resources defined in the configuration definition information. When the number of VM guests is 1000VM, collection information temporarily becomes about 150MB. It becomes less than 2MB by compressing it. Please prepare the backup area referring to this size.
System image or cloning image	Every time, when backing up, it is necessary. Therefore, when the backup is executed three times for instance, the capacity of image save area is three times necessary. Refer to "2.4.2.5 Dynamic Disk Space" in the "Design Guide CE" for the capacity of the image storage area.
Certificates Session cryptography key Definition files Image management information Home window announcement information License agreement when users are added Terms of use or terms of cancellation of L-Platform	The size of the file backed up changes according to the number of files backed up. Please prepare the backup area referring to this size to need only the area of less than 1MB even if these 100 files are stored by 10KB or less any file.
Metering information	[Offline backup]

Target Resources	Disk space necessary for the backup
	The size increases and decreases to the file backed up in proportion to the increase and decrease at the number of resources of metering objects and the retention period of the metering log. (*1) [Online backup] 1KB(*1)
Dashboard information	The size increases and decreases to the file backed up in proportion to the increase and decrease of the number of L-Server templates and the number of tenants. Please prepare the backup area referring to the following formulas when the dicker is defined in the L-Server template. When the number of tenants is 100, about 6.6GB is necessary. disk space = (67.0 + (55.5 number of * tenants)) * 1.2 (MB)
Usage condition information	20MB
Application information	The size increases and decreases to the file backed up according to the operating environment. Please calculate the total of the amount of disk under the control of the following directories, and prepare the backup area of the amount. [Windows Manager] - C:\SWRBADB - <i>Installation_folder</i> \SWRBAM - <i>Installation_folder</i> \SWOMGR [Linux Manager] - /etc/opt/FJSVswrbam - /var/opt/FJSVswrbam - /var/opt/FJSVJMCMN/etc - /var/opt/FJSVjmcald - /var/opt/FJSVJOBSC - /var/opt/FJSVfwseo/config/JM - /opt/FJSVJOBSC/bin - /etc/mjes - /var/spool/mjes

*1: The backup of metering information is gathered under the control of the directory specified by the rcxmgrbackup command at an off-line backup, and it is gathered in the area besides the specified directory at an online backup.

Please calculate a necessary amount of disk by backing up metering information referring to the following examples.

"Amount of disk necessary for the base backup" is necessary for an off-line backup.

It is necessary to total "Amount of disk necessary for the base backup" and "Amount of disk necessary for Difference backup" for an online backup.

In the following conditions, the amount of disk of about 12.6GB is necessary for about 1.3GB and online backups for an off-line backup.

Table 10.3 Condition necessary for backup of metering information

Item		Estimated Value
Number of operating L-Platforms		1000
Number of resources per L-Platform	L-Server	1

Item		Estimated Value
	Expansion disk	1
	Software	2
Usage status	<ul style="list-style-type: none"> - The following operations are executed every day <ul style="list-style-type: none"> - Return and deployment of 10 L-Platforms - Starting of 1,000 L-Servers when starting operations - Stopping of 1,000 L-Servers when finishing operations - A regular log is acquired every day - Keep metering logs for one year 	
Online backup frequency	<ul style="list-style-type: none"> - Execute monthly base backup (every 30 days) - Execute hourly difference backup. 	

Table 10.4 Formula for Metering Logs per Day

<ul style="list-style-type: none"> - Target capacity for metering logs <ul style="list-style-type: none"> - Event Logs for an L-Platform : 2.3 KB/each time (A) - Event Logs for other than an L-Platform : 0.6 KB/each time (B) - Regular logs : 2.3 * number of L-Platforms (KB) (C) - Metering logs per day <ul style="list-style-type: none"> (A) * operation number for L-Platforms per day + (B) * operation number for other than L-Platforms per day + (C) * number of operating L-Platforms <p>= 2.3 KB * 20 + 0.6 KB * 2000 + 2.3 KB * 1000 = 3.5MB</p>

Table 10.5 Disk space formula necessary for base backup

<p>Log of the metering each day * For one year</p> <p>3.5 MB * 365 = 1.3 GB</p>

Table 10.6 Disk space formula necessary for Difference backup

<p>disk space per WAL file : 16MB</p> <p>WAL file space frequency until acquiring base backup (30 days): 24 * 30</p> <p>16MB * 24 * 30 = 11.3GB</p>

Table 10.7 Disk space formula necessary for operation of online backup

<p>Disk space formula necessary for operation of online backup</p> <p>= Disk space formula necessary for base backup + Disk space formula necessary for Difference backup</p> <p>= 1.3GB + 11.3GB</p> <p>= 12.6GB</p>

Storage destination for backing up resources

This section describes the storage destination for backing up Admin Server resources.

Use the rcxmgrbackup command to specify a storage destination folder, except in the case of metering information.

The folders described in the following table are automatically created in the storage destination folder in order to store the resources. When restoration is to be performed, restoration occurs from the information in the latest folder of each folder. Therefore, even if a folder is deleted due to the disk capacity status, this will not cause a problem because the information in the latest folder will remain.

When the rcxmgrbackup command is used with the -cleanup option specified, all information older than the latest information collected by the command will be deleted.

Table 10.8 Relationship between backup method and data collected

Folder	Offline backup	Online backup (base backup)	Online backup (differential backup)
CTMG_OFFyyyymmddhhmmss	Yes	No	No
CTMG_BASEyyyymmddhhmmss	No	Yes	No
CTMGyyyymmddhhmmss	No	No	Yes
CFMGyyyymmddhhmmss	Yes	Yes	Yes
RORyyyymmddhhmmss	Yes	Yes	Yes
RBAyyyymmddhhmmss	Yes	No	No
RORSCW	Yes	Yes	Yes

"yyyymmddhhmmss" is the date and time the command was executed.

 **Note**

Backup files of the admin server should be stored on external storage media to prevent the backup data from being corrupted due to server failure.

Refer to "[10.5 Online Backup Settings for Metering](#)" for information on the storage destination for metering.

Standard at backup and restore processing time

Estimate the time that hangs to the backup restoration of the administrative server referring to the following command processing time.

The command processing time must be different according to customer's environment, and gather by the operational testing etc. in customer's environment, and decide the operation estimate time according to the value.


 **Example**

- Environment
 - CPU : 4CPU
 - Memory Size : 16GB
- Command processing time
 - offline backup : 3 minutes
 - online backup (base backup) : 2 minutes
 - online backup (differential backup) : 2 minutes
 - restore : 4 minutes

System restart point after restoration

In the system operations flow used by this product, the restart point of the system will vary according to the timing of the backup of resources. Therefore, to ensure that the system can restart from the status it had before backup, operate the system in accordance with whether offline backup or online backup is used for backup, and perform restoration processing in accordance with each backup type.

Figure 10.1 Schedule for Backup and Restoration of Admin Servers (Example)



The flow of the preceding diagram is as follows:

1. A problem occurs in the system (Example: Occurs at 12:35 on August 1, 2011)
2. In order to restore the system, restoration is performed on the environment backed up offline and the environment backed up online. (Example: Restores at 14:00 on August 1, 2011)
Refer to "[Points to note at backup and restoration](#)" for information on the restoration order.
3. The latest differential backup files are dated (12:00 on August 1, 2011), so the restart point will be from that date and time.

10.2 Offline Backup of the Admin Server

Before performing backup, the systems of this product must be stopped.

1. Stop the manager
2. Back up the Resources of this Product
3. Start the manager

10.2.1 Stopping the Manager

Stop the Manager and check that it is in a stopped state.

Stopping the Manager

Execute the command shown below to stop the Manager.

For details on the command, refer to "5.18 rcxmgrctl" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrctl stop <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxmgrctl stop <RETURN>
```

Checking the status of the services of this product

Check that the Manager and services of this product are stopped.

For details on how to check, refer to ["2.1 Starting and Stopping the Manager"](#).

10.2.2 Back up the Resources of this Product

Back up the resources of this product. Execute the command shown below.

For details on the command, refer to "6.6 rcxmgrbackup" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrbackup -dir directory [-cleanup] <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxmgrbackup -dir directory [-cleanup] <RETURN>
```

10.2.3 Starting the Manager

Execute the command shown below to start the Manager.

For details on the command, refer to "5.18 rcxmgrctl" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
> Installation_folder\SVROR\Manager\bin\rcxmgrctl start <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxmgrctl start <RETURN>
```

Saving image management information

Check the following image management information, the number of stored snapshot generations and the image file storage folder:

- Number of stored snapshot generations
- Image file storage folder

Execute the following command to set the number of stored snapshot generations and the image storage folder information to a standard output, by redirecting the information to a file, and then saving it.

[Windows Manager]

```
> Installation_folder\SVROR\Manager\bin\rcxadm imagemgr info > file <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxadm imagemgr info > file <RETURN>
```

Parameter

file

Specify the name of the file for output.

For details on the rcxadm imagemgr command, refer to "5.9 rcxadm imagemgr" in the "Reference Guide (Command/XML) CE".

10.3 Online Backup of the Admin Server

This section describes online backup of the admin server.

When using online backup of the admin server, the PostgreSQL Point-In-Time Recovery (PITR) mechanism is used in the backup of the metering database.

When using PITR backup and restoration, the following two resource types are backed up and restored:

- Base backup

The entire database cluster (file group in which database data is recorded) is backed up.

- WAL file

Write-Ahead Log (WAL) files are files in which the contents of updates to the database are recorded.

Backup of the two preceding resource types is taken when the commands for the two corresponding backup methods (base backup and differential backup) are executed.

Resources that are backed up and restored using PITR are stored in the directory that has been specified in the settings file, regardless of the storage destination specified when the command was executed. Refer to "10.5 Online Backup Settings for Metering" for information on how to set this.

Each of the backup methods for performing online backup of the admin server is described below.

Base backup

Base backup is the backup of the entire database cluster (file group in which database data is recorded).

Execute the command shown below.

For details on the command, refer to "6.6 rcxmgrbackup" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrbackup -dir directory -base [-cleanup] <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvvr/bin/rcxmgrbackup -dir directory -base [-cleanup] <RETURN>
```



The backup command may not end normally at times, so do not perform the following operations:

- Forced end using Ctrl+C during execution of the backup command
- Stopping the Manager during execution of the backup command

If the operations listed above have been performed, the following action will be required, depending on the status:

Execute the command shown below the next time and any subsequent times the base backup does not end normally.

When this command is executed, base backup will end normally.

Refer to Section "12.10 ctmg_resetbackuperror (Recover Base Backup Error)" of the "Reference Guide (Command/XML) CE" for information on the command.

```
<Installation_folder>\RCXCTMG\bin\ctmg_resetbackuperror.bat
```

The processing result is output as standard output.
 The contents and meaning of the processing result are shown in the table below.

Processing Result	Return Value	Message
Normal end	0	Successfully reset the base-backup error.
Error	Other than 0	Failed to reset the base-backup error.

- If starting of the Manager fails

When operations continue after a while without the command mentioned above (ctmg_resetbackuperror) being executed, and then the Manager is stopped, subsequent starts of the Manager may fail. If this happens, an error message will be output to the database log files, as follows:

- Database log files

```
Installation_folder\RCXCTMG\Charging\log\psql-nn.log (*1)
```

*1) The "nn" part is a 2-digit numeral indicating the day on which the log was output.

- Error message

Example: If the access control database failed to start

```
LOG: could not open file "pg_xlog/xxxxxxx" (log file 0, segment xx): No such file or directory (*2)
LOG: invalid checkpoint record
PANIC: could not locate required checkpoint record
HINT: If you are not restoring from a backup, try removing the file "C:/Fujitsu/ROR/RCXCTMG/Charging/pgsql/data/backup_label".
```

*2) The "xxxxxxx" and "xx" parts of the log are undefined.

In a case like this, delete the file shown below. When this file is deleted, start of the Manager will end normally. When this file is deleted, start of the Manager will end normally.

```
Installation_folder\RCXCTMG\Charging\pgsql\data\backup_label
```

Differential backup

With differential backup, the contents of updates to the database are output to multiple files in 16 MB-sized lots.

These files are called Write-Ahead Logging (WAL) files.

Usually, for each 16 MB written, the WAL file being written to is switched, and the WAL file for which writing has completed is saved to the "wal" directory under the backup directory.

Execute the rcxmgrbackup command.

Periodically executing the rcxmgrbackup command allows the contents of updates to the database that are recorded in saved WAL files to be maintained for a certain period of time. For example, when the rcxmgrbackup command is executed every hour, the contents of updates performed in the most recent one-hour period will be saved.

For details on the command, refer to "6.6 rcxmgrbackup" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrbackup -dir directory [-cleanup] <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxmgrbackup -dir directory [-cleanup] <RETURN>
```

10.3.1 Items to be Determined Before Periodic Execution

The following items must be determined before periodic execution is implemented.

Items	What to Decide
Frequency and timing of base backup	Determine the frequency of base backup. Example: 3:00 a.m. on the 1st of every month
Frequency and timing of differential backup	Determine the frequency of differential backup. Example: Once per hour
Location of backup	Determine the location of the backup. Setting a disk other than the disk that installed the product is recommended. In addition, sufficient capacity is required to be able to store the backup file.

Refer to "10.5 Online Backup Settings for Metering" for information on how to set the backup destination.

10.3.2 Settings for Periodic Execution of Backup

The following two settings are required in order to perform periodic execution of backup:

- Settings for periodic execution of base backup
- Setting for periodic execution of WAL file save



- If this procedure has been used to start batch files using the Task Scheduler, a command prompt is displayed while the batch files are being executed. Do not close this command prompt.
- When an error occurs at periodic execution of online backup, a message with the error code 67198 will be output to the log files. If the occurrence of errors is being monitored, use software for monitoring the log files to monitor this error message. For details on the error message, refer to "Message number 67198" in "Messages".

Settings for periodic execution of base backup

Specify settings so that a base backup is taken periodically.

Use Windows Task Scheduler as a mechanism for periodically executing commands. Refer to Windows Help for information on how to set the Task Scheduler.

This section describes an example of a setup procedure for implementing a backup at 3:00 a.m. on the 1st of every month.

1. From the Windows [Start] menu, select [Administrative Tools]-[Task Scheduler] to start the Task Scheduler.
2. To manage tasks hierarchically, use the following procedure to create a folder:
 - a. In the Task Scheduler menu, after selecting Task Scheduler Library, select [Actions]-[New Folder], and then enter any folder name in the dialog box that is displayed and click the <OK> button.
 - b. Selecting the created folder and then creating another folder by selecting [Actions]-[New Folder] from the Task Scheduler menu allows a further hierarchical level to be added.



Creating a folder in Task Manager allows tasks to be managed hierarchically. In cases such as where multiple tasks are to be registered, creating a folder allows task management to be performed efficiently.

3. From the Task Scheduler menu, select Actions >> Create Basic Task to display the Create Basic Task Wizard.

Point

When a subsequent operation is performed after any folder is selected, the task will be registered under that folder. If a folder is not selected, the task will be registered in the Task Scheduler Library.

4. In the [Name] field, enter a task name (for example, "Monthly backup") and click the <Next> button.
5. Select Monthly as the task trigger and click the Next button.
6. In the Start field, set the date and time at which periodic backup is to start.
Example: Set a date of the "1st" of the following month and "3:00:00".
7. In the Months field, select the Select all months checkbox.
8. In the Days field, Select the 1 checkbox.
9. Click the Next button.
10. Select Start a program as the task action and click the Next button.
11. Click the Browse button and in the Program/script field, set the batch files for base backup.

Example

C:\work\backupall.bat

```
@echo off
echo "Resource Manager Cloud Edition Resources backup Start"
call "{Installation_folder}\SVROR\Manager\bin\rcxmgrbackup" -directory {storage destination
folder} -base
echo "Resource Manager Cloud Edition Resources backup End"
```

- For details on the rcxmgrbackup command, refer to "6.6 rcxmgrbackup" in the "Reference Guide (Command/XML) CE".

12. In the Add arguments (optional) field, set a character string to be used for outputting the command output to log files.
Example: >>F:\backup\backupall.log 2>&1
13. Click the Next button.
14. Check the task settings, and if they are correct, click the <Finish> button.

Settings for periodic execution of differential backup

Specify settings so that a differential backup is taken periodically.

This section describes an example of a setup procedure for saving a differential backup every hour.

Point

When using the Create Basic Task Wizard, execution for a time interval shorter than one day cannot be set, so once the task has been registered for a different frequency, change the properties.

1. From the Windows [Start] menu, select [Administrative Tools]-[Task Scheduler] to start the Task Scheduler.
2. To manage tasks hierarchically, use the following procedure to create a folder:
 - a. From the Task Scheduler menu, after selecting Task Scheduler Library, select [Actions]-[New Folder], and then enter a folder name in the dialog box that is displayed and click the <OK> button.

- b. Selecting the created folder and then creating another folder by selecting [Actions]-[New Folder] from the Task Scheduler menu allows a further hierarchical level to be added.

Point

.....

Creating a folder in Task Manager allows tasks to be managed hierarchically. In cases such as where multiple tasks are to be registered, creating a folder allows task management to be performed efficiently.

.....

3. From the Task Scheduler menu, select [Actions]-[Create Basic Task] to display the Create Basic Task Wizard.

Point

.....

When a subsequent operation is performed after any folder is selected, the task will be registered under that folder. If a folder is not selected, the task will be registered in the Task Scheduler Library.

.....

4. In the [Name] field, enter a task name (for example, "Periodic WAL switching") and click the Next button.
5. Select Daily as the task trigger and click the Next button.
6. In the Start field, set the date and time at which online backup (WAL) is to start.
Example: Set the date of the following day and "0:00:00".
7. In the [Recur every] field, set 1 day (set by default).
8. Click the Next button.
9. Select Start a program as the task action and click the Next button.
10. Click the <Browse> button and in the [Program/script] field, set the batch files for online backup (WAL).

Example

.....

C:\work\hourlybackup.bat

```
@echo off
echo "Resource Manager Cloud Edition Resources backup Start"
call "%Installation_folder%\SVROR\Manager\bin\rcxmgrbackup" -dir {storage destination folder}
echo "Resource Manager Cloud Edition Resources backup End"
```

- For details on the rcxmgrbackup command, refer to "6.6 rcxmgrbackup" in the "Reference Guide (Command/XML) CE".

.....

11. In the Add arguments (optional) field, set a character string to be used for outputting the command output to log files.
Example: >>F:\backup\backupall.log 2>&1
12. Click the Next button.
13. Check the task settings, and if they are correct, click the <Finish> button.
14. Select the registered task from the task list, and select [Action]-[Properties] to open the Properties dialog.
15. Open the Triggers tab, select the existing trigger, and click the Edit button.
16. Check the [task every:] checkbox in [Advanced settings], and select "1 hour" (set by default).
17. For the [for a duration of], select "1 day" (set by default).
18. Click the OK button.

10.4 Restoring the Admin Server

This chapter describes how to restore resources that have been backed up.

1. Stop the manager
2. Restore the resources of the Manager
3. Start the manager
4. Update the configuration information in the operational status information

10.4.1 Stop the manager

Execute the command shown below to stop the Manager.

For details on the command, refer to "5.18 rcxmgrctl" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrctl stop <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvvr/bin/rcxmgrctl stop <RETURN>
```

10.4.2 Restoring the Resources of This Product

Restore the resources of this product. Execute the command shown below.

For details on the command, refer to "6.17 rcxmgrrestore" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrrestore -dir directory <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvvr/bin/rcxmgrrestore -dir directory <RETURN>
```

Restore image management information

If the following image management information that was saved at backup has been changed, reset it:

- Number of stored snapshot generations

[Windows Manager]

In *value*, specify the number of stored generations that were saved at backup.

```
>Installation_folder\SVROR\Manager\bin\rcxadm imagemgr set -attr vm.snapshot.maxversion=value  
<RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvvr/bin/rcxadm imagemgr set -attr vm.snapshot.maxversion=value <RETURN>
```

For details on the rcxadm imagemgr command, refer to "5.9 rcxadm imagemgr" in the "Reference Guide (Command/XML) CE".

10.4.3 Starting the Manager

Execute the command shown below to start the Manager.

For details on the command, refer to "5.18 rcxmgrctl" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrctl start <RETURN>
```

[Linux Manager]

```
# /opt/FJSVrcvnr/bin/rcxmgrctl start <RETURN>
```

10.4.4 Disabling L-Platform Applications

Disable an L-Platform application for which an application process no longer exists, if online backup of the admin server has been performed.

For details on the command, refer to "12.11 recoverAllService (Disable L-Platform Application)" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\RCXCTMG\MyPortal\bin\recoverAllService.bat <RETURN>
```

[Linux Manager]

```
# /opt/FJSVctmyp/bin/recoverAllService.sh <RETURN>
```

10.4.5 Update the configuration information in the operational status information

Execute the following command to update the configuration for the operational status information:

For details on the command, refer to "12.8 cmdbrefresh (Refresh Configuration Information of System Condition)" in the "Reference Guide (Command/XML) CE".

[Windows Manager]

```
>Installation_folder\SWRBAM\CMDB\FJSVcmdbm\bin\cmdbrefresh.exe -a -q <RETURN>
```

[Linux Manager]

```
# /opt/FJSVctmyp/bin/cmdbrefresh.sh -a -q <RETURN>
```

10.5 Online Backup Settings for Metering

Backup resources that use the PostgreSQL point-in-time recovery (PITR) mechanism (metering resources), which are among the resources that are obtained in online backup of the admin server, are stored in the directory that has been specified in the settings file, regardless of the storage destination specified by the command.

This section describes how to change the backup destination directory for the online backup of metering resources.

To change the backup destination directory, the files and items in the table shown below must be changed.

File to be Changed	File Name	Item to be Changed
Operational settings file for the database	postgresql.conf	WAL save directory
Operational settings file for online backup	ctmgbackup.properties	WAL save directory
		Backup directory

Stopping the Manager

Stop the manager.

For details on how to stop the manager, refer to "2.1 Starting and Stopping the Manager".

Changing the backup destination directory [Windows]

This section describes how to change the backup destination directory, based on the example shown below.

[Windows Manager]

Directory	Type	Directory Path
Backup directory	Before change	C:\Fujitsu\ROR\RCXCTMG\backup\data
	After change	D:\basebackup
WAL save directory	Before change	C:\Fujitsu\ROR\RCXCTMG\backup\wal
	After change	E:\walbackup

[Linux Manager]

Directory	Type	Directory Path
Backup directory	Before change	/var/opt/FJSVctchg/backup/data
	After change	/basebackup
WAL save directory	Before change	/var/opt/FJSVctchg/backup/wal
	After change	/walbackup

1. Create a new backup directory.

[Windows Manager]

```
> D: <RETURN>
> cd \ <RETURN>
> mkdir basebackup\Charging <RETURN>
> E: <RETURN>
> cd \ <RETURN>
> mkdir walbackup\Charging <RETURN>
```

[Linux Manager]

```
# mkdir /basebackup <RETURN>
# mkdir /walbackup <RETURN>
```

2. Set access privileges for users connected with the database, for the directory.

[Windows Manager]

```
>caccls D:\basebackup\Charging /T /E /G rcxctdbchg:F <RETURN>
>caccls E:\walbackup\Charging /T /E /G rcxctdbchg:F <RETURN>
```

[Linux Manager]

```
# chown -R rcxctdbdhg:rcxctdbchg /basebackup <RETURN>
# chown -R rcxctdbdhg:rcxctdbchg /walbackup <RETURN>
```

3. Copy (move) files from the existing directory to the new directory.

[Windows Manager]

```
>xcopy c:\Fujitsu\ROR\RCXCTMG\backup\data\* D:\basebackup\ /E /H /K /X <RETURN>
>xcopy c:\Fujitsu\ROR\RCXCTMG\backup\wal\* E:\walbackup\ /E /H /K /X <RETURN>
```

[Linux Manager]

```
# cp -pR /var/opt/FJSVctchg/backup/data/* /basebackup/. <RETURN>
# cp -pR /var/opt/FJSVctchg/backup/wal/* /walbackup/. <RETURN>
```

4. Modify the operational settings file for the database.

Change the settings for the following operational settings file for each database cluster:

[Windows Manager]

```
Installation_folder\RCXCTMG\Charging\pgsql\data\postgresql.conf
```

Change as follows:

- Setting before change

```
archive_command = 'copy "%p" "C:\\Fujitsu\\ROR\\RCXCTMG\\backup\\wal\\Charging\\%f"' #
command to use to archive a logfile segment
```

- Setting after change

```
archive_command = 'copy "%p" "E:\\walbackup\\Charging\\%f"' # command to use to archive a
logfile segment
```



Use "\\" as a delimiter.

[Linux Manager]

```
/var/opt/FJSVctchg/pgsql/data/postgresql.conf
```

- Setting before change

```
archive_command = 'cp "%p" "/var/opt/FJSVctchg/backup/wal/%f"' # command to use to archive a
logfile segment
```

- Setting after change

```
archive_command = 'copy "%p" "E:\\walbackup\\Charging\\%f"' # command to use to archive a
logfile segment
```



Use "/" as a delimiter.

5. Modify the operational settings file for the online backup.

Open the following file:

[Windows Manager]

```
Installation_folder\RCXCTMG\bin\conf\ctmgbackup.properties
```

Change as follows:

- Setting before change

```
BASE_BACKUP_DIR=C:/Fujitsu/ROR/RCXCTMG/backup/data
WAL_ARCHIVE_DIR=C:/Fujitsu/ROR/RCXCTMG//backup/wal
```

- Setting after change

```
BASE_BACKUP_DIR=D:/basebackup  
WAL_ARCHIVE_DIR=E:/walbackup
```



Use "/" as a delimiter.

[Linux Manager]

```
/opt/FJsvctmg/bin/conf/ctmgbackup.properties
```

Change as follows:

- Setting before change

```
BASE_BACKUP_DIR=/var/opt/FJsvctchg/backup/data  
WAL_ARCHIVE_DIR=/var/opt/FJsvctchg/backup/wal
```

- Setting after change

```
BASE_BACKUP_DIR=/basebackup  
WAL_ARCHIVE_DIR=/walbackup
```



Use "/" as a delimiter.

Start the manager

Start the manager.

For details on how to start the manager, refer to "[2.1 Starting and Stopping the Manager](#)".

Part 4 Monitoring

Chapter 11 Monitoring Resources.....	82
Chapter 12 Collecting Power Consumption Data and Displaying Graphs.....	93
Chapter 13 Monitoring Resource Pools (Dashboard).....	95
Chapter 14 Monitoring L-Platforms.....	96
Chapter 15 Accounting.....	97
Chapter 16 Monitoring Logs.....	119

Chapter 11 Monitoring Resources

This chapter explains how to monitor the configuration and status of managed resources.

11.1 Overview

Resource Orchestrator can centrally monitor the configuration and status of servers or other managed resources directly from the ROR console. This enables the identification of resources experiencing problems, which reduces the time spent on system maintenance. Moreover, Resource Orchestrator can easily launch external management software to precisely locate faulty parts within a managed resource.

Monitoring is based on the following three components:

- Resources

The tree displays chassis, servers, LAN switches, physical OS's, VM hosts, VM guests, and power monitoring device relationships and statuses (either PDU or UPS for management software).

When a hardware problem occurs on a server, affected guest operating systems can be easily detected.



Power monitoring devices are not subject to monitoring.

- Events

Resource Orchestrator displays events such as hardware failures, server switchovers triggered by hardware failures, and the results of every performed operation.

- Recent Operations

Resource Orchestrator displays the progress status of the various operations performed on resources.

The following table shows the level of monitoring performed for each resource monitored in Resource Orchestrator.

Table 11.1 Monitoring Level for Each Resource Type

Resource	Status monitoring	Event monitoring
Chassis	Yes	Yes
Server	Yes	Yes
Physical OS	Yes	No
VM Hosts	Yes	No
VM Guest	Yes	No
VM management software	Yes	No
LAN switch	Yes	Yes
Power monitoring device	No	No

Yes: Supported

No: Not supported

Regular update of resource data

The Resource Orchestrator manager regularly updates resource data with information gathered from the following resources.

Table 11.2 List of Regularly Updated Resources and Their Related Resources

Resources subject to regular update	Related resources	Data source
Chassis	Chassis	Server Management Unit

Resources subject to regular update	Related resources	Data source
Server	Server Physical OS VM host (*1) VM guest (*1)	ServerView Agents (*2) Server Management Unit Server Virtualization Software
LAN switch	LAN switch	LAN switch Server Management Unit (*3)
VM management software	VM management software VM host (*1) VM guest (*1)	VM management software

*1: When no VM management software is registered, the status of VM hosts and VM guests is updated during a regular update of their physical server. When VM management software is registered, their status is updated during the regular update of the VM management software.

*2: Only for PRIMERGY servers and PRIMEQUEST.

*3: Only for LAN switch blades mounted in a PRIMERGY BX chassis.

The time required to update all resources depends on the number of registered resources. For 1 chassis that contains 10 servers and 4 LAN switches, the update takes about 2 minutes. For 5 chassis that have identical configurations, the update should take about 10 minutes.

VM management software updates are independent from other resource updates, and takes approximately 3 minutes.

In the following cases, resource data is refreshed without waiting for the regular update.

- When a resource's state is changed as the result of an operation performed by Resource Orchestrator
- When a failure-triggered SNMP Trap is received from a resource

If a resource was operated externally to Resource Orchestrator, there may be a slight delay before its state is updated in the ROR console. To force an update of a resource's data, right-click the resource and select [Update] from the displayed menu. The time required to update resource data depends on the device. Generally, update should take no more than 40 seconds.

In order to restrain device and network load, resource data is not refreshed for 7 seconds following the last update time. However, when a failure-triggered SNMP Trap is received, resource data is refreshed unconditionally. When manually updating a resource from the menu right after performing an operation on that resource, if its data is not refreshed within 40 seconds, try updating it from the menu again.

11.2 Resource Status

Resources are monitored in the [Status] tab of the ROR console.

The [Status] tab shows the number of servers listed under the statuses "warning", "unknown", "error", or "fatal".

Servers whose status is "warning" or "unknown" are counted under "Warning", and servers whose status is "fatal" or "error" are counted under "Error".

Clicking on "Error" or "Warning", displays the resources under the corresponding status in the [Resource List] tab.



The status of resources can also be monitored from both the resource tree and the [Resource List] tab. When an error occurs, a status icon is added to the icon of the resource concerned.










Double-clicking on a resource icon displays the [Resource Details] tab, which provides detailed information about the corresponding resource.

Icons displayed in the ROR console

The following table shows the resource icons used in BladeViewer and their associated meanings.

Table 11.3 Resource Icons




Icon	Meaning
	Server resource
	Chassis

Icon	Meaning
	Server
	Physical OS
	VM host
	VM guest
	LAN switch
	Power monitoring device (*1)
	PDU (*1)
	UPS (*1)
	Management software

*1: Power monitoring devices (PDU or UPS) are not subject to monitoring.

The following table shows the status icons used in Resource Orchestrator and their associated meanings. It also shows which status icons require corrective actions.

Table 11.4 Status Icons

Icon	Status	Meaning	Corrective action
	normal	Normal	No action is necessary
	warning	Warning An error has occurred but the resource can still be used.(*1)	Action must be taken
	unknown	Unknown The status of the resource cannot be obtained. (*2, *3)	Action must be taken
	stop	Stop The resource has stopped and cannot be used.	No action is necessary
	error	Error An error whose cause is unknown has occurred and the resource cannot be used.	Action must be taken
	fatal	Fault A fault has occurred in the resource and the resource cannot be used.	Action must be taken

*1: When a LAN switch is in "warning" status, it may mean that the LAN switch has been replaced with another model.

To use the LAN switch as it is, first delete the registered LAN switch, and then register it again.

*2: When a VM guest is in "unknown" status, check the operation status of the VM host on which the VM guest is running.

*3: When a LAN switch is in "unknown" status, check the physical connection between the LAN switch and admin LAN as well as whether or not the LAN switch is responding to commands.

Note

- On the SPARC Enterprise T series, as statuses cannot be obtained from ILOM using SNMP, only "normal", "stop" or "unknown" statuses are shown, while "warning", "error", and "fatal" statuses cannot be detected. If an SNMP Trap indicating an error is displayed, check the status of the server on ILOM.
- For other servers, hardware statuses cannot be obtained from server management software (ServerView). Therefore, only "normal", "stop" or "unknown" statuses are shown, while "warning", "error", and "fatal" statuses cannot be detected.

- For PRIMEQUEST, all partitions within the same chassis may temporarily become "unknown" depending on the timing of change in power control status of the partition.

Table 11.5 Physical Server Icons












Icon	Meaning
	Spare server
	Maintenance mode server

Table 11.6 OS Icons

Icon	Meaning
	Windows OS
	Linux OS
	Solaris OS
	VMware host OS
	Hyper-V host OS
	Citrix XenServer host OS
	Linux Xen host OS
	KVM host OS
	Solaris Container host OS

Information

- For server virtualization software, the following information is also displayed.
 - VM management software

VM management software statuses can be one of the following: "normal" or "unknown".
If "unknown" is shown, check whether the VM management software is operating properly.
 - VM host

The status of a VM host is displayed in the same way as for a physical OS.
 - VM guest

Errors detected from server virtualization software are reflected in VM guest statuses.
VM guest statuses can be one of the following: "normal", "warning", "error", "unknown", or "stop".
For details, refer to "D.3 Functional Differences between Products" in the "Design Guide VE".
- For LAN switches, "error" and "fatal" are not displayed.
Only "warning", "normal", or "unknown" are displayed.

11.3 Addressing Resource Failures

This section explains how to address problems like hardware failures that occur in a system.

Basic Procedure

The following procedure is used to confirm and resolve problems using the ROR console:

1. Confirm the existence of a problem

For the confirmation method, refer to "[11.2 Resource Status](#)" and "A.3 Status Panel" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

2. Check the event log

Use the event log to check the device where the error occurred and the content of the event.

In some cases, a single problem can cause a series of events, so search back through past events to find events with dates that are close together.

3. Check the status of resources

From the resource tree, open the resource where the problem occurred and look for any affected chassis, physical servers, LAN switches, physical OS's, VM hosts, or VM guests.

If Auto-Recovery has been enabled for a physical OS or VM host, it will be automatically switched over with a spare server. If Auto-Recovery has not been enabled, server switchover can still be performed manually as long as a spare server has been designated.

For server switchover, refer to "4.2 Switchover" in the "Operation Guide VE".

4. Perform detailed investigation and recovery

From the [Resource Details] tab of the failed resource, launch the external management software to investigate the precise cause of the problem.

When no management software is available, confirm with the maintenance staff of the failed resource to investigate the problem.

Once this is done, perform the necessary maintenance work on any faulty hardware identified.

If a server hardware failure requires replacing a managed server, carry out the replacement operation as described in "[9.3.2 Replacing the Server](#)".

5. Perform post-recovery verification

Following recovery, confirm that there are no more icons indicating problems on the ROR console.

11.4 Monitoring Networks

An infrastructure administrator recognizes an error of a network device in one of following cases.

- Report of an error from a tenant administrator or tenant user
- Detection of errors when confirming system status using the ROR console
 - The event logs to show the errors of network devices are output.
If a port status change on a registered network device is detected, the message number 42781 will be output.
If the port status is "down" or "unknown" and that change was not caused by the infrastructure administrator, it indicates a problem with the network device. Check the network device.
 - Status icons of resources on the network device tree are changed to a status other than normal

An infrastructure administrator checks the status of the network device and takes corrective action if the problem can be solved.

If the problem cannot be solved by the infrastructure administrator, notification of the following information is sent to the network device administrator, requesting solving of the problem.

- Network device name in which the error occurred
- Network device status
- Phenomenon noticed when receiving requests for confirmation from a tenant administrator or tenant user

11.4.1 Identification of Error Locations

This section explains how to identify the network device on which an error has occurred.

When Notified of an Error by a Tenant Administrator or Tenant User

Use the following procedure to determine the location of the problem.

1. Confirm the network device status using the ROR console.
 - If event logs showing the errors of network devices are not output.
If a port status change on a registered network device is detected, the message number 42781 will be output.
If the port status is "down" or "unknown" and that change was not caused by the infrastructure administrator, it indicates a problem with the network device.
 - If status icons of resources on the network device tree have not changed to a status other than normal
2. When there is a network device on which an error has occurred, check if the device is the network device used for an L-Platform for which notification has been received.

When an error occurs on a network device which is not used for the L-Platform for which notification has been received, refer to "[When an Error is Detected during Status Confirmation Using the ROR Console](#)".

- When the network device on which an error has occurred is a firewall
 - a. In the orchestration tree, select the L-Platform providing services for which notification has been received from a tenant administrator or tenant user that an error has occurred.
 - b. Select the [Resource List] tab of the Main Panel.
 - c. Confirm [Use Resource] of [Firewall List].

When the status of a used resource is something other than "(normal)", and the name is the same as the network device confirmed in 1. on which an error has occurred, the error will be identified as having occurred on the network device (firewall).

Additionally, confirm the status of the specified firewall.

For details on how to confirm the status of the firewall, refer to "[11.4.2 Firewall Status Confirmation](#)".

- When the network device on which an error occurs is something other than a firewall
 - a. Confirm the name of the network resource.
The name of the network resource can be confirmed in the items of the displayed results of the `rcxadm netdevice show` command (`AllocatedResources[Network]`). Specify the name of the network device confirmed in 1. for the name of the network device name for the name option.
 - b. Select the L-Platform from the orchestration tree.
 - c. Select the L-Server under the L-Platform.
 - d. Select the [Resource Details] tab of the Main Panel.
 - e. Confirm [Network Resource] of [Network Information]. When the network device name is the same as the name confirmed in a., the error on the network device (L2 switch) can be identified on the specified network device that was confirmed in a.

Additionally, confirm the status of the specified L2 switch.

For details on how to confirm the L2 switch status, refer to "[11.4.3 L2 Switch Status Confirmation](#)".

When there is no network device on which an error has occurred, one of the following errors may have occurred.

- The wrong access control rules have been applied to the firewall, and passing of communication packet data is being rejected
Use the following procedure to confirm the status of the firewall.
 - a. Identify the firewall used for the notified L-Platform.
For details on how to specify the firewall, refer to "[When the network device on which an error occurs is firewall](#)".
 - b. Confirm the status of the firewall.
For details on how to confirm the status of the firewall, refer to "[11.4.2 Firewall Status Confirmation](#)".

- An error occurred in a network device that is managed using Resource Orchestrator

Request investigation from the network device administrator from the following point of view.

- If an error has occurred on a network device connecting to the network device used for the L-Platform.

- If an error has occurred on a network device on the communication route to the L-Platform

The network device administrator must confirm the network device status, using the following procedure.

- a. Log in directly to a network device other than the L-Platform.
- b. Confirm the status of the network device.



- For details on the rcxadm netdevice command, refer to "3.8 rcxadm netdevice" in the "Reference Guide (Command/XML) CE".
- For details on the operations (such as status confirmation) for network devices, refer to the manuals of network devices.

When an Error is Detected during Status Confirmation Using the ROR Console

When an error is detected during status confirmation using the ROR console, it can be determined that an error has occurred on the network device which has indicated an error (a firewall or an L2 switch).

- When the network device on which an error has occurred is a firewall

Confirm the status of the firewall.

For details on how to confirm the status of the firewall, refer to "[11.4.2 Firewall Status Confirmation](#)".

- When the network device on which an error has occurred is an L2 switch

Check the status of the L2 switch.

For details on how to confirm the L2 switch status, refer to "[11.4.3 L2 Switch Status Confirmation](#)".



For details on the operations (such as status confirmation) for network devices, refer to the manuals of network devices.

11.4.2 Firewall Status Confirmation

This section explains the confirmation procedure of firewall status.

When an L-Platform Using a Firewall is Identified

Use the following procedure to confirm the status of the firewall.

1. In the orchestration tree, select the network device of a firewall under the L-Platform.
2. Select the [Resource Details] tab, and click the link of [Preserved resource] of [Network Device] of [Basic Information of Network Device].

The [Resource Details] tab of the network device is displayed.

3. Confirm the displayed detailed information.
 - When there is a link of [Launch Network Device Web UI] in [Hardware Details]
 - a. Click the link and start the firewall management screen.
 - b. Confirm event logs or status from the started management window, and check the error detected by the firewall, such as passing of communication packets is being rejected.

- When there is no link of [Launch Network Device Web UI] in [Hardware Details]

Confirm the following information displayed in the Main Panel.

Basic Information - Device Status

The status of the firewall is displayed.

Indicates that an error has occurred, when the status is something other than "normal".

Port Information - Link Status

The port status of the firewall is displayed.

Indicates that a port error has occurred, when the status is something other than "up".

4. Confirm the status of the firewall.

- When passing of communication packets is rejected by a firewall or an event log is output

The infrastructure administrator must confirm if the following items using auto-configuration are correct.

- Scripts for configurations
- Parameter files
- Configuration files for interfaces

- When it is possible that the hardware has failed, in cases where the firewall device status is "unknown" or the link status is "down"

The infrastructure administrator must request confirmation the status from the administrator of the network device, in cases where firewall hardware has not failed. The network device administrator must request a hardware maintenance person to take corrective action when hardware has failed.

5. Take corrective action based on the results of checked scripts and files.

- When there are no errors in the scripts or files checked in 4.

Request confirmation from a tenant administrator or tenant user that there are no errors in the parameters taken over during the L-Platform update.

- When there are errors in the scripts or files checked in 4.

The infrastructure administrator will log in to the firewall directly, delete the failed configuration (such as rejection of communication packets), and modify error scripts or files.

6. Take corrective action based on the results of parameter checks.

- When there are no errors in the parameters taken over during the L-Platform update

Confirm with the administrator of the network device that the firewall configuration has not been modified, since an unexpected definition modification may have been made.

- When there are errors in the parameters taken over during the L-Platform update

The infrastructure administrator will log in to the firewall directly and delete the failed configuration (such as rejection of communication packets).

7. Take corrective action based on the check results if definitions have been modified.

- When the network device administrator has not modified the configuration

Extract the firewall definitions and check the content. When inappropriate settings have been configured, log in to the firewall directly, and modify the definitions.

- When a network device administrator has modified the configuration

Check if the configuration modification is necessary.

- When the configuration modification is not necessary

The infrastructure administrator must log in to the firewall directly, and delete or modify the problem-causing configuration (such as rejection of communication packets).

- When configuration modifications were necessary based on the system operation policy

Review if the details of scripts, parameter files, and interface configuration files are based on the operation policy.

When a Firewall Error is Detected during Status Confirmation Using the ROR Console

Use the following procedure to confirm the status of the firewall.

1. Select the network device of firewall on which an error occurs from the network device tree.
2. Select the [Resource Details] tab.
3. Confirm the status of the firewall.
4. Identify the L-Platform in use.
 - a. Confirm the name of the firewall allocated using auto-configuration by checking the items in displayed results of the `rcxadm netdevice show` command (`AllocatedResources[Firewall]`).
 - b. Confirm the name of the L-Platform using the firewall by checking the items in displayed results of the `rcxadm firewall show` command (`L-Platform Name`). Specify the firewall name confirmed in a. as the firewall name to be specified for the name option.
5. Confirmation procedure after this, refer to the operation after step 3. of "[When an L-Platform Using a Firewall is Identified](#)".



See

- For details on firewall operations (login, status confirmation, definition extraction, definition modification), refer to the manuals of firewalls.
- For details on the `rcxadm netdevice` command, refer to "3.8 `rcxadm netdevice`" in the "Reference Guide (Command/XML) CE".
- For details on the `rcxadm firewall` command, refer to "3.4 `rcxadm firewall`" in the "Reference Guide (Command/XML) CE".

11.4.3 L2 Switch Status Confirmation

This section explains the confirmation procedure of L2 switch status.

Use the following procedure to confirm the status of the L2 switch.

1. Select the network device on which the status icon has changed from normal to another using the network device tree.
2. Select the [Resource Details] tab.
3. Confirm the displayed detailed information.
 - When there is a link of [Launch Network Device Web UI] in [Hardware Details]
 - a. Click the link and start the L2 switch management screen.
 - b. Confirm event logs or status from the started management window, and check the error detected by the L2 switch.
 - When there is no link of [Launch Network Device Web UI] in [Hardware Details]

Confirm the following information displayed in the Main Panel.

Basic Information - Device Status

The status of the L2 switch is displayed.

Indicates that an error has occurred, when the status is something other than "normal".

Port Information - Link Status

The status of the port of the L2 switch is displayed.

Indicates that a port error has occurred, when the status is something other than "up".

4. Take corrective action based on the results of L2 switch status checks.
 - When an error is detected on an L2 switch or an event log is output

The infrastructure administrator must confirm if the specifications of configuration scripts or parameter files used in auto-configuration are correct.

- When it is possible that the hardware has failed, in cases where the L2 switch device status is "unknown" or the link status is "down"

The infrastructure administrator must request confirmation of the status of the L2 switch from the network device administrator. The network device administrator must request a hardware maintenance person to take corrective action when hardware has failed.

5. Take corrective action based on the results of checked scripts and files.

- When there are no errors in the scripts or settings in files checked in 4.

Confirm with the administrator of the network device that the L2 switch configuration has not been modified, since an unexpected definition modification may have been made.

- When there are errors in the scripts or settings in files checked in 4.

The infrastructure administrator will log in to the L2 switch directly, delete the failed configurations, and modify error scripts or files.

6. Take corrective action based on the check results if definitions have been modified.

- When the network device administrator has not modified the configuration

Extract the L2 switch definitions and check the content. When inappropriate settings have been configured, log in to the L2 switch directly, and modify the definitions.

- When a network device administrator has modified the configuration

Check that the configuration modification is necessary.

- When the configuration modification is not necessary

The infrastructure administrator must log in to the L2 switch directly, and delete or modify the problem-causing configuration.

- When configuration modifications were necessary based on the system operation policy

Review if the details of scripts and parameter files are based on the operation policy.



See

For details on L2 switch operations (login, status confirmation, definition extraction, definition modification), refer to the manuals of L2 switches.

11.4.4 Status Confirmation of Other Network Devices

This section explains the confirmation procedure for other network devices.

Use the following procedure to check the statuses of other network devices.

1. Log in to the network device directly.
2. Confirm the status using the network device functions.



See

For details on the operations (such as login and status confirmation) on the network devices, refer to the manuals of network devices.

11.5 Monitoring Storage

This section explains how to monitor storage.

The following is possible when monitoring storage.

- Display of virtual storage resource and disk resource information

- Monitoring of storage unit errors

Use of storage management software to monitor storage.

- For ETERNUS storage

Refer to the "ETERNUS SF Storage Cruiser User's Guide" and the "ETERNUS SF Storage Cruiser Message Guide".

- For EMC CLARiiON storage

Refer to the "EMC Navisphere Manager Administrator's Guide".

- For EMC Symmetrix DMX storage and EMC Symmetrix VMAX storage

Refer to the "EMC Navisphere Manager Administrator's Guide".

- For NetApp storage

Refer to the "Data ONTAP Storage Management Guide".

Chapter 12 Collecting Power Consumption Data and Displaying Graphs

This chapter explains how to export the power consumption data collected from registered power monitoring targets and how to display it as graphs, and also describes the exported data's format.

12.1 Overview

This section details the power consumption data that is collected from registered power monitoring targets.

Resource Orchestrator calculates the power (in Watts) and energy (Watt-hours) consumed by a power monitoring target by multiplying its collected electrical current (Amperes) by its registered voltage value (Volts).

This data can then be exported to a file in CSV format or as a graph.

The data can then be summarized or visualized as a graph, using an external tool such as Excel, to obtain a graphical representation of the power consumed by each power monitoring target.

Information

In Resource Orchestrator, power consumption is calculated as the product of electrical current (A) multiplied by voltage (V). Normally, power consumption is the product of an electrical current multiplied by a voltage and an additional phase factor (if the phase difference between the current and voltage is defined as " θ ", this factor is expressed as " $\cos \theta$ ").

Note

This data should only be used as a reference to evaluate the power consumption status. It should not be used as an exact power consumption measurement for billing purposes.

12.2 Exporting Power Consumption Data

For details of how to export power consumption data, refer to "13.1 Exporting Power Consumption Data" of the "User's Guide for Infrastructure Administrator (Resource Management) CE".

12.3 Power Consumption Data File (CSV Format)

This section explains the power consumption data file format (CSV format).

Each defined item of the exported power consumption data is separated by a comma (",").

Each line is exported in the following format.

- Data format

Data is exported using the following format:

```
Time,power_monitoring_target_name(data_type)[,power_monitoring_target_name(data_type)]...  
time1,data1[,data1]...  
time2,data2[,data2]...
```

- Header line

The header line contains column titles identifying the data (from line 2 and later) that is displayed under each column. Each column title is set according to the data types that have been selected in the [Export Environmental Data (*power_monitoring_target_type*)] dialog.

- Time

This column displays the date and time at which each data sample was collected.

Within data lines, the entry corresponding to this column is displayed in the following format: "YYYY-MM-DD hh:mm:ss" ("YYYY": Year, "MM": Month, "DD": Date, "hh:mm:ss": Hours:Minutes:Seconds). The time is displayed according to the time zone set in the admin server operating system.

- *power_monitoring_target_name(data_type)*

The *power_monitoring_target_name* part displays the name of the selected target.

The *data_type* part displays the following data types:

- Power (W) is shown as "power"
- Average Power (W) as "power-average"
- Energy (Wh) as "energy"

- Data lines

Each data line contains data values corresponding to each of the column titles shown in the header line.

A hyphen ("-") is displayed for any data that could not be collected.



Note

- Regardless of the specified power monitoring target, the data held within Resource Orchestrator that fits the conditions given for the selected time span and rate will be exported.
- Depending on the statuses of specified power monitoring targets, the data corresponding to the specified time span and rate may not have been collected.
In this case, a hyphen ("-") will be displayed for any data that could not be collected.
Hyphens can be displayed when data was collected from another power monitoring target (including a deleted one) at the same collection time, and data was not collected from the specified power monitoring target.
No data is collected from servers on which ServerView Agents is not running. In this case, missing data is shown using hyphens ("-").
- When power consumption data is exported, if the latest data is being collected at that point, some data may be shown using hyphens ("-").
- If the "Finest sampling" "rate" is selected in the [Export Environmental Data (*power_monitoring_target*)] dialog, the power and average power values will be equal for each data sample.
- If a "rate" other than "Finest sampling" has been selected in the [Export Environmental Data (*power_monitoring_target*)] dialog, values for each sample are displayed as follows. If data was collected at the displayed sample time, that value is displayed. If no data was collected at the displayed sample time, the last data collected in the time interval between that sample and the previous sample will be displayed.
- The energy (Wh) value of a finest sample is calculated under the assumption that the power value (W) collected for the sample stayed at the same value until the next sampling (in other words it is assumed that power values (W) do not vary during the duration of the polling interval).
- Only daily average data can be collected from blade chassis.
- Data collected from servers does not include power consumed by storage blades.
- For rates other than "Finest sampling", the energy value is calculated as the sum of energy samples. In such cases, the energy value of samples for which no data could be collected will be deemed to be 0.
- The average power (W) of each sample is calculated from the energy value (Wh) of that sample and its corresponding time interval.

12.4 Displaying Power Consumption Data Graphs

For details of how to display graphs of power consumption data, refer to "13.2 Displaying Power Consumption Data Graphs" of the "User's Guide for Infrastructure Administrator (Resource Management) CE".

Chapter 13 Monitoring Resource Pools (Dashboard)

This chapter explains how to monitor resource pools.

Use the [Dashboard (Pool Conditions)] tab of the ROR console to monitor the usage status of resource pools allocated to tenants and resource pools of overall systems.

For details on the [Dashboard (Pool Conditions)] tab, refer to "Chapter 4 Dashboard (Pool Conditions)" of the "User's Guide for Infrastructure Administrators CE".

Chapter 14 Monitoring L-Platforms

This chapter explains how to monitor L-Platforms.

The operation status of L-Servers can be monitored from the [Dashboard (System Conditions)] tab on the ROR console.

For details on the [Dashboard (System Conditions)] tab, refer to "Chapter 5 Dashboard (System Conditions)" in the "User's Guide for Infrastructure Administrators CE".

Chapter 15 Accounting

This chapter explains the accounting.

15.1 Overview

This section explains an overview of the accounting.

This function provides the basis to usage charge corresponding to the L-Platforms used by each tenant.

The accounting includes following functions.

Manage accounting information of L-Platform templates

Add, modify, or delete the accounting information of L-Platform templates. Based on the accounting information, usage fee (the estimated price) of L-Platform templates can be displayed on the L-Platform management window, etc. Usage charges can also be viewed in the usage charge window.

The database where the accounting information of L-Platform templates is stored is called the product master.

Note

Usage fee (the estimated price) for the L-Platform template will be displayed provided that settings for the estimated price display function are enabled. Refer to "8.7.1 Display Function Settings for Estimated Price" for information on settings for the estimated price display function.

Usage charge calculation


Usage charges are calculated based on the amount that the L-Platform is used and the charge information. The calculated usage charge is sent to the email address specified in the tenant management window of the ROR console. The usage charge is also stored in the usage charge database.

Viewing usage charges

Usage charges can be viewed in the ROR console. If necessary, the usage charge information can also be downloaded as a file.

Operation image

The operation image of accounting is shown below.



[Management and operation of accounting information by the infrastructure administrator]

1. The infrastructure administrator registers L-Platform template information using the L-Platform management window of the ROR Console.
2. The infrastructure administrator registers the accounting information using the product master maintenance command. Refer to "[15.3 Operate Accounting Information](#)" for information on how to operate the accounting information.
3. The infrastructure administrator publishes the L-Platform template.

[Create tenant]

4. The infrastructure administrator creates tenants.
Set the cut-off date for the calculation of usage charges and the email address to send them to as necessary.

[Operation in the tenant]

5. The subscriber references the usage fee (the estimated price) of the L-Platform templates displayed on the L-Platform management window, and subscribes to the L-Platform.
6. The tenant administrator references to the usage fee (the estimated price) of the L-Platform templates displayed in the Request on the ROR Console, then approves or rejects the subscription.
7. The infrastructure administrator views the monthly estimated charges for L-Platform templates displayed in the Request in the ROR console and assesses the L-Platform subscriptions.

[Invoice for usage charges]

8. The accounts manager receives the usage charge file.
Usage charges are automatically calculated based on the amount that each L-Platform is used and the charge information, then stored in the usage charge database. The usage charges for the previous month are confirmed the day after the cut-off date, and then sent as a usage charge file to the email address.
9. The accounts manager views the usage charge file, creates the invoice, and then sends it to the tenant.

[View usage charges]

10. The infrastructure administrator and the tenant administrator can view the confirmed usage charges. If necessary, the usage charge information can also be downloaded as a file.

15.2 Manage Accounting Information

This section explains how to manage the accounting information. The accounting information is managed in the product master.

The accounting information of product master is managed using the product master maintenance command. The product master maintenance command provides the following functions.

- Register the accounting information of an L-Platform template on the product master
- Output the accounting information of an L-Platform template that is registered on the product master to the accounting information file

Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the product master maintenance command.

Information

Usage fee (the estimated price) of L-Platform templates will be displayed when the following operations are performed by registering the accounting information.

- L-Platform subscription from the L-Platform management window
 - Modifying L-Platform templates
 - Approving application list from the ROR Console
 - Assessment from the ROR Console
-



Usage fee (the estimated price) for the L-Platform template will be displayed provided that settings for the estimated price display function are enabled. Refer to "8.7.1 Display Function Settings for Estimated Price" for information on settings for the estimated price display function.

15.2.1 Information Maintained by Product Master

The accounting information can be set to the product master as products for each element type (category) that consists of the L-Platform. The categories that can be set as products are shown below. Note that the unit prices can be specified by yearly, monthly, or hourly.

Category	Explanation
CPU	Unit price per CPU (*1).
CPU clock	Unit price per CPU clock of 0.1GHz (*1).
Memory capacity	Unit price per memory capacity of 0.1GB.
Virtual L-Server	Unit price per virtual L-Server. Set the unit price based on system disk, snapshot, and software, etc. Do not include the price for CPU, CPU clock, or memory in the specified value.
Physical L-Server	Unit price per physical L-Server. Set the unit price based on system disk, snapshot, and software, etc. Do not include the price for CPU, CPU clock, or memory in the specified value. Note that the usage fee (the estimated price) displayed on the L-Platform Management window may differ from actual price. (*2)
Data disk Capacity	Unit price per disk capacity of 0.1GB. (*3)
Template	Unit price per L-Platform template. Set the unit price based on firewall cost, network resources (network line, global IP, segment, NIC) usage cost, and system SE cost, etc. Do not include the price for virtual server or virtual disk in the specified value.

*1: The price per CPU allocated as usage fee (the estimated price) is the sum of "Unit price per CPU" and "Unit price per CPU clock * CPU clock".

Example) An example price calculation is shown below assuming following conditions.

[Conditions]

- CPU Clock: \$0.10/0.1GHz
- CPU: \$0.80/unit

[Example calculation]

- Price for a CPU of 3.2GHz: $\$0.10 * 32 + \$0.80 = \$4.00$
- Price for two CPUs each of 1.0GHz: $(\$0.10 * 10 + \$0.80) * 2 = \$3.60$

*2: When a physical L-Server is to be newly deployed, estimated price for the CPU performance and memory capacity will be calculated according to the values entered on the L-Platform Management window. The physical L-Server that is actually deployed will have performance that is closest to the value that was entered on the L-Platform Management window. Accordingly, estimated price displayed may differ to the actual price. For physical L-Servers that have already been deployed, estimated price will be calculated based on the actual CPU performance and memory capacity.

*3:) Estimated price for data disk capacity are added according to disk capacity usage for each storage pool, with no differentiation between extension disks and existing disks. Note also that if the same existing disk is attached to multiple L-Servers at this time, calculations for the existing disk capacity will be added together in accordance with the number of L-Servers to which the disk is attached. Resource allocation methods differ between extension disks and existing disks. For this reason, the storage pool used for an existing disk should not be the same as one used for an extension disk. For operations that use separate storage pools, charges for the existing disk can be calculated using the following two methods:

- If charging according to the total capacity of an existing disk attached to L-Server(s):
In the storage pool, set the amount to be charged (in units of 0.1GB) when attaching an existing disk to an L-Server. If the same existing disk is attached to multiple different L-Servers at this time, the disk capacity will be added together for the total number of attached L-Servers and charged accordingly.
- If charging by the available existing disk from the L-Platform:
Rather than setting the price for the existing disk defined by the storage pool, perform settings instead to include the usage charge for the available existing disk in the price for the L-Platform template.



.....

L-Platform operation when reconfiguration is not permitted

L-Servers and others will be allocated using the system configuration defined in the template if the L-Platform template reconfiguration is not permitted in the operation. In this case, only the prices for the templates need to be set and the prices for the L-Servers need not.

About Setting Prices

- In the Solaris container, although it is possible to allocate more CPU and memory to the non-global zone than is installed in the host operating system, if the CPU load and memory usage in each non-global zone increase, the allocated CPU function and memory capacity may become unusable.
In order to not exceed the capacity physically held by the host operating system when creating a non-global zone, it is possible to ensure the functionality of the allocated amount in the non-global zone by allocating CPU and memory.
However, if used for development environments or if non-global zones which exceed the physical CPU and physical memory are created, it is not possible to ensure the allocated amount of functionality. If CPU and memory are made the subject of charges in environments where the allocated functionality cannot be ensured, consider setting the CPU and memory unit prices at lower prices than normal.
- As it may not be possible to ensure the functionality of allocated amounts of CPU and memory if overcommit is enabled in cases such as where L-Platform import from related L-Servers is performed using VMware and Hyper-V as virtual software, give some consideration to price settings.

.....

The usage fee (the estimated price) displayed on the L-Platform management window and others is calculated as follows.

$\text{Data disk monthly price} = \text{disk unit price} * \text{amount of disk} * \text{monthly converted price}$ $+ \text{memory unit price} * \text{amount of memory} * \text{converted monthly price}$
--

- If the price is hourly basis, usage fee (the estimated price) is calculated for 24 hours * 30 days.
- If the price is yearly basis, usage fee (the estimated price) is twelfth of that price.
- Usage fee (the estimated price) is rounded to nearest hundredths of dollar (cent) when displayed.

15.2.2 Accounting Information File Format

The accounting information of L-Platform templates is written to the accounting information file. The format of accounting information file is as follows.

- Character code is UTF-8.
- Each column is separated by a comma.
- Comments cannot be written.
- Character string data are enclosed by double quotations. When the double quotation is a character in a character string, enter two double quotations to escape it.
- When a double quotation is set in a character string that is enclosed with double quotations, the single double quotation will be ignored.



Example

When the following string is entered in the accounting information file, the value will be "aaaaa"a".

```
"aaaaa" "a"
```

When the following string is entered in the accounting information file, the value will be "aaaaaa".

```
"aaa"aaa"
```

Columns represented in an accounting information file are shown below.

No	Name	Omit	Explanation
1	Product ID	No	Specify ID that identifies the product. Register one product for each resource identifier. Specify 16 or less characters using alphanumeric characters, _(underline), or -(hyphen).
2	Priority	No	Specify the priority in a product. Multiple unit prices can be specified in a product, and the unit price with larger value has higher priority. (*1) The same priority cannot be set to the same product. Specify the numerical value from 0 to 999.
3	Start of applicable date	No	Specify start of applicable date. Format: YYYY-MM-DDThh:mm:ss.SSSZ Example) 2011-04-01T00:00:00.000+0900
4	End of applicable date	Yes	Specify end of applicable date. Format: YYYY-MM-DDThh:mm:ss.SSSZ Example) 2012-03-31T23:59:59.999+0900 Specify the date prior to the start of applicable date.
5	Category code	No	Specify the product category using following codes. <ul style="list-style-type: none"> - cpu: CPU - cpu clock: CPU clock - memory: memory capacity - vm: virtual L-Server

No	Name	Omit	Explanation
			<ul style="list-style-type: none"> - pm: physical L-Server - disk: extension disk capacity - template: template
6	Resource identifier	No	Specify information to identify the accounting target resource with 128 or less alphanumeric characters. Resource identifiers vary by the category. (*2) <ul style="list-style-type: none"> - cpu, cpu_clock, memory: VM pool name or sever pool name - vm: virtual L-Server image name - pm: physical L-Server image name - disk: storage pool name - template: template ID
7	Unit code	No	Specify accounting unit using following codes. <ul style="list-style-type: none"> - year: yearly - month: monthly - hour: hourly
8	Unit price	No	Specify unit price. Specify 11 or less digits for the integer portion and 4 or less digit for the fractional portion. Specify the fractional currency unit (ex. cent) as 1 for U.S. dollar, euro, or Singapore dollar. Specify the currency unit as 1 for Japanese yen. (*3) Example) Specify 23 if the setting value is \$0.23. Specify 23 if the setting value is ¥23.
9	Product name	No	Specify the name to distinguish the products using 128 or less characters.
10	Description	Yes	Specify the description of the product using 1024 or less characters. A comma that follows the name must be entered even when the specification is omitted. Example) ...,Unit price,"Product name",

*1) An example of description is shown below assuming following settings.

- Example of the setting for product ID "ME-0001"

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ME-0001	0	\$2.00	2012-01-01T00:00:00.000+0900	None
Data B	ME-0001	1	\$1.00	2012-08-01T00:00:00.000+0900	2012-08-31T23:59:59.999+0900

- The unit price for product ID "ME-0001" is \$2.00 on 2011-07-01 because only data A is applied.
- The unit price for product ID "ME-0001" is \$1.00 on 2011-08-15 because data B has higher priority even though both data A and data B are in the applicable period.

- An example description of accounting information file

```
"ME-0001",0,"2012-01-01T00:00:00.000+0900",,"memory","/VMPool", "month",200,"Standard memory","Standard memory"
```

```
"ME-0001",1,"2012-08-01T00:00:00.000+0900","2012-08-31T23:59:59.999+0900","memory","/
VMPool","month",100,"Standard memory(Campaign)","Standard memory(Campaign)"
```

*2) The value of the resource identifier can be obtained from the value of the corresponding XML tag of the template information list that is output in XML format by using the template information list display command. Refer to "9.12 cfmg_listtemplate (Displaying Template Information List)" in the "Reference Guide CE" for information on how to use the template information list display command.

The resource identifier for each category code and the corresponding template information (XML tag) are shown below.

- Resource identifiers and corresponding template information (XML tag)

Category code	Resource identifier	Template information (XML tag)
template	Template ID	<template><id>
vm	Virtual L-Server image name	<image><imageName>
pm	Physical L-Server image name	<image><imageName>
cpu	VM pool name or sever pool name	<server><pool>
cpu_clock	VM pool name or sever pool name	<server><pool>
memory	VM pool name or sever pool name	<server><pool>
disk	Storage pool name	<server><storagePool>

Specify VM pool name, sever pool name and storage pool name in the format that start with / (slash).

If the VM pool name, sever pool name or storage pool name are omitted, they are output to the template information as <pool /> or <storagePool />, respectively. In this case, refer to the resource pool and perform settings on the ROR Console **Resource** tab. Refer to the "User's Guide for Infrastructure Administrators (Resource Management) CE" for information on the ROR Console **Resource** tab.

*3) The currency used is determined by the currency information setting. Refer to "8.7.2 Currency Information Settings" for information on the currency information setting.

An example description of template information and corresponding accounting information is shown below.

- Example of template information

```
<?xml version="1.0" encoding="Windows-31J"?>
<templates>
  <template>
    <id>templateId1</id>
    ...
    <servers>
      <server>
        <pool>/VMHostPool</pool>
        <storagePool>/StoragePool</storagePool>
        ...
        <image>
          <imageName>image1</imageName>
          ...
        </image>
      </server>
    </servers>
  </template>
</templates>
```

- Example description of accounting information file

```
"TP-0001",0,"2012-01-01T00:00:00.000+0900",,"template","templateId1","month",1000,"Web/DB
Windows Server 2008 R2 Standard","Service Windows Server 2008 R2 Standard"
```

```
"VM-0001",0,"2012-01-01T00:00:00.000+0900",,"vm","image1","month",500,"Windows Server 2008 R2
Standard","VM Windows Server 2008 R2 Standard"
"CP-0001",0,"2012-01-01T00:00:00.000+0900",,"cpu","/VMHostPool","month",100,"Xeon5110","Xeon5110"
"CL-0001",0,"2012-01-01T00:00:00.000+0900",,"cpu_clock","/VMHostPool","month",
50,"Xeon5110","Xeon5110"
"ME-0001",0,"2012-01-01T00:00:00.000+0900",,"memory","/VMHostPool","month",200,"Standard
memory","Standard memory"
"DI-0001",0,"2012-01-01T00:00:00.000+0900",,"disk","/StoragePool","month",10,"normal
disk","normal disk"
```

Note

- The accounting information will not be deleted from the product master automatically even after the end of applicable date. Reference to ["15.3.3 Delete Accounting Information"](#) to delete unnecessary accounting information.
- If the end of applicable date is specified, prepare other accounting information of the same product ID without specifying the end of applicable date.
- If the overcommit function is enabled, the category codes cpu_clock and memory will be calculated by default as CPU reserve performance and memory reserve capacity, respectively, and usage fee (the estimated price) will be displayed on the L-Platform Management window.
Refer to ["8.7.1 Display Function Settings for Estimated Price"](#) for information on charge settings when the overcommit function is enabled.

15.3 Operate Accounting Information

This section explains how to operate the accounting information.

The operation for the accounting information consists of registration, modification, deleting, and reference.

Register accounting information

Register the accounting information when newly created L-Platform templates are enabled.

The accounting information is set to the elements of L-Platform templates that are created. After finishing registration of the accounting information, enable the L-Platform templates.

It is also possible to register accounting information for L-Servers that were imported into the system using the L-Server import command.

Refer to ["15.3.1 Register Accounting Information"](#) for information on how to register the accounting information.

Modify accounting information

Modify the accounting information of the L-Platform templates that are already enabled. This corresponds to the case of setting limited time price for campaign or raising the price, for example.

The price is modified to the accounting information of the L-Platform templates registered on the product master.

It is also possible to modify accounting information for L-Servers that were imported into the system.

Refer to ["15.3.2 Modify Accounting Information Command"](#) for information on how to modify the accounting information.

Delete accounting information

Delete the accounting information if the following conditions are met.

- The L-Platform templates are disabled.
- The log that shows the usage result of the corresponding L-Platform templates does not exist in the metering log.

Refer to ["15.3.3 Delete Accounting Information"](#) for information on how to delete the accounting information. Refer also to ["Appendix B Metering Log"](#) for information on the metering log.

Reference accounting information

Reference the accounting information registered on the product master when calculating the accounting. Refer to ["15.3.4 Reference Accounting Information"](#) for information on how to reference the accounting information.

15.3.1 Register Accounting Information

Methods for registering accounting information differ for L-Platform templates and L-Servers that were imported into the system.

Register Accounting Information of L-Platform template

Create new L-Platform templates, and set the accounting information to the elements of the L-Platform template that was created. After finishing the registration of the accounting information, enable the L-Platform templates.

Follow the procedure below to register the accounting information.

1. Register new L-Platform templates.
Refer to "8.3.2 Creating New L-Platform Template" in the *User's Guide for Infrastructure Administrators CE* for information on how to register L-Platform templates.
2. Obtain a list of the template information registered.
Refer to "9.13 cfmng_listtemplate (Displaying Template Information List)" in the "Reference Guide CE" for information on how to obtain the template information list.
3. Execute the output function of the product master maintenance command.
The accounting information of the L-Platform templates registered on the product master will be output to the specified accounting information file by executing the output function of the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the output function of the product master maintenance command.
This operation is unnecessary for the initial registration. Create a new accounting information file from step 4.
4. Add the accounting information of the L-Platform templates to the output accounting information file based on the template information list.
Specify a date prior to the L-Platform template enabled date as the start of applicable date in the accounting information to be added. Omit the end of applicable date. Refer to "15.2.2 Accounting Information File Format" for information on the accounting information file format.

Example)

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	None

5. Notify the tenant of the contents of the newly enabled L-Platform templates (L-Platform template name, summary of the L-Platform template, usage fee (the estimated price), start of applicable date, etc.).
6. Execute the register function of the product master maintenance command.
Specify the accounting information file updated, and execute the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the register function of the product master maintenance command.
7. Enable the L-Platform template.
Enable the L-Platform template on the start of applicable date. Refer to "8.3.6 Publishing and Hiding L-Platform Template" in the "User's Guide for Infrastructure Administrators CE" for information on how to enable the L-Platform templates.

Registering Accounting Information for L-Servers imported into the System

Use the following procedures to import an L-Server into the system and register accounting information for the imported L-Server.

1. Use the L-Server import command to import the L-Server into the system.
Refer to "12.4 cfmng_importlserver (Import L-Server)" in the "Reference Guide CE" for information on how to use the L-Server import command.

Note

- If the <VM pool name> option is omitted when executing the L-Server import command, it will not be possible to register accounting information for the CPU, CPU clock or memory capacity.

- If the <storage pool name> option is omitted when executing the L-Server import command, it will not be possible to register accounting information for the L-Server data disk.

2. Obtain the template information list that was automatically generated by the L-Server import command. The template information list can be obtained using the template information list display command. Refer to "9.12 cfmg_listtemplate (Displaying Template Information List)" in the "Reference Guide CE" for information on how to use the template information list display command.

3.



Check the following tags to distinguish between automatically generated templates:

- Template ID (<template><id>): The template ID output when the L-Server import command is executed.
- L-Server name (<template><description>): The L-Server name specified when the L-Server import command is executed.

4. Execute the output function of the product master maintenance command.

The accounting information of the L-Platform templates registered on the product master will be output to the specified accounting information file by executing the output function of the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the output function of the product master maintenance command.

This operation is unnecessary for the initial registration. Create a new accounting information file from step 4.

5. Add the accounting information to the output accounting information file based on the template information list.

When applying a start date for the accounting information to be added, specify a date/time prior to the date/time that the L-Server import command was executed. Omit the end of applicable date. Refer to "15.2.2 Accounting Information File Format" for information on the accounting information file format.

Example)

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	None

6. Execute the register function of the product master maintenance command.

Specify the accounting information file updated, and execute the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the register function of the product master maintenance command.

15.3.2 Modify Accounting Information Command

Modify the accounting information of the L-Platform templates that are already enabled. This corresponds to the case of raising the price or setting limited time price for campaign.

It is also possible to modify accounting information for L-Servers imported into the system.

Follow the procedures below to modify accounting information for either L-Platform templates registered in the product master or L-Servers imported into the system.

1. Execute the output function of the product master maintenance command.

The accounting information of the L-Platform templates registered on the product master will be output to the specified accounting information file by executing the output function of the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the output function of the product master maintenance command.

2. Modify the price, or specify the time period of the output accounting information file.

An example of the modification of the accounting information file is shown below. Specify future date to the modification date.

- a. Add the modified unit price data newly to change the unit price of the product that is already registered on the product master. Example) Modify the unit price of the product whose product ID is "ID001" to \$2.10 from 2012-08-01.

Before modification:

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	None

After modification:

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	2012-07-31T23:59:59.999+0900
Data B	ID001	1	\$2.10	2012-08-01T00:00:00.000+0900	None

Set as follows for existing data A.

- End of applicable date: Modify to the date just before the modification date.

Set as follows for new data B.

- Priority: Higher priority than the existing data A
- Unit price: New unit price
- Start of applicable date: Modification date
- End of applicable date: Omit

- b. Add new data for the specific time period if a limited time price such as campaign price is to be registered.

Example) Halve the price in the period between 2012-08-01 and 2012-08-31.

Before modification:

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	None

After modification:

	Product ID	Priority	Unit price	Start of applicable date	End of applicable date
Data A	ID001	0	\$2.00	2012-01-01T00:00:00.000+0900	None
Data B	ID001	1	\$1.00	2012-08-01T00:00:00.000+0900	2012-08-31T23:59:59.999+0900

Do not modify existing data A.

Set as follows for new data B.

- Priority: Higher priority than the existing data A
- Unit price: New unit price
- Start of applicable date: Start date of the period
- End of applicable date: End date of the period

Refer to "15.2.2 Accounting Information File Format" for information on the accounting information file format.

3. Notify the tenant of the contents of the modified L-Platform templates (L-Platform template name, usage fee (the estimated price), start of applicable date, etc.).
4. Execute the register function of the product master maintenance command.
Specify the accounting information file updated, and execute the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the register function of the product master maintenance command.

Note

- If the applicable start date is not set to a future date and time, modify the charge information after the system has stopped. If system operation is not stopped, the pre-modification amounts may be displayed for the estimated charges and usage charges.

- The displayed price does not change for the subscription from saved specifications if the specifications are saved before modifying the price. Notify the tenant of the cautions that the price will not be the price displayed on the L-Platform management window but be the modified price after the modification date.

15.3.3 Delete Accounting Information

Delete the accounting information if the accounting calculation becomes unnecessary for the L-Platform templates or the L-Server imported into the system.

The accounting information becomes unnecessary if the following conditions are met.

- The L-Platform templates are disabled
- The log that shows the usage result of the corresponding L-Platform templates or L-Server imported into the system. does not exist in the metering log.

Follow the procedure below from disabling the L-Platform templates to deleting the accounting information.

Begin from "Check Metering Log" for L-Servers imported into the system.



See

Refer to "[Appendix B Metering Log](#)" for information on the metering log.

Disable L-Platform templates


1. Notify to the tenant about the contents of the L-Platform templates to be disabled (L-Platform template name, usage fee (the estimated price), start of applicable date, etc.).
2. Disable the L-Platform templates on the date that was notified.
Disable the L-Platform templates using the template management window of the ROR Console. Refer to "8.3.6 Publishing and Hiding L-Platform Template" in the "User's Guide for Infrastructure Administrators CE" for information on the setting for disabling the L-Platform template.

Check Metering Log

1. Check that the log that shows the usage result of the corresponding L-Platform templates does not exist in the metering log.
Output the metering log by the output metering logs command to check that no resource identifiers corresponding to the category code of that accounting information and no information for the item ID corresponding to that exists in the metering log.

The correspondence relationships between category codes and resource identifiers in the accounting information and item IDs in the metering log are shown below.

Accounting information



Accounting information		Metering log
Category code	Resource identifier	Item ID
cpu	VM pool name	vm_pool
	Server pool name	server_pool
cpu_clock	VM pool name	vm_pool
	Server pool name	server_pool

Accounting information		Metering log
Category code	Resource identifier	Item ID
memory	VM pool name	vm_pool
	Server pool name	server_pool
vm	Image name	image_name
pm	Image name	image_name
disk	Storage pool name	storage_pool
template	Template ID	base_template_id

Delete accounting information

1. Execute the output function of the product master maintenance command.
The accounting information of the L-Platform templates registered on the product master will be output to the specified accounting information file by executing the output function of the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the output function of the product master maintenance command.
2. Delete accounting information that becomes unnecessary from the output accounting information file.
3. Execute the register function of the product master maintenance command.
Specify the accounting information file updated, and execute the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the register function of the product master maintenance command.

15.3.4 Reference Accounting Information

Follow the procedure below to reference the accounting information registered on the product master.

1. Execute the output function of the product master maintenance command.
The accounting information of the L-Platform templates registered on the product master will be output to the specified accounting information file by executing the output function of the product master maintenance command. Refer to "10.3 productmaintain (Product Master Maintenance)" in the "Reference Guide CE" for information on the output function of the product master maintenance command.
2. Reference the output accounting information file.
Reference the accounting information file that was output by the output function of the product master maintenance command. Refer to "15.2.2 Accounting Information File Format" for information on the accounting information file format.

15.4 Calculation of Usage charges

This section explains how to calculate usage charges.



See

Refer to "[Appendix B Metering Log](#)" for information on the metering log, which is the information upon which the calculation of usage charges is based.

15.4.1 Overview of Usage charge Calculation

When a user subscribes to or unsubscribes from an L-Platform, or performs operations such as starting or stopping an L-Server, these are recorded as operation logs in the metering log.

Resource (L-Platform, L-Server, etc.) usage time is then aggregated from this operation log. Usage charges are calculated for each L-Platform based on the aggregated usage time, the amount of resources used, and the unit price in the charge information. The monthly usage charges are confirmed the day after the cut-off date set for the tenants, and then sent to the email address.

15.4.2 Resource Usage Times

Resource usage times include the time deployed and the time operated. These are aggregated based on the information in the metering log. Deployment time is the time between when the resource is deployed and when it is terminated. Operating time is the time between when the resource is started and when it is stopped.

Usage time is aggregated according to the following rules:

Usage time under one hour (in minutes)


Each day's usage time is aggregated as minutes.

Rounding

Times are rounded off to the nearest minute. Times 30 seconds and over are counted as 1 minute. Times less than 30 seconds are counted as 0 minutes.

The following shows an example of an L-Server deployed time and operated time.

This example shows when an L-Server is added at 7:00, started at 7:40, stopped at 18:20, and then deleted at 19:00.



15.4.3 How to Charge for Resources

Resources can be charged by a fixed rate or by the amount used. With fixed charging, the usage charges are charged according to a fixed fee rather than the usage time of the resources. With charging by the amount used, the usage charges are charged according to the usage time of the resources.

Unit codes for the charge information are used when charging. Fixed charging is used when either year or month is specified as the unit code. Charging by amount is used when hour is specified as the unit code.

The following table shows the relationships between the unit code specified in the charge information, the charging method, and the calculation of a month's usage charges:

Unit codes	charging method	Usage charges for one month
year	Fixed charging	Unit price / 12 (months)
month	Fixed charging	Unit price
hour	Charge by amount	Unit price / 60 (minutes) x usage time (minutes) x amount used



The unit price, unit code, and 1 month's usage charges for each resource specified in the charge information are displayed as usage charge information for each month from the ROR console **Accounting** tab to **Usage Charge Detail** window.

Refer to 12.3 Usage Charge Detail in the User's Guide for Infrastructure Administrators CE for information about the **Usage Charge**

Detail window. Also, tenant administrators can refer to the same information. Refer to 11.2 Usage Charge Detail in the "User's Guide for Tenant Administrators CE" for information about the **Usage Charge Detail** window viewable by tenant administrators.

15.4.4 Resource Usage Amounts and Times

If charging by amount is to be used for resources, the usage charge is determined by the amount of resources used and the time they are used for.

The following table shows the relationship between the product categories for each resource, the amount of resources used, and the usage time:

Resource	Product category	Resource usage amount	Usage time
L-Platform	Template	Total number of deployed L-Platforms	L-Platform deployed time
L-Server	- Virtual L-Server - Physical L-Server	Total number of deployed L-Servers	Deployment time of the L-Server
CPU	CPU	CPU number	Operating time of the L-Server
	CPU clock	Use one of the following: - CPU performance (GHz) - CPU reserved performance (GHz) (*1)	
Memory	Memory capacity	Use one of the following: - Memory (GB) - Memory reserved (GB) (*1)	Operating time of the L-Server
Extension disk	Data disk capacity	Disk size (GB)	Disk deployment time

*1: This is the default value when overcommit is enabled on the virtual L-Server. These can be changed by changing the settings.



Point

Usage Charges for physical L-Servers.

The calculation of Usage Charges for the CPU, CPU clock, and memory capacity of the physical L-Server are calculated using the values input into the **L-Platform Management** window (input value). Also, a server that is close to the input value in the specified server pool will be deployed as the physical L-Server. For that reason, if charging for the physical L-Server, perform operations such as preparing multiple physical L-Servers that are close to the input value in the server pool.

CPU usage charges


The usage charge for the CPU is calculated based on the CPU and the CPU clock. The calculation formula is as follows:

$(\text{CPU unit price} / 60 (\text{minutes}) + \text{CPU clock unit price} / 60 (\text{minutes}) \times \text{CPU clock count} / 0.1) \times \text{CPU count} \times \text{usage time}$

15.4.5 Example of Usage charge Calculation

Here we will describe an example of calculation, using an L-Platform with the configuration shown below.

Configuration



Charge information

The charge information is as follows:

Resource	Resource identifier	Unit codes	Unit price
template	TE_01	month	\$2.00
vm	IM_01	hour	\$0.10
cpu	/VMPool	hour	\$0.001
cpu_clock	/VMPool	hour	\$0.002
memory	/VMPool	hour	\$0.001
disk	/StoragePool	hour	\$0.001

Operation

Operations on the L-Platform are as follows:

Date/time	Operation
2012-07-01 10:10:00	Deploy L-Platform 1
2012-07-01 10:11:00	Start L-Server
2012-07-02 18:10:00	Stop L-Server 1
2012-07-02 18:11:00	Add L-Server 2
2012-07-02 18:12:00	Start L-Server
2012-07-02 18:13:00	Start L-Server 2
2012-07-05 18:00:00	Stop L-Server 1 and L-Server 2
2012-07-05 18:01:00	Terminate L-Platform 1

Usage time

The usage time for is resource is as follows:

Resource	Deployed time	Running time
L-Platform1	128 hours 51 minutes (7731 minutes)	-
L-Server1	128 hours 51 minutes (7731 minutes)	128 hours 51 minutes (7731 minutes)
L-Server2	71 hours 50 minutes (4310 minutes)	71 hours 48 minutes (4308 minutes)
Extension disk 1	128 hours 51 minutes (7731 minutes)	-
Extension disk 2	71 hours 50 minutes (4310 minutes)	-

Usage charges

The usage charges for L-Platform 1 are as follows:

L-Platform usage charges		Template + L-Server1+L-Server2=Usage charges				
		\$2.00	\$118.94	\$136.52	\$257.46	
Template						
Template ID	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
TE.01	\$2.00	/month	1			\$2.00
L-Server1						
Image name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
IM.01	\$0.10	/hour	1		7731	\$12.89
CPU						
VM pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
CPU	\$0.001	/hour			6227	\$0.10
CPU clock	\$0.002	/0.1 GHz hour	1	100	6227	\$20.76
Usage charge per 1uCPU						\$20.86
Usage charge for CPU						\$20.86
Memory						
VM pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
/vMPool	\$0.001	/0.1 GB hour	2	20	6227	\$20.76
Extension disk1						
Storage pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
/StoragePool	\$0.001	/0.1 GB hour	5	50	7731	\$64.43
Monthly usage charge for L-Server1						\$118.94
L-Server2						
Image name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
IM.01	\$0.10	/hour	1		4310	\$71.8
CPU						
VM pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
CPU	\$0.001	/hour			4308	\$0.07
CPU clock	\$0.002	/0.1 GHz hour	2	20	4308	\$28.72
Usage charge per 1CPU						\$28.79
Usage charge for CPU						\$28.79
Memory						
VM pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
/vMPool	\$0.001	/0.1 GB hour	4	40	4308	\$28.72
Extension disk2						
Storage pool name	Unit price	Unit	Usage amount	Unit	Usage time	Monthly charge
/StoragePool	\$0.001	/0.1 GB hour	1	10	4310	\$71.83
Monthly usage charge for L-Server2						\$136.52



Fractions in usage charges

When the calculations of usage charge produce a figure that includes fractions less than the lowest unit in the currency, the remainder is rounded off.

L-Platform transfers

When an L-Platform is moved, the usage charges for resources charged by amount are divided between the departure tenant and destination tenant, according to the amounts used. When resources are charged by a fixed amount, the departure tenant is billed.

15.4.6 Sending Usage charges

The usage charges for the previous month confirmed the day after the cut-off date are attached as a usage charge file and sent to the email address. The usage charge file is a zip file combining the usage charge list file and the usage charge detail file.

The detail of this file is as follows:

File	File name	Description
Usage charges file	YYYYMM_tenant_name[_date_deleted].zip	File of usage charges for the tenant in zip format. YYYYMM is the date of the cut-off. "_date_deleted" is added when the tenant has already been deleted.
Usage charge list file	YYYYMM_tenant_name[_date_deleted].csv	File in CSV format showing the tenant's previous month's usage charges plus the usage charges by the L-Platform they own. YYYYMM is the date of the cut-off. "_date_deleted" is added when the tenant has already been deleted.
Usage charge detail file	YYYYMM_L-PlatformID.csv	File in CSV format showing the breakdown of usage charges for each L-Platform. YYYYMM is the date of the cut-off.



Size of the usage charges file

The size of usage charge files depends on the number of L-Platforms deployed for the tenant and the configuration used. For example, if 200 L-Platforms including two L-Servers are deployed, the file size is about 160 Kb.

15.4.6.1 Usage Charge List File

The usage charge list file is a file in CSV format showing the tenant's previous month's usage charges plus the usage charges by the L-Platform they own.

The output items are as follows:

Item	Description
TenantName	This is the tenant name. (*1)
TenantDisplayName	This is the display name. Note (*1)
TenantDeletedDate	This is the date and time the tenant was deleted. Output only if the tenant has already been deleted. Empty string is output if this has not been deleted. Format: YYYY-MM-DD HH:mm:ss.SSS (*1) Example:2013-03-31 23:59:59.999
Date	This is the cut-off date. Format:YYYY-MM (*1) Example:2013-03
TotalChargeAmount	Total value of the usage charge for the tenant. The amounts are values, so they are not enclosed with double-quotes (""). Format:ZZZZZZZZZZ9 (*2) Example:800
FileVersion	This is the version of the file. Fixed as 1.0.
LplatformId	This is the L-Platform ID. (*1)
LplatformName	This is the L-Platform name. (*1)
LplatformDeletedDate	Date that the L-Platform was returned. Output only if the L-Platform has already been returned. Empty string is output if this has not been returned.

Item	Description
	Format:YYYY-MM-DD HH:mm:ss.SSS (*1) Example:2013-03-31 23:59:59.999
ChargeAmount	The amount of usage charges for each L-Platform. The amounts are values, so they are not enclosed with double-quotes (""). Format:ZZZZZZZZZZ9 (*2) Example:1000

*1: Data enclosed with double-quotes ("").

*2: The amount is shown only, without the currency symbol.

The following is an example of file output:

```
#TenantName,TenantDisplayName,TenantDeletedDate,Date,TotalChargeAmount,FileVersion,LplatformId,LplatformName,LplatformDeletedDate,ChargeAmount
"TNT00001","tenant01","2012-02-01 09:30:40.001","2012-02",1800,"1.0","","","",
"","","","","","TNT00001-LPlatform01","template-TNT00001-LPlatform01","2012-01-10 09:30:40.001",
1000
"","","","","","TNT00001-LPlatform02","template-TNT00001-LPlatform02","","",800
```

15.4.6.2 Usage charge Detail File

The usage charge detail file is a file in CSV format showing the breakdown of usage charges for each L-Platform.

The output items are as follows:

Item	Description
TenantName	This is the tenant name. (*1)
TenantDisplayName	This is the display name. Note (*1)
TenantDeletedDate	This is the date and time the tenant was deleted. Output only if the tenant has already been deleted. Empty string is output if this has not been deleted. Format: YYYY-MM-DD HH:mm:ss.SSS (*1) Example:2013-03-31 23:59:59.999
LplatformId	This is the L-Platform ID. (*1)
LplatformName	This is the L-Platform name. (*1)
LplatformDeletedDate	Date that the L-Platform was returned. Output only if the L-Platform has already been returned. Empty string is output if this has not been returned. Format:YYYY-MM-DD HH:mm:ss.SSS (*1) Example:2013-03-31 23:59:59.999
Date	This is the cut-off date. Format:YYYY-MM (*1) Example:2013-03
ChargeAmount	The amount of usage charges for each L-Platform. The amounts are values, so they are not enclosed with double-quotes (""). Format:ZZZZZZZZZZ9 (*1) Example:1000
FileVersion	This is the version of the file. Fixed as 1.0.
ItemColumn1	This is a breakdown (item 1). The template name, virtual L-Server name, or physical L-Server name is output.

Item	Description
ItemColumn2	This is a breakdown (item 2). The category of the resource. Empty string is output if this is for an L-Platform template, virtual L-Server, or physical L-Server.
ItemColumn3	This is a breakdown (item 3). The image name or resource identifier is output. (*1)
ItemColumn4	This is a breakdown (item 4). This is the unit corresponding to the unit price. A hyphen (-) is output if this is for an L-Platform template, virtual L-Server, or physical L-Server.
UnitPrice	This is the unit price. (*1)
UsedFrequency	This is the usage time. (*1)
ItemAmount	This is a breakdown of the amounts. Format:ZZZZZZZZZZ9 (*2) Example:50

*1: Data enclosed with double-quotes ("").

*2: The amount is shown only, without the currency symbol.

The following is an example of file output:

```
#TenantName,TenantDisplayName,TenantDeletedDate,LplatformId,LplatformName,LplatformDeleteDate,Date,Ch
hargeAmount,FileVersion,ItemColumn1,ItemColumn2,ItemColumn3,ItemColumn4,UnitPrice,UsedFrequency,Item
Amount
"TNT00001","tenant01","2012-02-01 09:30:40.001","TNT00002-LPlatform01","template-TNT00002-
LPlatform01","2012-02-01 09:30:40.001","2012-02",1000,"1.0","","","","","","",
"","","","","","","","","","","Template","","TE_01","-","\200.0000/month","1 month",200
"","","","","","","","","","Virtual server(serverId001)","","image001","-","\1.2000/h","5h",6
"","","","","","","","","","Virtual server(serverId001)","CPU","/VMPool","1core,
10GHz","\1.6667,\0.5560/h","18h",26
"","","","","","","","","","Virtual server(serverId001)","Memory capacity","/VMPool","10GB","\20.0000/
h","18h",360
"","","","","","","","","","Virtual server(serverId001)","Disk Capacity","/StragePool","10GB","\8.7500/
h","18h",158
"","","","","","","","","","Virtual server(serverId001)","Disk Capacity","/
StragePool2","10GB","\9.0000/h","2h",18
"","","","","","","","","","Virtual server(serverId001)","Disk Capacity","/
StragePool3","10GB","\9.7230/h","6h",59
"","","","","","","","","","Virtual server(serverId003)","","image003","-","\1.2000/h","5h",6
"","","","","","","","","","Virtual server(serverId003)","CPU","/VMPool","1core,
10GHz","\1.6667,\0.5560/h","18h",26
"","","","","","","","","","Virtual server(serverId003)","Memory capacity","/VMPool","10GB","\20.0000/
h","18h",360
"","","","","","","","","","Virtual server(serverId003)","Disk Capacity","/StragePool","10GB","\8.7500/
h","18h",158
"","","","","","","","","","Virtual server(serverId003)","Disk Capacity","/
StragePool2","10GB","\9.0000/h","2h",18
"","","","","","","","","","Virtual server(serverId003)","Disk Capacity","/
StragePool3","10GB","\9.7230/h","6h",59
"","","","","","","","","","Physical server(serverId002)","","image002","-","\1.2000/h","5h",6
"","","","","","","","","","Physical server(serverId002)","CPU","/ServerPool","1core,
10GHz","\1.6667,\0.5560/h","18h",26
"","","","","","","","","","Physical server(serverId002)","Memory capacity","/
ServerPool","10GB","\20.0000/h","18h",360
"","","","","","","","","","Physical server(serverId002)","Disk Capacity","/
StragePool","10GB","\8.7500/h","18h",158
"","","","","","","","","","Physical server(serverId002)","Disk Capacity","/
StragePool2","10GB","\9.0000/h","2h",18
"","","","","","","","","","Physical server(serverId002)","Disk Capacity","/
StragePool3","10GB","\9.7230/h","6h",59
```

Chapter 16 Monitoring Logs

This chapter explains how to monitor logs.

16.1 Operation Logs

This section explains the operation logs of Resource Orchestrator.



Note

- Operation logs should be used by only infrastructure administrators or administrators, as all user operations of Resource Orchestrator can be viewed.
- Displaying resource names arranged in hierarchies is not supported.

16.1.1 Overview

Provides the functions to record user operations as operation logs in Resource Orchestrator.

Using this function, administrators can monitor the following information:

- Time events were recorded in the operation logs
- User ID
- User group name
- IP address
- Status
- Resource name
- Operations

The operation logs are output in the following formats:

Date	User	Group	IP	Progress	Resource	Event
-----	-----	-----	-----	-----	-----	-----

Element Name	Description	Remarks
Date	Time events were recorded in the operation logs	The time events recorded in the operation logs are output in the local time. If daylight savings time (a regulation of time in summer) is set on the operating system, the time events are output in daylight savings time. Time events are output in the following format: YYYY-MM-DD HH:MM:SS.XXX
User	User ID	The user ID of the logged in user is output. When a special administrator uses the command, a hyphen ("-") is output.
Group	User group name	The name of the user group name the logged in user belongs to is output. When the logged in user does not belong to a user group, a hyphen ("-") is output.
IP	IP address	The IP addresses of the connected clients are output.
Progress	Status	Starting and stopping of operations, and errors are output. The following statuses are output: <ul style="list-style-type: none">- Start of operations

Element Name	Description	Remarks
		Starting(<i>Operation_identifier</i>) - End of operations Completed(<i>Operation_identifier</i>) - Errors during operations Error(<i>Operation_identifier</i>)
Resource	Resource name	A resource name and a resource identifier are output in the following format: - "Resource identifier(<i>Resource_name</i>)"
Event	Operations	The parameters received by the manager are output. For the information that will be output, refer to " 16.1.4 Scope of Operations Recorded in Operation Logs ".

Note

- A hyphen ("-") may be output for an operation identifier.
- For operations involving multiple resources, the same resource name as the one displayed in the Recent Operations on the ROR console and the event log is output in "Resource".

Example

Output the latest 1 day's worth of data.

For details on how to operate operation logs, refer to "5.13 rcxadm logctl", and for the information to be output, refer to "[16.1.4 Scope of Operations Recorded in Operation Logs](#)" in the "Reference Guide (Command/XML) CE".

```
>rcxadm logctl list -latest -duration 1D <RETURN>
```

Date	User	Group	IP	Progress	Resource	Event
2011-03-10 21:15:00.390	-	-	10.20.30.53	Starting(BX620-1_21)	BX620-1_473(snap)	
l_servers create						
2011-03-10 21:15:06.250	-	-	10.20.30.53	Error(BX620-1_21)	BX620-1_473(snap)	
l_servers create						
2011-03-10 21:26:05.953	-	-	10.20.30.73	Starting(BX620-1_25)	BX620-1_510(snap)	
l_servers create						
2011-03-10 21:29:21.150	-	-	10.20.30.73	Completed(BX620-1_25)	BX620-1_510(snap)	
l_servers create						
2011-03-10 23:15:39.750	admin	-	10.20.30.53	Starting(BX620-1_35)	BX620-1_510(snap)	
server_images snapshot						
2011-03-10 23:15:46.781	admin	-	10.20.30.53	Completed(BX620-1_35)	BX620-1_510(snap)	
server_images snapshot						
2011-03-10 23:16:23.625	admin	-	10.20.30.53	Starting(BX620-1_36)	BX620-1_510(snap)	
server_images restore						
2011-03-10 23:16:28.484	admin	-	10.20.30.53	Completed(BX620-1_36)	BX620-1_510(snap)	
server_images restore						
2011-03-10 23:17:00.859	admin	-	10.20.30.53	Starting(BX620-1_37)	BX620-1_510(snap)	
server_images destroy						
2011-03-10 23:17:04.718	admin	-	10.20.30.53	Completed(BX620-1_37)	BX620-1_510(snap)	
server_images destroy						
2011-03-10 23:19:25.734	admin	-	10.20.30.53	Starting(BX620-1_38)	BX620-1_744(image_test)	
server_images create						
2011-03-10 23:27:29.640	admin	-	10.20.30.53	Completed(BX620-1_38)	BX620-1_744(image_test)	
server_images create						

2011-03-10 23:42:37.171	admin	-	10.20.30.53	Starting(BX620-1_40)	BX620-1_578(image_test)
server_images destroy					
2011-03-10 23:42:47.460	admin	-	10.20.30.53	Completed(BX620-1_40)	BX620-1_578(image_test)
server_images destroy					
2011-03-10 23:51:06.620	userA	groupA	127.0.0.1	Starting(BX620-1_41)	BX620-1_806(LS_RT_A001)
l_servers create					
2011-03-10 23:53:06.437	userA	groupA	127.0.0.1	Completed(BX620-1_41)	BX620-1_806(LS_RT_A001)
l_servers create					
2011-03-10 23:53:39.265	userA	groupA	127.0.0.1	Starting(BX620-1_42)	BX620-1_806(LS_RT_A001)
l_servers start					
2011-03-10 23:54:26.640	userA	groupA	127.0.0.1	Completed(BX620-1_42)	BX620-1_806(LS_RT_A001)
l_servers start					
2011-03-10 23:54:45.531	userA	groupA	127.0.0.1	Starting(BX620-1_43)	BX620-1_806(LS_RT_A001)
l_servers restart					
2011-03-10 23:55:26.859	userA	groupA	127.0.0.1	Completed(BX620-1_43)	BX620-1_806(LS_RT_A001)
l_servers restart					
2011-03-10 23:55:48.953	userA	groupA	127.0.0.1	Starting(BX620-1_44)	BX620-1_806(LS_RT_A001)
l_servers stop					
2011-03-10 23:56:26.390	userA	groupA	127.0.0.1	Completed(BX620-1_44)	BX620-1_806(LS_RT_A001)
l_servers stop					
2011-03-10 23:57:11.968	userA	groupA	127.0.0.1	Starting(BX620-1_46)	BX620-1_806(LS_RT_A001)
l_servers attach					
2011-03-10 23:58:21.359	userA	groupA	127.0.0.1	Completed(BX620-1_46)	BX620-1_806(LS_RT_A001)
l_servers attach					
2011-03-10 23:58:35.620	userA	groupA	127.0.0.1	Starting(BX620-1_47)	BX620-1_806(LS_RT_A001)
l_servers detach					
2011-03-10 23:59:23.343	userA	groupA	127.0.0.1	Completed(BX620-1_47)	BX620-1_806(LS_RT_A001)
l_servers detach					
2011-03-10 23:59:40.265	userA	groupA	127.0.0.1	Starting(BX620-1_48)	BX620-1_806(LS_RT_A001)
l_servers migrate					
2011-03-11 00:00:53.984	userA	groupA	127.0.0.1	Completed(BX620-1_48)	BX620-1_806(LS_RT_A001)
l_servers migrate					
2011-03-11 00:01:09.296	userA	groupA	127.0.0.1	Starting(BX620-1_50)	BX620-1_806(LS_RT_A001)
l_servers update					
2011-03-11 00:02:58.125	userA	groupA	127.0.0.1	Completed(BX620-1_50)	BX620-1_806(LS_RT_A001)
l_servers update					
2011-03-11 00:04:42.640	userA	groupA	127.0.0.1	Starting(BX620-1_57)	BX620-1_806(LS_RT_A001)
l_servers destroy					
2011-03-11 00:05:22.921	userA	groupA	127.0.0.1	Completed(BX620-1_57)	BX620-1_806(LS_RT_A001)
l_servers destroy					
2011-03-11 00:35:44.250	userA	groupA	127.0.0.1	Starting(BX620-1_117)	BX620-1_954(LS_RT_A001)
folders move_resource					
2011-03-11 00:35:44.625	userA	groupA	127.0.0.1	Completed(BX620-1_117)	BX620-1_954(LS_RT_A001)
folders move_resource					
2011-03-11 01:04:34.880	admin	-	10.20.30.53	Starting(BX620-1_570)	BX620-1_2193(master-52)
l_servers convert					
2011-03-11 01:04:36.650	admin	-	10.20.30.53	Completed(BX620-1_570)	BX620-1_2193(master-52)
l_servers convert					
2011-03-11 01:05:05.568	admin	-	10.20.30.53	Starting(BX620-1_571)	BX620-1_2193(master-52)
l_servers revert					
2011-03-11 01:05:06.451	admin	-	10.20.30.53	Completed(BX620-1_571)	BX620-1_2193(master-52)
l_servers revert					

 Note

The starting point (Starting) of recording for each operation is when the operation is displayed in the Recent Operations on the ROR console.

16.1.2 Usage Method

This section explains the methods for configuring and operating operation logs.

Perform the following procedure:

1. Disk space estimation

Infrastructure administrator (infra_admin) estimates the disk size to use for storing operation logs.

Estimate the amount of disk space using the following formula, and then decide the number of days to retain operation logs.

$$\{(Number_of_operations_of_the_resource_in_1_day) * (Number_of_target_resources) * 1(KB)\} * (retention_period)$$

Example

Disk space when estimating that the retention period is 180 days (by default), the target resource is operated 4 times, and the number of target resources is 256

Retention period	Necessary Disk Space	Formula
180 days worth	Approx. 185 MB	$4 * 256 * 1 * 180 = 184320$ (KB)

2. Check the settings in the [Date and Time properties] dialog of the operating system

Check whether the following tabs of the OS are configured correctly. If the settings are incorrect, set them correctly.

- [Date and Time] tab
- [Time Zone] tab
- [Internet Time(or the Network Time Protocol)] tab

3. Configure the retention period of operation logs

Execute the `rcxadm logctl set` command, to configure the retention period for operation logs.

For details on the `rcxadm logctl set` command, refer to "5.13 `rcxadm logctl`" in the "Reference Guide (Command/XML) CE".

4. Start recording of the operation log

Execute the `rcxadm logctl start` command to start recording the operation log.

When the `rcxadm logctl start` command is executed, the operation logs will be recorded for the configured retention period from the date recording of operation logs is started.

Days when no events occur, or days when recording is not possible due to the manager being stopped are not counted as dates for recording.

Note

- When the settings of the OS [Date and Time Properties] dialog have been changed after starting the recording of operation logs
It may not be possible to correctly display or delete the operation logs.
- When changing the settings of the OS [Date and Time Properties] dialog after starting the recording of operation logs
Refer to "[16.1.3 Retention](#)".
- When a Cloud Edition license has been registered
When starting the manager, recording of operation logs is started automatically.

16.1.3 Retention

This section explains the retention of operation logs.

- Periodic deletion

Due to extended periods of operation or modification of retention periods, operation logs which have exceeded a certain retention period are periodically deleted.

The timing of deletion (based on retention period checks) is set to take place as the first operation after the date changes.

Note

- The recording period is the retention period + 1. After periodic deletion is performed, the recording period will be equal to the retention period.
- Periodic deletion is executed when the next recording is started (the first recording after the date changes), and operation logs will be deleted in chronological order.

- Deletion

Users can delete unnecessary operation logs by defining a retention period.

- Backup and Restore

Use the following procedure for backup and restoration of operation logs.

- Backup

1. Confirm the "retention folder" for the operation logs.
2. Stop recording operation logs.
3. Back up the "retention folder" confirmed in 1.
4. Start recording operation logs.

- Restore

1. Confirm the "retention folder" for the operation logs.
2. Stop recording operation logs.
3. Restore the backed-up folder into the "retention folder" confirmed in 1.
4. Start recording operation logs.

- Modification of the settings in the [Date and Time properties] dialog after starting the recording of operation logs

Use the following procedure to make changes.

1. Stop recording operation logs.
2. Display the operation logs and back up the necessary portions from the records.
3. Confirm the "retention folder" for the operation logs.
4. Empty the "retention folder" by moving all files in the "retention folder" checked in 3. to a new location.
5. Modify the settings in the [Date and Time properties] dialog.
6. Start recording operation logs.

For details on operations for operation logs, refer to "5.13 rcxadm logctl" in the "Reference Guide (Command/XML) CE".

Note

- Once recording operations are stopped, user operations are not recorded until the recording of logs is started again.

- Performing this procedure resets the recording period of operation logs to 0.

16.1.4 Scope of Operations Recorded in Operation Logs

The scope of operations recorded in operation logs and the character strings displayed in the Event column are as indicated below.

Table 16.1 Scope of Operations

Resource Type	Action	Strings Displayed in the Event Column
L-Server	Creation	l_servers create
	Deletion	l_servers destroy
	Modification	l_servers update
	Powering on	l_servers start
	Powering off	l_servers stop
	Restarting	l_servers restart
	Disk addition	l_servers attach
	Disk detachment	l_servers detach
	Folder migration	folders move resource
	Migration	l_servers migrate
	Physical L-Server configuration	l_servers set_attrs
	Transmission of network information to physical L-Servers	l_servers setup
	Conversion	l_servers convert
	Reversion	l_servers revert
Image	Creation	server_images create
	Deletion	server_images destroy
	Restore	server_images restore
	Snapshot collection	server_images snapshot
L-Platform	Creation	l_platforms create
	Deletion	l_platforms destroy
	Modification	l_platforms update
Tenant	Create	tenants create
	Deletion	tenants destroy
	Modification	tenants update
Resource Folders	Creation	folders create
	Deletion	folders destroy
	Modification	folders update

16.2 Audit Logs

This section explains audit logs.

By looking up audit logs, it is possible to find out *who* performed *what* operation *when*.

16.2.1 Configuration Management Audit Log

This section explains the configuration management audit log.

The file name, file size, and number of generations of the audit log are shown below:

Log name	Description	File size	Number of generations
vsys_audit_log	Audit logs are output to this log.	10 MB	10 generations (*1)

*1: If the number of saved generations exceeds 10 generations, old generations will be deleted, starting with the oldest generation.

The file size and the number of generations to be saved can be changed. Refer to "[Procedure for changing the size of the file](#)" and "[Procedure for changing the number of generations to be saved](#)" for details.

With default settings, audit logs will be held for approximately 50 days if 10 people use this product for approximately one hour per day per person. If necessary, back up audit logs at appropriate intervals according to the usage frequency. The names of the files to be backed up are shown below:

vsys_audit_log.[n] (where "n" is the generation number)
 Example: To back up three generations' worth of files, the names of the files to be backed up are as follows:
 - vsys_audit_log.1
 - vsys_audit_log.2
 - vsys_audit_log.3

Output Destination

The log output destinations are shown below:

[Windows Manager]

Output folder	Output destination file
<i>Installation_folder</i> \RCXCFMG\logs	vsys_audit_log.[n] (n is the number of generations)

[Linux Manager]

Output folder	Output destination file
/var/opt/FJSVcfmg/logs	vsys_audit_log.[n] (n is the number of generations)

Output format

Audit logs are CSV files where the following items are output in the following order:

Output format
<date/time when the operation was performed>,<user ID>,<organization ID>,<operation ID>,<parameters>,<operation result>

Item	Description
date/time when the operation was performed	YYYY-MM-DD HH:MM:SS.sss (local time).
user ID	The user ID of the user that executed the operation.
organization ID	The organization ID of the user that executed the operation.
operation type	A string indicating the content of the operation. (*1)
parameters	The parameters specified by the request.

Item	Description
operation result	"SUCCESS" if the operation was successful and "FAILURE" if the operation failed.

*1: The operation types are as follows:

Operation type	Description
VSYS#deploy	Deploying an L-Platform.
VSYS#update	Reconfiguring an L-Platform.
VSYS#getList	Obtaining a list of L-Platforms.
VSYS#getDetail	Obtaining detailed information for an L-Platform.
VSYS#release	Returning all L-Platforms as a batch.
VSYS#lock	Locking an L-Platform.
VSYS#unlock	Unlocking an L-Platform.
VServer#create	Adding a server.
VServer#search	Obtaining server information.
VServer#stop	Stopping a server.
VServer#start	Starting a server.
VServer#release	Returning a server.
VServer#attach	Adding an expansion disk.
VServer#detach	Deleting an expansion disk.
VServer#changeSpec	Changing server performance.
VServer#backup	Creating a snapshot.
VServer#restore	Restoring a server.
VServer#removeBackup	Deleting a snapshot.
VServer#getBackupList	Obtaining a list of snapshots.
VServer#cancelError	Releasing the error status of snapshots or restorations.
VServer#addPatch	Registering patch information.
VServer#deletePatch	Deleting patch information.
VServer#getInitPW	Obtaining the initial password for a server.
VServer#cloning	Collecting a cloning image from a deployed server.
Event#notify	Notifying events that occurred on a server. With the current version, changes to the power status and migration events are notified.
EventLog#getList	Obtaining a list of event logs.
VSYS#setLoginDate	Updating the date/time when the user logged in to L-Platform Manager View.
VSYS#getLoginDate	Obtaining the date/time when the user logged in to the L-Platform Manager View.
VSYS#setUndeploy	Changing the status of an L-Platform, server or disk to "undeployed".
VSYS#flowDeploy	Deploying an L-Platform. (For flows: no operation after authorization.)
VSYS#flowEnableDeploy	Deploying an L-Platform. (For flows: operation to perform after authorization.)
VSYS#flowUpdate	Reconfiguring an L-Platform. (For flows: no operation after authorization.)
VSYS#flowEnableUpdate	Reconfiguring an L-Platform. (For flows: operation to perform after authorization.)
VSYS#flowRejectApplication	Rejecting deployment application.
VSYS#flowForward	Applying to deploy an L-Platform or change a configuration.

Operation type	Description
VSYS#flowError	Executing post-processing when an error has occurred with an application flow for deploying an L-Platform or changing a configuration.
VSYS#flowCancel	Canceling the application to deploy an L-Platform or change a configuration.
VSYS#flowSaveCancel	Canceling the application to deploy an L-Platform or change a configuration.
VSYS#flowCancelRetry	Canceling the flow for saving a configuration and then making another application.
VSYS#flowReleaseApplication	Applying to return an L-Platform.
VSYS#flowRelease	Returning all L-Platforms as a batch. (For flows: no operation after authorization.)
VSYS#flowEnableRelease	Returning all L-Platforms as a batch. (For flows: operation to perform after authorization.)
VSYS#flowReleaseForward	Setting the status of a return application to "forwarding complete".
VSYS#changeOrg	Changing a user ID or organization ID for an L-Platform.
VSYS#recoverSystem	Recovering an L-Platform.
VSYS#recoverServer	Recovering a server.
VSYS#recoverDisk	Recovering a disk.
VSYS#setRecoverInfo	Recovering a resource ID or disk number.
VSYS#setChangeInfo	Recovering an L-Platform name, server name, or server specification.
VSYS#setServerStatus	Recovering the status of a server.
Parameters#set	Registering or updating parameter information.
Parameters#getList	Obtaining a list of parameter information.
Parameters#getDetail	Obtaining detailed parameter information.
Parameters#delete	Deleting parameter information.
Softwares#create	Registering software information.
Softwares#getList	Obtaining a list of software.
Softwares#getDetail	Obtaining detailed software information.
Softwares#delete	Deleting software information.
Images#getList	Obtaining a list of images registered.
Images#register	Registering image information with this product.
Images#unregister	Deregistering image information from this product.
Images#update	Updating image information.
Images#search	Searching image information.
Images#getDetail	Obtaining detailed image information.
Images#getServerType	Obtaining a list of L-Server Templates.
Network#getList	Obtaining a list of networks.
Network#addCategory	Registering a network resource type.
Network#deleteCategory	Deleting a network resource type.
Network#getCategoryList	Obtaining a list of network types.
Templates#importPublic	Registering template information.
Templates#search	Searching an L-Platform template.
Templates#getDetail	Obtaining detailed L-Platform template information.
Templates#changeShow	Changing the settings as to whether L-Platform templates can be displayed.

Operation type	Description
Templates#deletePublic	Deleting L-Platform templates.
DeployMaster#getTemplate	Obtaining a deployment master from an L-Platform template.
DeployMaster#save	Saving configuration information.
DeployMaster#getSaveList	Obtaining a list of configuration information.
DeployMaster#getDetail	Obtaining detailed configuration information.
DeployMaster#delete	Deleting configuration information.
DeployMaster#setStatus	Setting the status of configuration information.
VSYS#getPoolList	Obtaining a list of resource pools for ServerView Resource Orchestrator.

Procedure for changing output destination

Use the following procedure to change the audit log output destination.

1. Rewrite the settings file.

The following table shows the settings file and the location to change:

[Windows Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	<i>Installation_folder</i> \RCXCFMG\config\vsys_log4j.xml	<param name="File" value="C:\ProgramData\Fujitsu\SystemwalkerCF-MG\logs\vsys_audit_log" />

[Linux Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	/etc/opt/FJSVcfmg/config/vsys_log4j.xml	<param name="File" value="/var/opt/FJSVcfmg/logs/vsys_audit_log" />

2. Restart the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

Procedure for changing the size of the file

Use the following procedure to change the audit log file size.

1. Rewrite the settings file.

The location to change is shown below:

[Windows Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	<i>Installation_folder</i> \RCXCFMG\config\vsys_log4j.xml	Change the underlined part of the <param name="MaxFileSize" value="10MB" /> element under the <appender name="auditfileout" class="org.apache.log4j.RollingFileAppender"> element to the desired value. Example: value="100MB" (to change the size of the audit log file to 100 MB)

[Linux Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	/etc/opt/FJSVcfmg/config/vsys_log4j.xml	Change the underlined part of the <param name="MaxFileSize" value="10MB" /> element under the <appender name="auditfileout" class="org.apache.log4j.RollingFileAppender"> element to the desired value. Example: value="100MB" (to change the size of the audit log file to 100 MB)

- Restart the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

Procedure for changing the number of generations to be saved

Use the following procedure to change the number of audit log generations to be saved.

- Rewrite the settings file.

The location to change is shown below:

[Windows Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	<i>Installation_folder</i> \RCXCFMG\config\vsys_log4j.xml	Change the underlined part of the <param name="MaxBackupIndex" value="9" /> element under the <appender name="auditfileout" class="org.apache.log4j.RollingFileAppender"> element to the desired value. Example: value="100" (to change the number of audit log generations to 100)

[Linux Manager]

Log name	Settings file	Location to change (one location)
vsys_audit_log	/etc/opt/FJSVcfmg/config/vsys_log4j.xml	Change the underlined part of the <param name="MaxBackupIndex" value="9" /> element under the <appender name="auditfileout" class="org.apache.log4j.RollingFileAppender"> element to the desired value. Example: value="100" (to change the number of audit log generations to 100)

- Restart the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to Restart the manager.

16.2.2 Audit Logs of Output by the Tenant Management, Accounting, Access Control and System Condition

This section explains audit logs of output by the tenant management, accounting, access control and system condition functions.



Point

- If L-Platform Management is operated, audit logs will be output to Configuration Manager. Refer to "16.2.1 Configuration Management Audit Log" for details.

- Audit logs relating to the registration, modification or deletion of infrastructure administrators, infrastructure operators, infrastructure monitors, administrators, operators and/or monitors can be checked in the OpenDS access log. The storage locations and file names of OpenDS access logs are as follows.

[Windows Manager]

```
OpenDS_Installation_folder\opends\logs\access
```

[Linux Manager]

```
/opt/fujitsu/ServerViewSuite/opends/logs/access
```

Refer to the OpenDS website for details on OpenDS access logs.

```
URL: https://docs.opends.org/2.2/page/DefAccessLog (As of February2012)
```

Output format

Audit logs are CSV files where the following items are output in the following order:

Output format
<i>operation date/time,user ID,tenant name,operation type,operation information,operation result</i>

Item	Description
<i>operation date/time</i>	The date/time when the operation was performed. The date/time is output using the following format: YYYY-MM-DD HH:MM:SS.sss (local time)
<i>user ID</i>	The user ID of the user that performed the operation.
<i>tenant name</i>	The tenant name of the user that executed the operation. If the operation is performed from tenant management GUI, the tenant name is fixed as "ctmgadm".
<i>operation type</i>	The type of the operation performed. Refer to " Operation types and operation information " for details.
<i>operation information</i>	Detailed information for the operation type. Refer to " Operation types and operation information " for details.
<i>operation result</i>	The result of the operation performed. One of the following values is output: SUCCESS: When the operation was successful FAILURE: When the operation failed

Output files

Audit logs are output to the following files:

Function	Output file
Tenant management (GUI operations from the ROR Console)	[Windows Manager] <i>Installation_folder\RCXCTMG\SecurityManagement\log\ctsec_audit_a.log</i> [Linux Manager] <i>/var/opt/FJSVctsec/log/ctsec_audit_a.log</i>
Tenant management (creating users from the ROR Console:	[Windows Manager] <i>Installation_folder\RCXCTMG\SecurityManagement\log\ctsec_audit_s.log</i>

Function	Output file
Provisional account registration method)	[Linux Manager] /var/opt/FJSVctsec/log/ctsec_audit_s.log
Accounting	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\Charging\log\ctchg_audit.log [Linux Manager] /var/opt/FJSVctchg/log/ctchg_audit.log
Accounting (GUI operations from the ROR Console)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\Charging\log\charging_audit.log [Linux Manager] /var/opt/FJSVctchg/log/charging_audit.log
Accounting (Published API operation)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\Charging\log\accounting_audit.log [Linux Manager] /var/opt/FJSVctchg/log/accounting_audit.log
Access Control	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\SecurityManagement\log\ctac_audit.log [Linux Manager] /var/opt/FJSVctsec/log/ctac_audit.log
System condition	[Windows Manager] <i>Installation_folder</i> \SWRBAM\CMDB\FJSVcmdbm\var\log\audit\uiGUI\cmdb_audit.log [Linux Manager] /opt/FJSVcmdbm/var/log/audit/uiGUI/cmdb_audit.log

Procedure for changing the file size and the number of generations held

By default, audit log files are rotated when they reach 10 MB.

To change the maximum size of audit log files or the maximum number of generations held, perform the following procedure:

1. Stop the manager.
Refer to "2.1 Starting and Stopping the Manager" for information on how to stop the manager.
2. Edit the appropriate items in the following definition files:
 - Definition files

Function	Definition file
Tenant management (GUI operations from the ROR Console)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditsecalog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditsecalog4j.xml
Tenant management (creating users from the ROR Console: Provisional account)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditsecslog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditsecslog4j.xml

Function	Definition file
registration method)	
Accounting	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditclog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditclog4j.xml
Accounting (GUI operations from the ROR Console)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditcguiolog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditcguiolog4j.xml
Accounting (Published API operation)	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditacntlog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditacntlog4j.xml
Access Control	[Windows Manager] <i>Installation_folder</i> \RCXCTMG\conf\auditaclog4j.xml [Linux Manager] /etc/opt/FJSVctmg/conf/auditaclog4j.xml
System condition	[Windows Manager] <i>Installation_folder</i> \SWRBAM\CMDB\FJSVcmdbm\CMDBConsole\WEB-INF\classes\log4j.properties [Linux Manager] /opt/FJSVcmdbm/CMDBConsole/WEB-INF/classes/log4j.properties

- Setting items

Setting item	Description
MaxFileSize	This item sets the maximum size of audit log files. The file size can be specified using a combination of an integer greater than 0 and a unit (KB, MB or GB). (*1), (*2) Example: <param name="MaxFileSize" value="500KB"/>
MaxBackupIndex	This item sets the maximum number of generations of the audit log file. An integer greater than 0 can be specified. (*1) Example: <param name="MaxBackupIndex" value="50"/>

*1: Do not specify decimal fractions. Also, do not leave a blank space.

*2: Do not specify a maximum file size that is larger than the size of the disk. Conversely, do not set values that are too small for the maximum file size, or else the logs will be overwritten frequently.

3. Start the manager.

Refer to "2.1 Starting and Stopping the Manager" for information on how to start the manager.

Operation types and operation information

The following table shows the operation types and operation information that are output to audit logs:

Function	Operation type	Content	Operation information (*1)
Tenant management (GUI	registUser	Notify user registration	"mail=""xxx@com""

Function	Operation type	Content	Operation information (*1)
operations from the ROR Console)	createUser	Create users	"userid="<user ID of the user created>"&mail="xxx@com"&lastname="<last name>"&firstname="<first name>"&auth="tenant_admin tenant_operator tenant_monitor tenant_user"&explanation="xxx"&corporatename="fujitsu"&emergencymail="yyy@com"&emergencytel="0000" (only if the infrastructure administrator performed or the tenant administrator performed by the direct registration method)
	deleteUser	Delete users	"userid="<user ID of the user deleted>"
	updateUser	Update user information	"userid="<user ID of the user updated>"&mail="xxx@com"&lastname="<last name>"&firstname="<first name>"&auth="infra_admin infra_operator administrator monitor operator tenant_admin tenant_operator tenant_monitor tenant_user"&explanation="xxx"&corporatename="fujitsu"&emergencymail="yyy@com"&emergencytel="0000"
	listUser	Get a list of user information	None.
	moveUser	Relocate users	"userid="<user ID of the user that has been relocated>"&oldorgid="<tenant name of the original tenant>"&neworgid="tenant name of the tenant to which the user has been relocated"
	updatePassword	Update passwords	"userid="<user ID of the user whose password has been updated>"
	createOrg (*2) (*3)	Create an tenant	- With no calculation of Usage Charges "orgid="<tenant name of the tenant that has been created>"&orgname="<tenant name>"&mail="xxx@com"&globalpool="<global pool that has been set>" - With calculation of Usage Charges "orgid="<tenant name of the tenant that has been created>"&orgname="<tenant name>"&mail="xxx@com"&globalpool="<global pool that has been set>"&cutoffdate="<Cut off date>"&accountingmail="<email address where usage charges are sent>"
	deleteOrg (*3)	Delete tenants	"orgid="<tenant name of the tenant that has been deleted>"
	updateOrg (*2) (*3)	Update tenant information	- With no calculation of Usage Charges "orgid="<tenant name of the tenant that has been updated>"&orgname="<tenant name>"&mail="xxx@com"&globalpool="<global pool that has been set>" - With calculation of Usage Charges "orgid="<tenant name of the tenant that has been created>"&orgname="<tenant name>"&mail="xxx@com"&globalpool="<global pool that has been set>"&cutoffdate="<Cut off date>"

Function	Operation type	Content	Operation information (*1)
			<i>date>""&accountingmail=""<email address where usage charges are sent>""</i>
	listOrg	Get a list of tenant information	None.
Tenant management (creating users from the ROR Console: Provisional account registration method)	createUser	Create users	"userid=""<user ID of the user created>""&mail=""xxx@com""&lastname=""<last name>""&firstname=""<first name>""&auth=""tenant_user""&explanation=""xxx""&corporatename=""fujitsu""&emergencymail=""yyy@com""&emergencytel=""0000""
Accounting	updatePMaster	Update product master	None.
	listPMaster	Get a list of product master	None.
	updateMlogSch	Update periodic log schedule settings	"use=""yes no""&time=""<time of output of periodic log>""&type=""<frequency of output of periodic log>""&day=""<day of output of periodic log>""
	listMlogSch	Get a list of periodic log schedule settings	"use=""yes no""&time=""<time of output of periodic log>""&type=""<frequency of output of periodic log>""&day=""<day of output of periodic log>""
	listMeteringlog	Get a list of metering logs	"start=""<start date of the acquisition period>""&end=""<end date of the acquisition period>""&type=""event period""
	deleteMlog	Delete metering logs	"retention=""<log entry retention period>""
Accounting (GUI operations from the ROR Console)	listLplatformCharge	Get a list of usage charge for each L-Platform	None.
	getDetailCharge	Get a breakdown of L-Platform usage charges	None.
	listTenantCharge	Get a list of usage charge for each tenant	None.
	listLplatformChargeByTenant	Get a list of usage charge for each L-Platform under the specified tenant	None.
	downloadFile	File download	"target=""LplatformChargeList DetailCharge TenantChargeList LplatformChargeListByTenant""
Accounting (Published API operation)	getResourceUsage	Get resource usage	None.
	getUsagePoint	Get usage frequency	None.

Function	Operation type	Content	Operation information (*1)
	registerUsagePoint	Register usage frequency (*4)	"date="" <i><date of data registered></i> ""(*5)""&id="" <i><L-Platform ID></i> ""&name="" <i><L-Platform name></i> ""&tenantname="" <i><tenant name of managed tenant></i> ""&tenantdeletedate="" <i><date when managed tenant was deleted></i> ""(*6)""
	getDailyCharge	Get daily usage charges	None.
	registerDailyCharge	Register daily usage charges (*4)	"date="" <i><date of data registered></i> ""&id="" <i>L-Platform ID</i> ""&name="" <i><L-Platform name></i> ""&tenantname="" <i><tenant name of managed tenant></i> ""&tenantdeletedate="" <i><date when managed tenant was deleted></i> ""
	getMonthlyCharge	Get usage charges	None.
	registerMonthlyCharge	Register monthly usage charges (*4)	"date="" <i><date of data registered></i> ""&id="" <i>L-Platform ID</i> ""&name="" <i><L-Platform name></i> ""&tenantname="" <i><tenant name of managed tenant></i> ""&tenantdeletedate="" <i><date when managed tenant was deleted></i> ""
	getTenants	Get tenant information	None.
Access Control	updateAuthority	Access authority modifications	"roleid="" <i><role name of modification target></i> ""&actionid="" <i><action ID of modification target></i> ""&permission="" <i><allow/deny status of specified action></i> "" (The above information will be output as follows: one information item when a role name is specified, or if a file is specified, the number of information items will match the number of action IDs.)
System condition (*4)	dispUsageStatus	Display usage condition	None.

*1: If a value is not set for an item, """" is output.
An example is shown below.

```
... &globalpool="" "" "" ...
```

*2: If multiple global pools have been set, the global pools are output separated by commas.
An example is shown below.

```
...&globalpool="" "/AddressPool, /ImagePool" "" ...
```

*3: For the operation result of createOrg, deleteOrg, or updateOrg, the processing result will be output. Use the operation log (resource operation) to check the actual processing result. Refer to "[16.1 Operation Logs](#)" for information on how to check the operation log (resource operation).

*4: Multiple lines may be output each time there is a registration operation.

*5: Format is "yyyy-MM-dd".

*6: Format is "yyyy-MM-ddTHH:mm:ss.SSSZ".

*7: Audit logs for usage condition are output only when operations are performed from the ROR Console.

16.2.3 Application Process Audit Log

This section explains the application process audit log.

Usage

To obtain the process instance audit log for the application process, execute the get process instance audit information command.

```
Installation_folder\SWRBAM\bin\swrba_audit
```

The process instance audit information that can be obtained will be the process instance information that was complete after the command was executed the previous time.

Privilege Required/Execution Environment

[Windows Manager]

- Administrator privileges are required. If the operating system is Windows Server 2008, execute as the administrator.
- This command can be executed on the admin server.

[Linux Manager]

- System administrator (superuser) privileges are required.
- This command can be executed on the admin server.

Output files

The following table shows the file name, file size, and generations of the audit log:

Log name	Description	File size	Number of generations
swrba_audit.log	Audit logs are output.	10 MB	10 (*1)

*1:

- The trigger for the generation switchover is when the file exceeds 10MB.
If the file size does not reach 10 MB, the log continues to be output to the same file even if the swrba_audit command is executed multiple times.
- Once 10 generations (100 MB) is exceeded, the oldest file (swrba_audit9.log) is deleted.

Destination

The table below shows the log output destination.

[Windows Manager]

Output folder	Output destination files
Installation_folder\SWRBAM\var\audit	swrba_audit.log.[n] (n is the generation)

[Linux Manager]

Output folder	Output destination files
/opt/FJSVswrbam/var/audit	swrba_audit.log.[n] (n is the generation)

Output format

The audit log is a CSV format file. The following items are output in the following order.

One item of process instance information is displayed as one record.

```
"Process instance start time","Process instance starter","Process instance name","Process instance state","Process instance end time","Activity name","Task execution date/time","Person responsible","Status","Task process",...,"Result of application"
```

Item	Description
Process instance start time	Time when the application was executed
Process instance starter	User ID of applicant

Item	Description
<i>Process instance name</i>	Process instance name L-PlatformSubscription_xxx,L-PlatformChange_xxx,L-PlatformUnsubscription_xxx
<i>State of process instance</i>	State of process instance closed: Closed
<i>Process instance end time</i>	Time that the process instance ended yyyy-mm-dd hh:mm:ss.sss
<i>Activity name</i>	Activity name Application,Approve,Assess,Pending state,Cancel
<i>Task execution date/time</i>	The date/time the task was executed
<i>Person responsible</i>	User ID of the user that executed the task
<i>Status</i>	Shows the state of task COMPLETED: Completed
<i>Task process</i>	Button name executed by the activity: Application: Apply - Approve: 0:Approve or 1:Reject - Assess: 0:Accept or 1:Dismiss - Pending state : 0:Cancel - Cancel: 0:Cancel
<i>Result of application</i>	Result of application: - Accepted: When [Accept] is executed for an assessment task - Approved: When [Approve] is executed for an approval task (when ApproverOnly) - Rejected: When [Reject] is executed for an approval task - Dismissed: When [Dismiss] is executed for an assessment task - Canceled: When [Cancel] is executed for a cancellation task - Canceled: When [Cancel] is executed for a pending task

Output example

The example below shows the output of the audit information for the process instance with the name "L-Platform usage application_100".

```
"2012-04-11 17:03:53.580", "tenant_user001", "L-PlatformSubscription_100", "closed", "2012-04-11
17:04:25.471", "Application", "2012-04-11
17:03:56.111", "tenant_user001", "COMPLETED", "Apply", "Approve", "2012-04-11
17:04:15.908", "tenant_admin001", "COMPLETED", "0:Approve", "Assess", "2012-04-11
17:04:21.346", "infra_admin001", "COMPLETED", "0:Accept", "Accepted"
```



Using an operating system feature such as Task Scheduler (Windows Manager) or cron (Linux Manager), configure the settings so that the get process instance audit information command is executed at fixed intervals so that an audit log of process instances can be obtained between command executions.

16.3 Operation Logs (Activity)

This section explains operation logs.

Operation logs are used as maintenance information when investigating and dealing with errors.

16.3.1 Operation Logs for Accounting

The following table shows the files where operation logs used for maintenance information accounting are output:

Copy the files described below to collect maintenance information.

[Windows Manager]

Type	Destination of files output	Description
Operation log	<i>Installation_folder</i> \RCXCTMG\Charging\log\accounting_calc_mail.log (*1)	The results of sending the usage charge file are output. (*2)

*1: This log file is 5 MB in size and holds 5 generations.

*2: Refer to "Chapter 9 Messages Starting with ctact" in the "Messages" for information on the execution result that is output.

[Linux Manager]

Type	Destination of files output	Description
Operation log	/var/opt/FJSVctchg/log/accounting_calc_mail.log (*1)	The results of sending the usage charge file are output. (*2)

*1: This log file is 5 MB in size and holds 5 generations.

*2: Refer to "Chapter 9 Messages Starting with ctact" in the "Messages" for information on the execution result that is output.

16.4 Investigation Logs

This section explains investigation logs.

Investigation logs are used as maintenance information when investigating and dealing with errors.

16.4.1 Investigation Logs on Admin Servers

The investigation logs on Admin Servers are classified into the following types:

Log name	Description	File size	Number of generations
vsys_trace_log	Trace logs for the management of L-Platform template and L-Platform are output to this log.	10MB	10 generations (*1)
vsys_batch_log	Trace logs for the batch processing section of the management of L-Platform template and L-Platform are output to this log.		
myportal_trace.log	Trace logs for the Manager View are output to this log.		
cfmg_api_log	Logs for the CFMG APIs are output to this log.		
Event log	Information such as errors that occur while the Manager View is being used is output to this log. Refer to "Chapter 20 Messages Starting with VSYS" in the "Messages" for information on event logs.	-	-

*1: If this number is exceeded, old generations will be deleted, starting with the oldest generation.

Output Destination

The log output destinations are shown below:

[Windows Manager]

Output folder	Output destination file
<i>Installation_folder</i> \RCXCFMG\logs	vsys_trace_log, vsys_batch_log, cfmg_api_log
<i>Installation_folder</i> \RCXCTMG\MyPortal\log	myportal_trace.log

[Linux Manager]

Output destination directory	Output destination file
/var/opt/FJSVcfmg/logs	vsys_trace_log, vsys_batch_log, cfmg_api_log
/var/opt/FJSVctmyp/log	myportal_trace.log

Output format

Output format
<date/time> <log level> <message ID> <message text>

Item	Description	
date/time	yyyy-mm-dd hh:mm:ss,sss	
log level	One of the following:	
	info	Information level message
	warn	Warning level message
	error	Error level message
	fatal	Fatal level message
message ID (*1)	Prefix and message number: - The prefix for myportal_trace.log is "MGRV". - The prefix for cfmg_api_log is "PAPI". - The prefix for all other logs is "VSYS".	
message text (*1)	Message content	

*1: Refer to the "Messages" for information on the message ID and message text.

Procedure for changing the investigation output destination

Use the following procedure to change the output destination for investigation logs.

1. Rewrite the settings files corresponding to each log.

The following table shows the settings file and the location to change:

[Windows Manager]

Log name	Settings file	Location to change (one location)
vsys_trace_log	<i>Installation_folder</i> \RCXCFMG\config\vsys_log4j.xml	<param name="File" value="C:\ProgramData\Fujitsu\SystemwalkerCF-MG\logs\vsys_trace_log" />

Log name	Settings file	Location to change (one location)
vsys_batch_log	<i>Installation_folder</i> \RCXCFMG\config\ \batch_log4j.xml	<param name="File" value="C:\ProgramData \Fujitsu\SystemwalkerCF-MG\logs \vsys_batch_log" />
myportal_trace.log	<i>Installation_folder</i> \RCXCTMG \MyPortal\config \managerview_log4j.xml	<param name="file" value=" C:\Fujitsu\ROR/ RCXCTMG/MyPortal/log/myportal_trace.log" />
cfmg_api_log	<i>Installation_folder</i> \RCXCFMG\config\ \api_log4j.xml	<param name="file" value="C:\ProgramData \Fujitsu\SystemwalkerCF-MG\logs \cfmg_api_log" />

[Linux Manager]

Log name	Settings file	Location to change (one location)
vsys_trace_log	/etc/opt/FJSVcfmg/config/ vsys_log4j.xml	<param name="File" value="/var/opt/FJSVcfmg/ logs/vsys_trace_log" />
vsys_batch_log	/etc/opt/FJSVcfmg/config/ batch_log4j.xml	<param name="File" value="/var/opt/FJSVcfmg/ logs/vsys_batch_log" />
myportal_trace.log	/etc/opt/FJSVctmyp/config/ managerview_log4j.xml	<param name="file" value="/var/opt/ FJSVctmyp/log/myportal_trace.log" />
cfmg_api_log	/etc/opt/FJSVcfmg/config/ api_log4j.xml	<param name="File" value="/var/opt/FJSVcfmg/ logs/cfmg_api_log" />

2. Restart the manager.

Refer to "[2.1 Starting and Stopping the Manager](#)" for information on how to Restart the manager.

Part 5 High Availability and Disaster Recovery

Chapter 17 High Availability of Managed Resources.....	142
Chapter 18 Disaster Recovery.....	156

Chapter 17 High Availability of Managed Resources

This chapter explains failover.

17.1 High Availability of Managed Resources

This section explains how to realize high availability of managed resources.

The methods of environment creation and operation for enabling higher availability of managed resources vary depending on resources involved.

- Servers

Refer to "[17.1.1 High Availability of L-Servers](#)".

- Blade chassis

Refer to "[17.1.2 Blade Chassis High Availability](#)".

- Storage chassis

Refer to "[17.1.3 High Availability for Storage Chassis](#)".

17.1.1 High Availability of L-Servers

This section explains high availability for L-Servers.

Regardless of the server type, select the [HA] checkbox on the [Server] tab to perform redundancy settings when creating an L-Server.

- For physical L-Servers

Select the [HA] checkbox to enable the selection of the pool of a spare server.

The server pool of the spare server that the physical server will use for automatic switchover is registered in can be specified.

For details on the [Server] tab, refer to "16.2.2 [Server] Tab" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

For the details on conditions for switchover to spare servers, refer to "9.3 Server Switchover Conditions" in the "Setup Guide VE".

- For virtual L-Servers

Settings differ according to the server virtualization software being used.

Refer to "16.3.2 [Server] Tab" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Checks of Spare Server Models and Configurations

The L-Server definition and spare server configuration are checked when configuring server redundancy during creation or modification of a physical L-Server.

Confirmation is performed on the following items of an L-Server definition and spare server configuration:

- Server Model

Check if there is a server compatible with the L-Server definition in the specified server pool.

The compatibility of server models is evaluated by the definition file for checks on spare server models and configurations.

The definition file is created when installing managers.

When installing a new compatible server model, update the definition file by adding the server model.

In the following cases, the same server model of physical server as the server specified in the L-Server definition is selected.

- When there is no definition file
- When there is an error in definitions

- Number of NICs

Check the number of NICs mounted on a compatible server and L-Server.

A server is considered as a server satisfying the conditions, in the following cases:

- The number of NICs mounted on the compatible server is the same as the number in the L-Server definition
- The number is more than the number in the L-Server definition

Selection of Suitable Spare Servers

When the [Use a low spec server] checkbox is not selected, a spare server is automatically set.

Based on the following conditions, an L-Server definition is compared to physical L-Servers existing in the specified resource pool as a spare server:

- When specifying the model name on creation of a physical L-Server
 - If the "model name" is the same or compatible
 - Number of NICs
- If CPUs and memories are specified when specifying a physical L-Server
 - CPU core count
 - CPU clock speed
 - Memory capacity
 - Number of NICs

Configurations are not checked.

A server that satisfies or exceeds all conditions and has the nearest specifications to the L-Server definition is selected.

When the [Use a low spec server] checkbox is selected, physical servers with models matching that in the L-Server definition are selected as spare servers.

For details, refer to "B.9 Methods for Selecting Physical Servers Automatically" in the "Setup Guide CE".

Modification of Checks on Spare Server Models and Configurations

The switchover policy and the definition of server model compatibility can be modified.

Although the definition file is deployed when installing managers, a server model with a matching L-Server definition and physical server model is selected as a spare server in the following cases:

- When there is no definition file
- When there is an error in definitions

When the [Use a low spec server] checkbox is selected, physical servers with models matching that in the L-Server definition are selected as spare servers.

The definition file for checks on spare server models and configurations is stored in the following location.

Location of the Definition File

[Windows Manager]
Installation_folder\SVROR\Manager\etc\customize_data

[Linux Manager]
/etc/opt/FJSVrcvmr/customize_data

Definition File Name

spare_server_config.rcxprop

Definition File Format

For the definition file, write each line in the following format:

Key = Value

When adding comments, start with a number sign ("#").

Definition File Items

Specify the following items in a definition file.

Table 17.1 List of Items Specified in Definition Files for Checking Spare Server Models and Configurations

Item	Key	Value	Remarks
Policy of Switchover	OVERALL_POLICY	skip	<p>Configure the check policy of the L-Server definition for the whole system and the spare server configuration.</p> <ul style="list-style-type: none"> - skip <p>Omits the check of whether or not there is a server that satisfies the spare server conditions. Even if a server pool that does not satisfy the conditions is selected, creation and modification of an L-Server are performed without checking.</p> <ul style="list-style-type: none"> - warning <p>Server pools without servers that satisfy the spare server conditions are also displayed. When a server pool that does not satisfy the conditions is selected, a warning message is displayed during creation and modification of an L-Server, checking whether to continue the operation.</p> <ul style="list-style-type: none"> - error <p>Server pools without servers that satisfy the spare server conditions are not displayed. Therefore, a server pool that does not satisfy the spare server conditions cannot be selected. Server switchover is not possible when the destination cannot be found while performing the switchover, even if the check has been made in advance.</p>
		warning	
		error	
Compatibility of Server Model (*1)	SPARE_SVR_COMP ATX (X is a number from 0 - 255)	["modelA", "modelB"]	<p>Define compatible server models as a group.</p> <p>When checking the L-Server definition and the spare server configuration, the server models in the same group are the target of switchover.</p> <p>Examples of server models are as below.</p> <ul style="list-style-type: none"> - BX920 S1 - BX920 S2

*1: The value of SPARE_SVR_COMPAT is changeable. Server switchover may fail depending on the combination of changed values, such as when a server with no compatibility is set as a spare server.

Example Definition File

```
# Spare server check configuration

# Spare server check logic's policy: skip | warning
```

```
| error
OVERALL_POLICY=skip

# Server model compatibility list
SPARE_SVR_COMPAT0=[ "BX920 S1", "BX920 S2" ]
```

17.1.2 Blade Chassis High Availability

This section explains high availability for when operating L-Servers on blade servers.

When the server is a physical L-Server for a blade server, this function which enables restarting of L-Servers, by manually switching over servers to spare servers when there are blade servers are specified as spare servers on other chassis.

Prerequisites

For details on prerequisites for high availability of blade chassis, refer to "7.1 Blade Chassis High Availability Design" in the "Design Guide CE".

Installation

This section explains the preparations for configuration of server switchover.

Use the following procedure for configuration:

1. Register a server in a spare blade chassis in the server pool.

Perform one of the following steps:

- Register a server in a spare blade chassis in the server pool
- Register a server in a spare chassis in the server pool for a spare server

2. Create an L-Server.

For details, refer to "16.1 Creation Using an L-Server Template" or "16.2 Creation of Physical L-Servers Using Parameters" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

In this case, perform redundancy for the L-Server.

On the [Server] tab of the [Create an L-Server] dialog, set the following items.

- Check the [HA] checkbox.
- When the server in the chassis was registered in the spare server pool in step 1., specify the spare server pool.

Operations

This section explains how to perform switchover of L-Servers.

Use the following procedure to perform switchover of L-Servers:

1. A chassis error is detected.

If the following events occur, determine whether to perform chassis switchover regarding the event as the chassis failure.

- When both management blades cannot be accessed because of a management blade failure
- Communication with the admin LAN is not possible
- When communication is not possible because there is trouble with the LAN switches that connect with the admin LAN

2. Check the chassis on which the L-Server for which an error was detected.

Execute the `rcxadm chassis show` command to check.

For details on the `rcxadm chassis show` command, refer to "3.2 rcxadm chassis" in the "Reference Guide (Command/XML) CE".

3. Check if the status of the L-Server that is the source for switchover is stop.

If the status of the L-Server is not stop, stop the L-Server.

The L-Server cannot be stopped, as the management blade cannot be accessed. Stop the L-Server on the managed server, using the console of managed server.



Note

If switchover is performed while an L-Server in a chassis that has trouble is still operating, there is a possibility that another instance of the L-Server will be started and its disks damaged. Ensure the L-Server is stopped.

4. Place the server into maintenance mode.

For details on how to place servers into maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Execute the `rcxadm server` command from the command line.

For details on the `rcxadm server` command, refer to "3.11 `rcxadm server`" in the "Reference Guide (Command/XML) CE".

5. Start the L-Server.

Start the L-Server on the switchover destination server.

For details on how to start an L-Server, refer to "17.1.1 Starting an L-Server" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

6. Release the server that has been switched to from maintenance mode.

For details on how to release servers from maintenance mode, refer to "Appendix C Maintenance Mode" in the "User's Guide for Infrastructure Administrators (Resource Management) CE".

Execute the `rcxadm server` command from the command line.

For details on the `rcxadm server` command, refer to "3.11 `rcxadm server`" in the "Reference Guide (Command/XML) CE".

Restoration

This section explains restoration.

Use the following procedure for restoration:

1. If a management blade has failed, replace it with new one. If an admin LAN or switches fail, replace them. After that, initialize the management blade. To initialize the management blade, select "controlled by VIOM" in the management window of the management blade. After performing the configuration to forcibly reset the local VIOM settings on the displayed screen, restart the management board. In either case, if any concerns arise, contact Fujitsu technical staff.
2. Mount a blade on the chassis.
3. After unregistering the restored chassis using the ROR console, register the chassis again.
4. After powering on the server in the restored chassis from the server resource tree, forcibly power off the server.

After restoring the blade chassis, use the following procedure to relocate the L-Server.

1. Stop an L-Server.

For details on how to stop an L-Server, refer to "17.1.2 Stopping an L-Server" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

2. Perform modification of the physical server to use.

In the [Modify an L-Server] dialog, specify the restored server for [Physical server].

For details on how to modify the physical server to use, refer to "17.2.1 Modifying Specifications" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

3. Start the L-Server.

For details on how to start an L-Server, refer to "17.1.1 Starting an L-Server" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".

17.1.3 High Availability for Storage Chassis


This section explains high availability of storage chassis connected to physical L-Servers.

If performing replication between two storage units of LUNs used by a physical L-Server, quick restoration of physical L-Servers is possible, even when storage units have failed.

This section explains the switchover of disks used by physical L-Servers, between two storage units on which replication of LUNs is managed by a single manager.

- When performing switchover of physical L-Servers and disks used by physical L-Servers in a Disaster Recovery environment, refer to "[Chapter 18 Disaster Recovery](#)".

Figure 17.1 Switchover of operating or standby status of storage



- When the disk resource is created using dynamic LUN mirroring, refer to "[When using dynamic LUN mirroring](#)".

Prerequisites

For details on prerequisites for high availability of storage chassis, refer to "7.2 Storage Chassis High Availability Design" in the "Design Guide CE".

Replication of Storage Unit LUNs

- For ETERNUS
 - Define the LUN replication using ETERNUS SF AdvancedCopy Manager.
- For EMC CLARiiON
 - Define the LUN replication using the MirrorView function.
- For EMC Symmetrix DMX storage and EMC Symmetrix VMAX storage
 - Define the device replication using the SRDF function.

Replication Definition Files

The replication definition file must be created in advance. In the replication definition file, describe the relationship between the operating storage and the standby storage for replication.

The format of the replication definition file is as follows:

```
IP_address_of_operating_storage_unit,Operating_volume_identifier,IP_address_of_standby_storage_unit,Standby_volume_identifier
```

Configure the definition file using a unique combination of an IP address for an operating or standby storage unit, and an identifier for an operating or standby volume. When the information overlaps in the replication definition file, an error will occur when creating a failover or a failback script.

- For ETERNUS

The relationship for replication can be checked using ETERNUS SF AdvancedCopy Manager.

Specify the IP address of a storage for the storage identifier. Check the IP address of a storage using the rcxadm storage list command.

For details on volume identifiers, check them from ETERNUS SF AdvancedCopy Manager. Volume identifiers are written in hexadecimal format without zero suppression.



Example

```
192.168.1.24,0x0001,192.168.2.25,0x0005  
192.168.1.24,0x0002,192.168.2.25,0x0006  
192.168.3.25,0x0001,192.168.4.26,0x0005
```



Information

When replicating using the Copy Control Module of ETERNUS SF AdvancedCopyManager, a replication definition file can be created.

For details on the rcxrepdef command, refer to "5.21 rcxrepdef" in the "Reference Guide (Command/XML) CE".

- For EMC CLARiiON

The relationship for replication can be checked using the MirrorView function.

Specify an IP address for the storage identifier. Check the IP address, using the rcxadm storage list command.

For details on volume identifiers, check them using the MirrorView function. Volume identifiers are written in hexadecimal format without zero suppression.



Example

```
192.168.1.24,0x0001,192.168.2.25,0x0005  
192.168.1.24,0x0002,192.168.2.25,0x0006  
192.168.3.25,0x0001,192.168.4.26,0x0005
```

- For EMC Symmetrix DMX storage and EMC Symmetrix VMAX storage

The relationship for replication can be checked using the SRDF function.

Specify SymmID for the storage identifier. Check SymmID, using the rcxadm storage list command.

Specify a device for the volume identifier. Check the device, using the SRDF function. Volume identifiers are written in hexadecimal format without zero suppression.

Example

```
000192601264,0001,000192601265,0005
000192601264,0002,000192601265,0006
000192601274,0001,000192601275,0005
```

When performing switchover from operating to standby (failover)

This section explains the procedure to perform switchover from operating storage units to standby storage units.

1. Create the replication definition file.

For details on replication definition files, refer to "[Replication Definition Files](#)".

2. Create the following scripts by executing the rcxstorage -failover command.

- failover script
- Physical L-Server stopping script
- Physical L-Server startup script

For details on the rcxstorage command, refer to "5.22 rcxstorage" in the "Reference Guide (Command/XML) CE".

- Create these scripts in units of operating storage.
- These scripts are created based on the configuration information at the time which the command is executed. When changing configurations, create these scripts again.
- Execute the rcxstorage command with the -failover option, when an operating and a standby storage unit are displayed in the storage tree. The script can be created as long as the operating storage unit is displayed in the storage tree, even if it has failed.

Note

These scripts cannot be created when the operation target storage unit is not displayed in the storage tree.

3. Execute the physical L-Server stopping script on the server where the manager is being operated. This operation stops the physical L-Server targeted by the failover script. To forcibly stop the server without shutting down the operating system running on the L-Server, specify the -force option when executing the physical L-Server stopping script.

If an error occurs during execution of the script, contact Fujitsu technical staff.

Note

Physical L-Servers are stopped in the order of the entries in the physical L-Server stopping script. When specification of the order of stopping physical L-Servers is necessary, edit the physical L-Server stopping script.

4. Delete the zoning combining the WWPN of the HBA of the physical L-Server and the WWPN of the port of the operating storage from the Fibre Channel switch. For ETERNUS storage, this step is not necessary as the zoning for Fibre Channel switch will be deleted by Resource Orchestrator when the failover script is executed.
5. If the replication function for storage is in operation, stop it.

6. Execute the failover script on the server where the manager is being operated.
 - If the error message number 62513 occurs during script execution

The Thin Provisioning and Thick Provisioning attributes of the operating disk resource and standby disk resource may be not the same. Check the replication definition file, and define the disk resource with the same attributes of Thin Provisioning and Thick Provisioning.
 - When an error other than the above has occurred

Contact Fujitsu technical staff.
7. To access the standby storage, add the zoning combining the WWPN of the HBA of the physical L-Server and the WWPN of the port of the standby storage to the Fibre Channel switch. For ETERNUS storage, this step is not necessary as the zoning for Fibre Channel switch will be added by Resource Orchestrator when the failover script is executed.
8. When perform reading or writing for the LUN of the standby storage, modify the settings of replication if necessary.
9. Execute the physical L-Server startup script on the server where the manager is being operated. This operation starts the physical L-Server.

If an error occurs during execution of the script, contact Fujitsu technical staff.

 **Note**

Physical L-Servers are started in the order of the entries in the physical L-Server startup script. When the specification of the order of starting physical L-Servers is necessary, edit the physical L-Server startup script.

10. When operating an L-Platform, use the `cfmg_syncdiskinfo` command to reflect the information for switched disks on the L-Platform configuration information.

[Windows Manager]

```
>Installation_folder\RCXCFMG\bin\cfmg_syncdiskinfo <RETURN>
```

[Linux Manager]

```
# /opt/FJSVcfmg/bin/cfmg_syncdiskinfo <RETURN>
```

For details on the `cfmg_syncdiskinfo` command, refer to "12.7 `cfmg_syncdiskinfo` (disk information synchronization)" in the "Reference Guide (Command/XML) CE".

When performing switchover from standby to operating (failback)

This section explains the procedure for performing switchover from standby storage units to operating storage units.

1. Request repair of the operating storage units.
2. Using storage management software, restore the logical configuration (RAID, LUN) of an operating storage unit.
3. Using storage management software, check the LUN masking definition and LUN mapping definition of the operating storage unit. If the definitions relating to the WWPN of the HBA of the physical L-Server remain, delete them.

 **Information**

When the storage is ETERNUS, delete the affinity group for the LUN of the operating storage unit

4. By modifying the settings of the replication function, perform replication of the storage unit from the operating to the standby, then wait until the status of the LUNs of the operating and standby storage become equivalent.

5. Prepare the replication definition file.

Use the same replication definition file as that for failover. When changing the configuration after executing the failover script, correct the replication definition file.

6. Create the following scripts by executing the rcxstorage -failback command.

- failback script
- Physical L-Server stopping script
- Physical L-Server startup script

For details on the rcxstorage command, refer to "5.22 rcxstorage" in the "Reference Guide (Command/XML) CE".

- Create these scripts in units of operating storage.
- These scripts can be created after executing the failover script and performing switchover to the standby storage unit.
- These scripts are created based on the configuration information at the time which the command is executed. When changing configurations, create these scripts again.
- Execute the rcxstorage command with the -failback option, when an operating and a standby storage unit are displayed in the storage tree. These scripts cannot be created when the operation target storage unit is not displayed in the storage tree.

7. Execute the physical L-Server stopping script on the server where the manager is being operated. This operation stops the physical L-Server targeted by the failback script. To forcibly stop the server without shutting down the operating system running on the L-Server, specify the -force option when executing the physical L-Server stopping script.

If an error occurs during execution of the script, contact Fujitsu technical staff.



Note

Physical L-Servers are stopped in the order of the entries in the physical L-Server stopping script. When specification of the order of stopping physical L-Servers is necessary, edit the physical L-Server stopping script.

8. Delete the zoning combining the WWPN of the HBA of the physical L-Server and the WWPN of the port of the standby storage from the Fibre Channel switch. For ETERNUS storage, this step is not necessary as the zoning for Fibre Channel switch will be deleted by Resource Orchestrator when the failback script is executed.

9. Stop the storage replication function.

10. Execute the failback script on the server where the manager is being operated.

- If the error message number 62513 occurs during script execution

The Thin Provisioning and Thick Provisioning attributes of the operating disk resource and standby disk resource may be not the same. Check the replication definition file, and define the disk resource with the same attributes of Thin Provisioning and Thick Provisioning.

- When an error other than the above has occurred

Contact Fujitsu technical staff.

11. To access the operating storage, add the zoning combining the WWPN of the HBA of the physical L-Server and the WWPN of the port of the operating storage to the Fibre Channel switch. For ETERNUS storage, this step is not necessary as the zoning for Fibre Channel switch will be added by Resource Orchestrator when the failback script is executed.

12. By modifying the settings of the replication function, perform replication of the storage unit from the standby to the operating, then wait until the status of the LUNs of the standby and operating storage become equivalent.

13. Execute the physical L-Server startup script on the server where the manager is being operated. This operation starts the physical L-Server.

If an error occurs during execution of the script, contact Fujitsu technical staff.



Note

Physical L-Servers are started in the order of the entries in the physical L-Server startup script. When the specification of the order of starting physical L-Servers is necessary, edit the physical L-Server startup script.

14. When operating an L-Platform, use the `cfmg_syncdiskinfo` command to reflect the information for switched disks on the L-Platform configuration information.

[Windows Manager]

```
>Installation_folder\RCXCFMG\bin\cfmg_syncdiskinfo <RETURN>
```

[Linux Manager]

```
# /opt/FJSVcfmg/bin/cfmg_syncdiskinfo <RETURN>
```

For details on the `cfmg_syncdiskinfo` command, refer to "12.7 `cfmg_syncdiskinfo` (Synchronize Disk Information)" in the "Reference Guide (Command/XML) CE".

When using dynamic LUN mirroring

This document explains some changes and points to note when using dynamic LUN mirroring.

Prerequisites

Refer to "7.2 Storage Chassis High Availability Design" in the "Design Guide CE".

Replication of Storage Unit LUNs

If disk resources are automatically generated from virtual storage, replication may be automatically set depending on the settings in the mirroring definition file. Replication settings use REC for CCM (machine-to-machine copying, transfer mode: Stack mode), so copy groups or pairs are automatically generated. The name of the generated copy group will be the value entered in the mirroring definition file.

Replication Definition Files

When replication using CCM is set, a replication definition file can be generated by executing the `rcxrepdef` command.

For details on the `rcxrepdef` command, refer to "5.21 `rcxrepdef`" in the "Reference Guide (Command/XML) CE".

When performing switchover from operating to standby (failover)

The procedure for switchover is the same as that for when a LUN is created in the storage unit beforehand.

Note

The disk resources created using dynamic LUN mirroring are not deleted when failover to the standby node occurs.

Information

Start to copy using REC (transfer mode: Stack mode) for CCM for the dynamic LUN mirroring. Stop the replication function using the procedure described in step 5. in the same way as follows:

1. Use the `acec suspend` command by specifying the `-force` option to forcibly suspend the REC session.
2. Use the `acec change` command to change the REC transfer mode to Through mode.
3. Suspend the REC session using the `acec cancel` command. In this case, do not specify the `-force` option.

When performing switchover from standby to operating (failback)

The procedure for switchover is the same as that for when a LUN is created in the storage unit beforehand.

17.2 High Availability for Admin Servers

This section explains high availability of managers.

Prerequisites for Manager Cluster Operation

For details on prerequisites for operating managers in cluster environments, refer to "7.3 Admin Server High Availability Design" in the "Design Guide CE".

Manager Cluster Operation in Windows Guest Environments in Hyper-V environments

- Install an operating system and configure a domain controller on the domain controller server.
- Perform installation and configuration of the admin server.

The following operations are necessary:

- Primary node
 - Connection with shared storage
 - Configure BIOS
 - Install Hyper-V roles
 - Install and configure EMC Solutions Enabler (when used)
 - Add a failover clustering function
 - Create a Hyper-V virtual network
 - Create clusters
 - Prepare virtual machines
 - Register virtual machines in clusters
 - Install and configure storage management software
 - Install and configure VM management software
 - Install and configure ServerView Operations Manager and ServerView Virtual-IO Manager
 - Install the Resource Orchestrator manager
 - Setup Resource Orchestrator
- Secondary node
 - Connection with shared storage
 - Configure BIOS
 - Install Hyper-V roles
 - Install and configure EMC Solutions Enabler (when used)
 - Add a failover clustering function
 - Create a Hyper-V virtual network

For details on the following items, refer to the Hyper-V manual.

- Install Hyper-V roles
- Add a failover clustering function
- Create a Hyper-V virtual network
- Create clusters
- Prepare virtual machines
- Register virtual machines in clusters
- Operation

When an error occurs on a VM guest, the operation will continue if the VM guest is switched over.

Note

- When performing configuration, modification, or deletion of managed server environments, such as L-Server creation, if an error occurs on VM guest, the operation may fail.

In this case, part of the environment of the managed server may be created. Perform the operation again after deleting created environments.

- When performing L-Server creation or ETERNUS configuration information modification using ETERNUS, if an error occurs on a VM guest, ETERNUS may not be able to return from the status of processing to normal status. In this case, to restore, forcibly log on from ETERNUSmgr, then log off. In the case of ETERNUS DX60/DX80/DX90, contact Fujitsu technical staff. For details on how to restore ETERNUS, refer to the ETERNUS manual.

Manager Cluster Operation in Windows and Linux Environments

The settings and deletion operations described below are required for cluster operation.

For details on the settings for cluster operation and the procedure for deletion, refer to "Appendix D Manager Cluster Operation Settings and Deletion" in the "Setup Guide VE".

- Settings
 - Primary node
 - Create cluster resources
 - Copy dynamic disk files
 - Perform link settings for folders on the shared disk
 - Set folder and file access rights
 - Set access rights for the Resource Orchestrator database
 - Change the IP address set for the manager's admin LAN
 - Register service resources
 - Start the cluster service
 - Secondary node
 - Perform link settings for folders on the shared disk
 - Set access rights for the Resource Orchestrator database
 - Change the IP address set for the manager's admin LAN
 - Start the cluster service
- Deletion
 - Primary node
 - Stop the cluster service
 - Delete service resources
 - Uninstall the manager
 - Secondary node
 - Uninstall the manager
 - Delete shared disk files
 - Delete cluster resources

 Note

- If switchover of an admin server occurs while L-Servers are operating, the operation being performed may fail.
If you were creating or registering resources, delete unnecessary resources and then perform the operation again.
- When performing L-Server creation or ETERNUS configuration information modification using ETERNUS, if an error occurs on an admin server, ETERNUS may not be able to return from the status of processing to normal status. In this case, to restore, forcibly log on from ETERNUSmgr, then log off. In the case of ETERNUS DX60/DX80/DX90, contact Fujitsu technical staff. For details on how to restore ETERNUS, refer to the ETERNUS manual.

Chapter 18 Disaster Recovery

This chapter provides information on Disaster Recovery for the admin server where Resource Orchestrator manager operates.

Resource Orchestrator provides simple and highly reliable Disaster Recovery, through exporting and importing the following information that Resource Orchestrator manager handles:

- L-Platform Templates
- L-Platform configuration information
- Resource information
- Accounting information
- Metering log

Prerequisites for Disaster Recovery Environment Configuration

For details on prerequisites when configuring Disaster Recovery environments, refer to "7.4 Disaster Recovery Design" in the "Design Guide CE".

18.1 Installation

This section explains how to configure a Disaster Recovery environment.

Configure a Disaster Recovery environment using the following flow.

1. Pre-setup Preparations

Perform pre-setup preparations for the primary and backup sites.

For details, refer to the "Design Guide CE".

- Replication of Storage Units

Copy the primary site information to the backup site using the storage unit replication function.

For storage replication, use the functions of "[17.1.3 High Availability for Storage Chassis](#)".

Disaster Recovery can be operated on LUNs created beforehand or on dynamic LUN mirroring storage of ETERNUS. For details on prerequisites for storage replication, refer to "7.2 Storage Chassis High Availability Design" in the "Design Guide CE".

For primary sites, it is not necessary for the disk resources for backup site to have been detected. Therefore, it is not necessary to connect storage units for the backup site to the server for the primary site.

Configure the image file storage folder specified during installation of Resource Orchestrator on the storage of the replication target. Copy the image files stored in the image file storage folder in the same way.

- When creating physical L-Servers

Refer to "Appendix D Preparations for Creating a Physical L-Server" in the "Design Guide CE".

- When creating virtual L-Servers using virtual machine software

Refer to "Appendix E Preparations for Creating a Virtual L-Server" in the "Design Guide CE". Note that when you create VM management software on some physical L-Server, you don't need to create VM management software on backup site.

- When using virtual L-Servers with VMware

Execute the following command to disable detection of replicated LUN.

```
>esxcfg-advcfg -s 0 /LVM/DisallowSnapshotLUN <RETURN>
```

Note

LUNs which were created by ETERNUS dynamic LUN mirroring are handled as LUNs created beforehand after a disaster recovery failover. Replication settings must be done manually before future failover operations because automatic replication setting is not available to LUNs created beforehand. For details about LUNs created by dynamic LUN mirroring and LUNs created beforehand, refer to "D.3 Storage Preparations" of "Design Guide CE".

2. Set up for disaster recovery

Do the following set up that collects information for disaster recovery failover and eases failover operations.

a. Create folders which contain failover information

Create the following folders and files which are used to contain failover information.

folders which contain failover information folders which contain failover information\Image - Folder to contain physical server image files folders which contain failover information\ManagerExport - Output directory of rcxmgrexport command folders which contain failover information\MAP - Folder to contain map file of physical server names folders which contain failover information\OtherBackupFiles - Folder to contain definition files and user scripts folders which contain failover information\storage_file - Output file of rcxstorage command folders which contain failover information\vmmgr_file.txt - File to define VM management software
--

Example

D:\ D:\Export\Image D:\Export\ManagerExport D:\Export\MAP D:\Export\OtherBackupFiles D:\Export\storage_file D:\Export\vmmgr_file.txt
--

Create the following folders under the failover information container folder.

The failover information container folder and folders under the failover information container folder need to be replicated to backup site because these are used in recovery operation.

Folders under failover information container folder

The following folders need to be created.

- Image

This folder is used to transfer physical image files. Any folder name can be used.

- ManagerExport

This folder is mandatory. The folder name cannot be changed.

- MAP

This folder is used to map physical server names. The folder name cannot be changed.

- OtherBackupFiles

This folder is used to contain files other than the above. Any folder name can be used.

3. Install and configure the manager

Install Resource Orchestrator manager on the primary and backup sites.

When the environment is configured as disaster recovery failover is transparent to ROR console users, SVOM and VIOM need to be installed into admin server of backup site under either of the following conditions. The condition must be satisfied during installation and once the installation finished there is no such condition.

- Admin server of primary site stopped
- Network that can reach primary site disconnected

Set the failover information container folder which was created in 2. to the following definition file. The same setting must be done on backup site as well as on primary site in preparation for disaster recovery failover.

[Windows manager]

Installation_folder\SVROR\Manager\etc\customize_data\fa_dr.rcxprop

After installing the manager, set up SSL when it's needed.

For details, refer to "Chapter 2 Installation" and "Chapter 3 SSL Communication Environment Settings for the ROR Console" in the "Setup Guide CE".



.....

The site certificate that was issued by the CA is recommended to be used for the Disaster Recovery environment.

When test certificates are used, certificates on the backup site also need to be imported to the browser when installation or after the switchover.

For details, refer to "Chapter 6. Importing a Certificate to a Browser" in the "Setup Guide CE".

.....

When using Disaster Recovery, a license for the "DR option" is necessary.

After installing Resource Orchestrator, register the license for the "DR option" on the primary and backup sites.

For details on how to register the license, refer to "Chapter 5 License Setup and Confirmation" in the "Setup Guide CE".

The Image file storage folder must be the Image folder created in a. of "2. Set up for disaster recovery".

The following certificate files installed on both the primary and backup sites must be the same. When installing a manager on the backup site, copy the files from the primary site. Perform this operation after stopping the manager.

When configuring a single backup site to inherit multiple primary sites, copy the following files of the manager on the primary site that is first created to the managers on the other primary sites.

- *Installation_folder\SVROR\Manager\etc\opt\FJSVssmgr\current\certificate*
- *Installation_folder\SVROR\Manager\etc\opt\FJSVrcxdm\certificate*
- *Installation_folder\SVROR\Manager\sys\apache\conf\ssl.crt*
- *Installation_folder\SVROR\Manager\sys\apache\conf\ssl.key*

The following customizations, which are performed according to "Chapter 19 To Customize Environment" in the "Setup Guide CE", of the primary site need to be reflected in the backup site before switching.

Set up the backup site too while setting up the environment, or reflect the settings as a process of switching.

- "19.1 Settings for Sending Email"
- "19.2.3 Setting Application process settings"
- "19.2.4 Setting Application process to be used"
- "19.3 Customizing the Dashboard"
- "19.4 Setting the Host Names for Virtual Servers"
- "19.5 Setting the Method for Setting Resource Names"
- "19.6 Settings for the Overcommit Function"
- "19.7 Editing the Environment Setup File for the L-Platform API"

- "19.9 System Disk Settings for Physical L-Servers"
- "19.12 Edit the License Agreement"
- "19.13 Editing the User Agreement when Registering a User"

Back up modified files of the following.

- *installation_folder*\RCXCFMG\config\command_config.xml
- *installation_folder*\RCXCFMG\config\mail_config.xml
- *installation_folder*\RCXCFMG\config\vsys_config.xml
- *installation_folder*\RCXCTMG\Charging\conf\accounting.properties
- *installation_folder*\RCXCTMG\MyPortal\config\application_process.properties
- *installation_folder*\RCXCTMG\MyPortal\config\custom_config.xml
- *installation_folder*\RCXCTMG\MyPortal\config\managerview_config.xml
- *installation_folder*\RCXCTMG\MyPortal\config\license\create\default
- *installation_folder*\RCXCTMG\MyPortal\config\license\reconfigure\default
- *installation_folder*\RCXCTMG\MyPortal\config\license\return\default
- *installation_folder*\RCXCTMG\SecurityManagement\conf\portal.properties
- *installation_folder*\IAPS\F3FMihs\servers\FJapache\htdocs\sopdocs\pub\html\en\cRegApply_agreement.forUse_en.html

4. Configure managed servers

Configure the settings of managed servers and network devices for the primary and backup sites.

Refer to "7.4 Disaster Recovery" in the "Design Guide CE" beforehand.

And for details on the configuration, refer to the following sections in the "Setup Guide CE".

- "Chapter 7 Registering Infrastructure Administrators"
- "Chapter 8 Creating Definition Files"
- "Chapter 9 Registering Resources with Resource Orchestrator"
- "Chapter 11 Installing Software and Registering Agents on VM Hosts"
- "Chapter 12 Registering Resources to the Global Pool"
- "Chapter 13 Creating L-Server Templates"
- "Chapter 14 Creating an L-Server for an Infrastructure Administrator"
- "Chapter 15 Collecting and Registering Cloning Images"
- "Chapter 16 Creating L-Platform Templates"

For Disaster Recovery environments, configure as follows.

- Register servers on server tree in advance on backup site as well as on primary site. As for pools, L-Platforms, users and user groups registered on orchestration tree on backup site, these don't need to be the same as those of primary site. Register them depending on the production you do on the backup site.
- Upon arranging the network device, register it beforehand on the network device tree also in the backup site. When NS Appliance is used as a network device, create an NS Appliance also in the backup site and register it as a network device beforehand. For NS Appliance operation procedures refer to "NS Option Instruction".
- When using the auto-configuration function for network devices
Copy the files and folders below to the backup site.
 - *Installation_folder*\SVROR\Manager\etc\customize_data\network_device_model.xml
 - *Installation_folder*\SVROR\Manager\etc\scripts\

- Regarding the following configurations, use the information satisfying the necessities of both the primary and backup site.
 - Under *Installation_folder*\SVROR\Manager\etc\storage\emc
 - *Installation_folder*\SVROR\Manager\etc\customize_data\storage_portset.rcxprop
 - Under *Installation_folder*\Manager\etc\customize_data\fc_connection_pattern

5. Configure the server NIC definition

When using a NIC other than one in the default configurations of network auto-configuration and using a blade server, create a server NIC definition, and reflect it on the manager.

Create the same server NIC definition for the backup site same as for the primary site in advance, and reflect it on the manager. Execute the `rcxadm nicdefctl commit` command, and reflect the created server NIC definition on the manager.

For details on the server NIC definitions, refer to "13.11 Server NIC Definitions" in the "Reference Guide (Command/XML) CE".

For details on the `rcxadm nicdefctl commit` command, refer to "5.15 rcxadm nicdefctl" in the "Reference Guide (Command/XML) CE".

6. Create the file used in disaster recovery

a. Create the VM management software definition file

Create the following file under the failover information container folder. This file is used to register VM management software to Resource Orchestrator on backup site.

- `vmmgr_file.txt`

The format of the VM management software definition file is shown below. Note that the first line of the below example is to explain the content of the file and don't include the line in the actual file.

For details on the VM management definition file, refer to "5.20 rcxrecovery" in the "Reference Guide (Command/XML) CE".

name	soft name	ip	user name	password	physical-lserver
vcenter,	vmware-vc,	192.168.1.24,	admin,	admin,	yes
scvmm,	ms-scvmm,	192.168.100.77,	root,	root,	no

b. Create the physical server mapping definition file

If you want to change server names between primary site and backup site, create the physical server mapping definition file. This file must be located in the MAP folder under the failover information container folder and be the csv file which includes the following content.

#PhysicalServer	
Server1-1,Server2-1	
Server1-2,Server2-2	
:	:

Server1-1 and Server1-2 are the server names on primary site.

Server2-1 and Server2-2 are the corresponding server names on backup site.

For details on the physical server mapping definition file, refer to "5.20 rcxrecovery" in the "Reference Guide (Command/XML) CE".

7. Set up for automatic failover information collection

The portion of failover information which is modified through operations by tenant users and/or tenant administrators can be collected automatically. There are two methods to collect the information automatically as explained below.

- Collect the information periodically

Execute the following command to collect the failover information at regular intervals.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrexpport -interval minutes <RETURN>
```

For details on the rcxmgrexpport command, refer to "5.19 rcxmgrexpport" in the "Reference Guide (Command/XML) CE".

- Collect the information after an operation is done

Execute the following command to collect the information automatically when operations by tenant users and/or tenant administrators which change the failover information are done.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrexpport -event on <RETURN>
```

For details on the rcxmgrexpport command, refer to "5.19 rcxmgrexpport" in the "Reference Guide (Command/XML) CE".

Note

- When collecting the failover information for disaster recovery, the information is collected from the entire system. If the collection is done at too short intervals or after too frequent user operations, it may affect production or normal system operations. Decide the method to collect the failover information considering the impact to the system.
- There is information which is not collected by the automatic collection performed by "7. Set up for automatic failover information collection" but necessary for disaster recovery failover. Follow the operations described in "18.2 Normal Operation" to collect the complete failover information.

18.2 Normal Operation

This section explains operations which need to be done before disaster recovery failover.

When you do operations like deploying L-Platform which changes resource configuration information, you need to recollect information which is used in disaster recovery failover as explained below. The information collection needs to be done automatically or periodically to keep up with the latest configuration.

1. Export the required information from the main site

As a backup in case of a failure in the main site, and where an environment has been constructed on the backup site that can be used for recovery, export the information as explained below. The information is not necessary, when information is collected automatically.

- L-Platform template
- L-Platform configuration information
- Resource information
- Accounting information
- Metering log
- Execution information of sample scripts

One of the following operations is recommended.

- When changing the managed server configuration, export the information first, and maintain the latest system information
- Export regularly, and update the data

Execute the command shown below to collect the information.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxmgrexpport -dir dir1 <RETURN>
```

For details on the rcxmgrexpport command, refer to "5.19 rcxmgrexpport" in the "Reference Guide (Command/XML) CE".

Moreover, when you change the target network device configuration, keep the latest system configuration by exporting the information.

The information can be exported using the following command.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rxadm netconfig export -file file.xml<RETURN>
```

For information on using netconfig command, refer to "3.7 rxadm netconfig" in the "Reference Guide (Command/XML) CE".

Note

- Operations like L-Platform deployment, return, configuration modification which changes various information, must not be done during exporting information.
- If accounting setting is on, it is recommended to export switchover information every day. This ensures the exported information of the operation site be updated to newest.

2. Backup customize information of the primary site

When disaster recovery failover is done from primary site to backup site, some settings must be done again. To ease these settings, save the following information of primary site. Use "OtherBackupFiles" folder in the failover information container folder to save the information.

- *Installation_folder\SVROR\Manager\etc\customize_data*
- *Installation_folder\SVROR\Manager\etc\trapop.bat*
- *Installation_folder\SVROR\Manager\etc\event_handler*
- *Installation_folder\SVROR\Manager\etc\scripts*
- *Installation_folder\SVROR\Manager\etc\vm*

3. Acquire the storage replication information

Check the corresponding LUNs used to perform storage unit replication for the primary and backup sites. When configuring "Operations to collect information when changing environments" in step 5. in "[18.1 Installation](#)", this operation is not necessary, since the information is collected automatically.

Create a replication definition file which describes LUN relations. When using dynamic LUN mirroring storage of ETERNUS, since the target LUNs to be replicated are added by the deployment of L-Platforms, create the replication definition file using the rxrepdef command. Specify that file and create the file to perform mapping of LUNs in the backup site resources from the relation lists during import.

To create this file, execute the rcxstorage command with the -recovery and -mode options. Specify "prepare" for the -mode option.

For details on replication definition files, refer to "[Replication Definition Files](#)" in "[17.1.3 High Availability for Storage Chassis](#)".

For details on the rxrepdef command, refer to "5.21 rxrepdef" in the "Reference Guide (Command/XML) CE".

For details on the rcxstorage command, refer to "5.22 rcxstorage" in the "Reference Guide (Command/XML) CE".

4. Back up directory service information

Backs up the directory service information. Back up the information, after performing operations such as registering, modifying, or deleting a user.

5. Back up VM management software information

When configuring VM management software on an admin server, it is necessary to restore the VM management software information. Therefore, back up the VM management software information as well. For details on how to back up and restore VM management software information, refer to the manual of each VM management software. It is necessary to collect the VM management software information at the timing of registration, modification, or deletion of a VM guest.

6. Back up firewall configurations

When configuring a firewall automatically using the auto-configuration function for network devices, it is recommended to use the network device configuration backup command or the management software configuration backup function, and operate as follows:

- After configuring auto-configuration of the firewall, back up the configuration and collect the newest configuration.
- Back up firewall configurations regularly.

When backing up firewall configuration regularly, collect the firewall configuration immediately after rcxmgexport, which exports configuration of Resource Orchestrator, finished to synchronize the timing of configuration backup. Note that this operation is not necessary for NS appliance.

7. Reflecting changes of settings and backing up configuration files

After a Disaster Recovery environment is set up, if the settings of the primary site are changed according to "[Chapter 8 Changing Settings](#)", the changes of the following settings need to be reflected in the backup site before switching.

- "[8.2 Settings for Sending Email](#)"
- "[8.4 Editing Information in the Home Window](#)"
- "[8.5.1 Settings for Permissions to Change L-Platform Templates](#)"
- "[8.5.2 Subnet Settings at Segment Editing](#)"
- "[8.5.3 Settings for the Simplified Reconfiguration Function](#)"
- "[8.5.4 Distribution Ratio Settings](#)"
- "[8.5.5 Application Process Settings](#)"
- "[8.5.7 Edit the License Agreement](#)"
- "[8.5.9 Default Password Setting for Sent Emails](#)"
- "[8.5.10 Settings for the Maximum Number of Connections for the L-Platform Template](#)"
- "[8.6.1 Settings for Tenant Management and Account Management](#)"
- "[8.6.2 Editing the User Agreement when Registering a User](#)"
- "[8.7 Accounting Settings](#)"
- "[8.8 System Condition Server List Settings](#)"
- "[8.9 Settings for Event Log Output for CMDB Agent](#)"

Back up modified files of the following.

- *installation_folder*\RCXCFMG\config\mail_config.xml
- *installation_folder*\RCXCFMG\config\vsys_config.xml
- *installation_folder*\RCXCTMG\Charging\conf\accounting.properties
- *installation_folder*\RCXCTMG\Charging\conf\metering_log.properties
- *installation_folder*\RCXCTMG\MyPortal\config\application_process.properties
- *installation_folder*\RCXCTMG\MyPortal\config\custom_config.xml
- *installation_folder*\RCXCTMG\MyPortal\config\managerview_config.xml
- *installation_folder*\RCXCTMG\SecurityManagement\conf\portal.properties
- *installation_folder*\SWRBAM\CMDB\FJSCMDB\axis2\WEB-INF\services\mdr_cfm\cmdb.properties
- *installation_folder*\SWRBAM\CMDB\FJSCMDB\axis2\WEB-INF\services\mdr_ror\cmdb.properties
- *installation_folder*\SWRBAM\CMDB\FJSCMDB\CMDBConsole\WEB-INF\classes\viewlist_en.xml
- *installation_folder*\RCXCTMG\MyPortal\config\license\create\default
- *installation_folder*\RCXCTMG\MyPortal\config\license\reconfigure\default
- *installation_folder*\RCXCTMG\MyPortal\config\license\return\default
- *installation_folder*\IAPS\F3FMihs\servers\FJapache\htdocs\sopdocs\pub\html\en\cRegApply_agreement.forUse_en.html

18.3 Switchover Operation During Disasters

This section explains operations of disaster recovery failover when a disaster strikes the primary site.

The same operations can be used for failback from the backup site to the recovered primary site.


For switchover operations during a disaster, there are the two main operations described below.

- Operations to Perform Batch Switchover of All Resources

The operations to perform batch switchover of all resources.

For details, refer to "[Detailed Procedure for Switchover Operation during Disasters](#)".

Figure 18.1 Operations to Perform Batch Switchover of All Resources




- Operation involving resource switchover by tenant

Restore each tenant, after restoring global resources.


a. Restore global resources

Figure 18.2 Restore global resources



b. Restore each tenant resource

Figure 18.3 Restore each tenant resource



For details, refer to "[Detailed Procedure for Switchover Operation during Disasters](#)".

Detailed Procedure for Switchover Operation during Disasters

The details of the procedure are explained below.

1. Stop operation of the backup site

Stop the operations being performed on the backup site, and prepare to switch over from the primary site.

2. Disconnect the storage

Stop the storage replication function, and disconnect the backup site from the primary site.

3. Mount volumes which contain the information for failover

Mount the volume which is replicated from the primary site through "2. Set up for disaster recovery" of "[18.1 Installation](#)", to the manger of backup site.

4. Copy physical L-Server Images

Physical L-Server images for primary site are replicated to backup site. However, the image file storage folder of backup site contains physical L-Server images for backup site. Do the followings to switch the physical L-Server images on backup site.

- a. Save the physical L-Server images in the image file storage folder to a different folder.

The image file storage folder can be shown by `rcxadm imagemgr` command with `info` option.

For details on `rcxadm imagemgr` command, refer to "5.9 `rcxadm imagemgr`" of "Reference Guide (Command/XML) CE".

- b. Clear the content of the image file storage folder.

- c. Copy the physical L-Server images for primary site to the image file storage folder.

The physical L-Server images for primary site can be found in the Image folder of the volume mounted at "3. Mount the volume which contains the information for failover"

- d. Restart the manager.

5. Copy firewall configurations

When using the firewall auto-configuration function for network devices, copy the newest configuration from the primary site to the firewall of the backup site.

This operation is not needed for NS appliance.

6. Recover customize information of primary site

When you had modified any file in the following folder on primary site, restore the files from backup saved in "2. Backup customize information of the primary site" of "[18.2 Normal Operation](#)", and restart manager when it's needed.

[Windows Manager]

- The following files under `installation_folder\SVROR\Manager\etc\customize_data`

- `l_server.rcxprop`
- `logctl_env.rcxprop`
- `storage_rcxprop`
- `vnetwork_vmware.rcxprop`
- `vnetwork_hyperv.rcxprop`
- `vnetwork_excluded_vmware.rcxprop`
- `rcx_base.rcxprop`
- `server_spec.rcxprop`
- `library_share_deny.conf`
- `image_admin_hyperv.rcxprop`
- `library_share_UserGroupName_deny.conf`
- `kb978336_scvmm.rcxprop`
- `image_admin_hyperv_UserGroupName.rcxprop`

- server_control.rcxprop
- vm.rcxprop
- vm_console.rcxprop
- scvmm_mac_pool.rcxprop
- scvmm_mac_pool_*TenantName*.rcxprop
- vm_VMware.rcxprop
- vm_Hyper-V.rcxprop
- create_image_previous_folder_name_scvmm.rcxprop
- auto_replace.rcxprop
- Physical.rcxprop
- spare_server_config.rcxprop
- *installation_folder*\SVROR\Manager\etc\trapop.bat
- All files under *Installation_folder*\SVROR\Manager\etc\event_handler
- All files under *Installation_folder*\SVROR\Manager\etc\scripts
- The follow file *installation_folder*\SVROR\Manager\etc\vm
 - vds_vc

7. Reflecting changes of settings of the primary site

Reflect the following customization settings of the primary site, which are performed according to "Chapter 19 To Customize Environment" in the "Setup Guide CE", in the backup site.

- "19.1 Settings for Sending Email"
- "19.2.3 Setting Application process settings"
- "19.2.4 Setting Application process to be used"
- "19.3 Customizing the Dashboard"
- "19.4 Setting the Host Names for Virtual Servers"
- "19.5 Setting the Method for Setting Resource Names"
- "19.6 Settings for the Overcommit Function"
- "19.7 Editing the Environment Setup File for the L-Platform API"
- "19.9 System Disk Settings for Physical L-Servers"
- "19.12 Edit the License Agreement"
- "19.13 Editing the User Agreement when Registering a User"

After a Disaster Recovery environment is set up, if the settings of the primary site are changed according to "[Chapter 8 Changing Settings](#)", reflect the changes of the following settings in the backup site.

- "[8.2 Settings for Sending Email](#)"
- "[8.4 Editing Information in the Home Window](#)"
- "[8.5.1 Settings for Permissions to Change L-Platform Templates](#)"
- "[8.5.2 Subnet Settings at Segment Editing](#)"
- "[8.5.3 Settings for the Simplified Reconfiguration Function](#)"
- "[8.5.4 Distribution Ratio Settings](#)"
- "[8.5.5 Application Process Settings](#)"

- "8.5.7 Edit the License Agreement"
- "8.5.9 Default Password Setting for Sent Emails"
- "8.5.10 Settings for the Maximum Number of Connections for the L-Platform Template"
- "8.6.1 Settings for Tenant Management and Account Management"
- "8.6.2 Editing the User Agreement when Registering a User"
- "8.7 Accounting Settings"
- "8.8 System Condition Server List Settings"
- "8.9 Settings for Event Log Output for CMDB Agent"

8. Batch import

Perform batch switchover operations, using the switchover information for Disaster Recovery.

a. Mapping of storage

Perform storage resource mapping, based on the files defining the relations between primary site and backup site storage.

b. Divide import resources

In order to implement the import process in phases within the command used in d., divide the import resources based on the following types.

- Global resources and resources of individual tenants
- Physical L-Server resources and virtual L-Server resources

c. Delete the backup site environment

Delete the following environment used for the backup site operations.

- L-Platform templates
- L-Platform configuration information
- Resource information
- Accounting information
- Metering log

d. Import the information

Import the following information:

- L-Platform templates
- L-Platform configuration information
- Resource information
- Accounting information
- Metering log

The information can be imported using the following operations:

- Operations to Perform Batch Switchover of All Resources

Execute the rcxrecovery command. Execute the following command when settings for disaster recovery are done.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxrecovery <RETURN>
```

- Operation involving resource switchover by tenant

Restore global resources

Execute rcxrecovery command. Execute the following command when set up for disaster recovery are done.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxrecovery -global <RETURN>
```

2. Restore each tenant resource

Execute rcxrecovery command for each tenant. Execute the following command when set up for disaster recovery are done.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxrecovery -tenant tenant1 <RETURN>
```

For details on the rcxrecovery command, refer to "5.20 recovery" in the "Reference Guide (Command/XML) CE".

The rcxrecovery command displays messages which represent what are processed currently. Also in the following cases, the command shows prompt to wait for your action. Please continue the command answering the questions shown by the command.

- When -nocleanup option is not specified and the backup site is to be cleaned up, an inquiry will be displayed to ask you if it really can be cleaned up. Press "y" to approve the cleanup and continue the rcxrecovery command. If cleanup of the backup site cannot be done, press "n" to quit the command.
- When VM management software is not set up on any Physical L-Servers, restoration of VM management software must be done manually. rcxrecovery command may show prompt in the process to wait for the restoration of VM management software. In that case, continue the command after you finished restoration of VM management software.
- When VMware ESXi is included in servers to be taken over, VM host needs to be registered to SVOM. rcxrecovery command may show prompt in the process to wait for VM host registration to SVOM. In that case, continue the command after you finished the VM host registration to SVOM. Regarding how to register VM host to SVOM, refer to manual of SVOM.

Note

- L-Servers for which only the configuration definition has been created is not covered by disaster recovery failover. Execute the rcxadm config command as follows to back up the information which is used to relate the configuration definition to L-Server again later.

[Windows Manager]

```
>Installation_folder\SVROR\Manager\bin\rcxadm config filter -convert -indir indir -outdir outdir  
<RETURN>
```

The following information will be output to *outdir*, using the file name convert.txt.

After completing the restoration procedure, perform creation of a link with an L-Server and setting the scope again as shown below:

```
[command]  
rcxadm lserver convert -with BX900_1 -name physical_lserver_1  
rcxadm lserver convert -with BX900_3 -name physical_lserver_2 -to /tenant_1  
rcxadm lserver convert -with BX900_6 -name physical_lserver_3 -label test_label3 -comment  
test_comment3 -to /folder_1  
[user]  
user_1, physical_lserver_1  
user_1, /tenant_1/physical_lserver_2  
user_2, /folder_1/physical_lserver_2  
[usergroup]  
usergroup_1, physical_lserver_1  
usergroup_2, /folder_1/physical_lserver_3
```

- Storage using the ETERNUS dynamic LUN mirroring is switched to the LUN that was prepared on the backup site when the switch operation is performed after a disaster. Operation may be different if the storage is not released even after deleting the L-Platform.
- Perform operation so that the import of the resource configuration information and user definition file (XML file) using the rcxrecovery command is not executed at the same time as modification of the resource configuration information and user definition file (XML file) due to L-Server creation, or other operations.
- The RC console may not display proper power status of L-Servers right after a disaster recovery failover. Wait for about 3 minutes after the failover to see the right power status of L-Servers.
- Importing may fail when switchover is performed to the backup site, due to a VM guest switchover failure. In this case, perform the import again using the following procedure, but excluding the managed servers for which import failed. The following shows an example of where the VM guest could not be restored during L-Server import.
- Disaster recovery failover fails when configuration import fails. In this case, execute the failover command again after corrective action for the cause of the import failure. When you execute the command again, -nocleanup option needs to be specified if the previous command execution was done without -nocleanup option and configuration cleanup was done and "cleanup of resources" process ended in "completed".

The following shows an example of where the VM guest could not be restored during L-Server import.

- 1) An error has occurred during import.

```
>Installation_folder\SVROR\Manager\bin\rcxrecovery <RETURN>
FJSVrcx:ERROR:62569:/tenant1/l-platform1/l-server1:lserver:import was
interrupted. Message=:67154: VM Guest not found
```

- 2) The status of the relevant resources is displayed to help determine the cause of the error.

```
>Installation_folder\SVROR\Manager\bin\rcxadm config show -type lserver -name /
tenant1/l-platform1/l-server1 -dir dir1 -format xml<RETURN>
```

- 3) Delete the resource where the problem occurred from the export file.

```
>Installation_folder\SVROR\Manager\bin\rcxadm config filter -exclude lserver -
name /tenant1/l-platform1/l-server1 -indir dir1 -outdir dir2 <RETURN>
```

- 4) Import again.

```
>Installation_folder\SVROR\Manager\bin\rcxrecovery -nocleanup<RETURN>
```

9. Restore directory service information

Restore directory service information. As for how to restore the information, refer to the manuals of the directory service software.

10. Check the imported L-Platforms

When an L-Platform is exported during its deployment or a reconfiguration and then the L-Platform configuration information is imported using rcxrecovery, L-Platform information without resources may be recovered.

In this case, information of the L-Platform whose resources may not exist is output to the log.

Confirm the details output in logs, and take corrective action.

For information on the content output to the log and the actions, refer to "1.2.3 Log Output when Switching Servers with Disaster Recovery" in the "Reference Guide (Command/XML) CE".

11. Recover Usage Charge

- Send Usage Charge Files

Usage charge files for each tenant of the exported month will be recovered to the following directory.

Refer to "15.4.6 Sending Usage Charges" for the format of the usage charge files.

- Usage Charge files

Stored folder

Installation_folder\RCXCTMG\Charging\importdata

- File names
 - YYYYMM_Tenant_name[_Deleted_date].zip
 - YYYYMM is the cutoff year and month of the tenant.
 - Deleted_date will be appended if the tenant is deleted.

Usage charge files will be needed for the accounts manager to determine the usage charges for each tenant on the month of the recovery.

Send these files to the accounts manager of each tenant based on the tenant information file.

The tenant information file is a file describing the tenant and holds information such as tenant name, cutoff date, accounting E-mail address and so on.

The tenant information file is stored in the same directory as the usage charge files.

- Tenant information file

Stored folder

Installation_folder\RCXCTMG\Charging\importdata

- File names
 - tenant_info.csv
- Format
 - CSV file format with "Tenant name", "Tenant display name", "Tenant deleted date", "Tenant last cutoff date", "Tenant next cutoff date", and "Accounting E-mail address" columns.

```
#TenantName , TenantDisplayName , TenantDeletedDate , TenantLastCutoffDate , TenantNextCutoffDate , Accounting
MailAddress
tenant01 , tenant001 , , 2012-05-31 , 2012-06-30 , tenant1@example.com
tenant02 , tenant002 , , 2012-05-31 , 2012-06-30 , tenant2@example.com
tenant03 , tenant003 , 2012-05-27 16:48 , 2012-05-31 , 2012-06-30 , tenant3@example.com
tenant04 , tenant004 , , 2012-05-31 , 2012-06-30 , tenant4@example.com
```

Sending usage charge files to the accounts manager as follows.

- Operations to Perform Batch Switchover of All Resources
 - Send the recovered usage charge files of each tenant to the accounts manager.
 - For each usage charge files, which tenant it corresponds to can be determined from the file name.
 - Obtain the accounting E-mail addresses from the tenant information file and send the usage charge files.
- Operation involving resource switchover by tenant
 - Obtain the accounting E-mail addresses of the switchover tenant from the tenant information file and send the target usage charge files.

When sending the usage charge files, notify the following information along.

- The usage files of the backup site will be sent on the day after the cutoff date separately.
- Usage charge on the month of the recovery has to be calculated with usage charge files of the operation site and the backup site.

In cases such as the accounting calculation is stopped due to the disaster on the day of the cutoff of the tenant or the tenant is already deleted, there is no accumulated data on the backup site.

Therefore, the usage charge files will not be sent from the backup site.

Notify the accounts manager that those tenants can be charged only from the usage charge files from the operation site.

The cutoff date of the tenant can be obtained from tenant information file.

- Notify tenant administrator

In Usage Charge window of the backup site, the usage charges are of that from backup up site only.

Therefore, infrastructure administrator has to inform tenant administrators of this and, if necessary, disclose the usage charge information of the operation site.



Note

Note that the calculation of the usage charge in backup site will start at the next day of the recovery.

12. Change FQDN setting

When admin servers have different IP addresses between primary and backup sites and FQDN needs to be taken over to backup site, change the IP address for FQDN registered in DNS server to IP address of admin server on the backup site after disaster recovery failover is done.

When FQDN is taken over from primary site to backup site, clear cache or temporary internet files of Web browsers which are used to connect to ROR console on clients.

When test certificates are used, import the certificate of the backup site to the browser if the certificate is not imported.

For details, refer to "Chapter 6. Importing a Certificate to a Browser" in the "Setup Guide CE".

The access rights that were modified on the primary site are not carried over to the backup site. Update them manually when the switchover has completed.

18.4 Operation after the switchover

This section explains operations after the switchover.

- Invoicing Usage Charge

The accounts manager receives two types of files, the usage charge files of the month of the recovery sent from infrastructure administrator and usage charge files sent from backup site.

Use these files to calculate the usage charge for the tenants on the month of recovery and invoice the tenants.

The calculation procedure using files mentioned above is as follows.

- a. Extract usage charge detail files

Extract usage charge files from both operation site and backup site, and obtain usage charge detail files for each L-Platforms.

The name format of the usage charge detail files as following.

Refer to "15.4.6.2 Usage Charge Detail File" for detail.

file name

`YYYYMM_L-PlatformID.csv`

- b. Prevent duplicate charging for the monthly charging products

For each L-Server in the usage charge detail file, if the UsageFrequency column for the image, cpu, and memory is set to "1 month", compare the values of the ItemAmount columns in the usage charge detail files from operation site and backup site and delete the row with the lower value.

For the rows for the disks, delete only the rows with same size and pool name.

If there are multiple pairs rows with same size and pool name, delete only one for each pair.

If there is no monthly charging product, then this operation can be omitted.

c. Merge usage charge detail files

For each L-Platforms, copy rows after line 2 of the csv data of the backup site and add to the end of usage charge detail file from the operation site.

d. Calculate the usage charge of L-Platforms

Calculate the usage charge of L-Platforms.

Sum up the values of the ItemAmount column of the usage charge detail file.

e. Calculate the usage charge of tenants

Iterate b.-d. procedure to every L-Platforms and sum up the usage charge of L-Platforms to calculate the tenant usage charge.

18.5 Switchback operation

This section explains switchback operation from backup site to primary site after hardware environment on primary site gets recovered.

The switchback can be done with the same procedure as switchover, though the following operations are needed in advance.

1. Clear management software information

When a disaster doesn't damage the whole primary site, it is possible that some management software information remains in hardware that is not suffered from the disaster. Examples of that management software information are affinity on ETERNUS and reserved addresses of DHCP. In that case, clear the remaining management software information on the recovered primary site.

2. Installation of primary site

Build the environment on primary site for switchback. This environment needs to be built in the same way as backup site was built. For details on building procedure, refer to "[18.1 Installation](#)".

3. Collect switchback information

Collect switchback information from backup site. For details on how to collect the information, refer to "[18.2 Normal Operation](#)".

4. Start replication from backup site

Start storage replication from backup site to primary site.

Appendix A Notes on Operating ServerView Resource Orchestrator

This appendix provides important reminders for the operation of Resource Orchestrator.

Redundancy Configurations for the Admin LAN

If communication issues occur on the admin LAN, or one of the network interfaces used by a managed server on the admin LAN fails, the following operations may result in errors. In such cases, restore the admin LAN network as quickly as possible.

- Backup and restore operations
- Collection and deployment of cloning images
- Server switchover and failback

HBA address rename

- With Resource Orchestrator, the factory-set WWN of a managed server's HBA is overridden when the HBA address rename function is used. The WWN is reset to its factory-set value when the server is deleted from Resource Orchestrator. Before using HBAs in an environment that is not managed by Resource Orchestrator, first delete the server in which it is mounted using the ROR console. For details on how to delete a server, refer to "9.2 Deleting Managed Servers" of the "User's Guide for Infrastructure Administrators (Resource Management) CE".
- The WWN of a managed server is set during startup, using a network boot session to connect to the admin server. Once set up with a proper WWN, the managed server reboots into its own Operating System. Therefore, a managed server may reboot during its startup.
- Do not move HBAs whose HBA address rename settings have been set up to different managed servers. If operating HBAs without resetting their WWNs, when the same WWN is configured on multiple servers data may be damaged by same volume access.

Changing the Manager's System Time

When the admin server's system time is reset to a time in the past, the resource monitoring by the manager stops for this period. To reset the system time to more than just a few minutes in the past, return the time and then restart the manager.

For details on how to restart the manager, refer to "2.1 Starting and Stopping the Manager".

Restarting Managers

By default, the manager services restart at 3:45 am everyday for stable system operation.

The settings for restarting can be changed depending on the authority level. To change the configuration, perform the following:

- Configuration file

[Windows Manager]

Installation_folde\SVROR\Manager\rails\config\rcx\rcx_manager_params.rb

[Linux Manager]

/opt/FJSVrcvnr/rails/config/rcx/rcx_manager_params.rb

- Configuration Parameters

Table A.1 Configuration Parameters

Parameter	Meaning	Initial Value
RESTART_ENABLE	Select the restart operation status.	true

Parameter	Meaning	Initial Value
	<ul style="list-style-type: none"> - When restarting Specify "true". - When not restarting Specify "false". 	
RESTART_HOUR	Specify the restart time (hour) from 0 to 23.	3
RESTART_MIN	Specify the restart time (minutes) from 0 to 59.	45
RESTART_CYCLE	Specify the restart interval (days) from 1 to 5.	1

- Parameter change procedure

1. Stop the manager.
2. Use an editor and change the parameters of the rcx_manager_params.rb file.
3. Start the manager.

For details on how to start and stop the manager, refer to "2.1 Starting and Stopping the Manager".



Note

The conditions for restarting are, that more than RESTART_CYCLE * 24 hours have passed since manager was started and it is the time specified for RESTART_HOUR and RESTART_MIN.

For the stable operation of systems, configure the restarting of managers to occur on a daily basis.

Changing Multiple Operations of Managers

When executing multiple operations simultaneously, the upper limit is set for the number of simultaneous operations.

The upper limit of the number of simultaneous operations can be changed depending on the usage environment. To change the configuration, edit the following definition file.

When there is no definition file, create one.

Placeholder for the Definition File

[Windows Manager]
Installation_folder\SVROR\Manager\etc\customize_data

[Linux Manager]
 /etc/opt/FJSVrcvnr/customize_data

Definition File Name

rcx_base.rcxprop

Format of the Definition File

Describe the definition file in individual lines as below:

Key = Value

Items in the Definition File

Specify the following items.

Table A.2 Items in the Definition File

Item	Key	Value	Remarks
Multiplicity	TASK_WORKER_COUNT	Specify the multiplicity from 5 - 30.	The default value is "30". For basic mode, the default value is "5".

Item	Key	Value	Remarks
			Operates by default, when there are no definition files.

Example Definition File

An example definition file is indicated below. In this example, the multiplicity is set to "10".

```
TASK_WORKER_COUNT=10
```

Changing Procedures of Definition Files

- When the manager is operating in a normal environment
 1. Stop the manager.
 2. Change TASK_WORKER_COUNT values for rcx_base.rcxprop files.
When there is no rcx_base.rcxprop file, create one.
 3. Start the manager.
- When the manager is operating in a cluster environment

[Windows Manager]

 1. Stop the manager.
 2. Place the shared disk of the manager online. Place other cluster resources offline.
 3. Change the TASK_WORKER_COUNT values for rcx_base.rcxprop files on the shared disk. When there is no rcx_base.rcxprop file, create one.
Drive_name\Fujitsu\ROR\SVROR\customize_data\rcx_base.rcxprop
 4. Start the manager.

[Linux Manager]

 1. Stop the manager.
 2. Mount the shared disk of the admin server on the primary node or the secondary node.
 3. Change the TASK_WORKER_COUNT values for rcx_base.rcxprop files in the shared disk.
When there is no rcx_base.rcxprop file, create one.
Destination_to_mount_shared_disk/Fujitsu/ROR/SVROR/etc/opt/FJSVrcvmr/customize_data/rcx_base.rcxprop
 4. Unmount the shared disk for the admin server from the node mounted in step 2.
 5. Restart the manager.

For details on how to start and stop the manager, refer to "2.1 Starting and Stopping the Manager".



Advisory Notes for Basic Mode

Memory usage will increase according to the multiplicity.
For details on the memory usage to increase, refer to "Table A.3 Increased Memory Use with Multiple Operations".
Calculate the memory used from a value in the table and the memory size required for the manager operations described in "2.4.2.6 Memory Size" of the "Design Guide CE", and then add memory if necessary.

Table A.3 Increased Memory Use with Multiple Operations

Multiplicity	Increase in Memory Use (Unit: MB)
5	-

Multiplicity	Increase in Memory Use (Unit: MB)
6 - 14	$1080 + (\textit{Multiplicity} * 40)$
15 - 30	$2104 + (\textit{Multiplicity} * 40)$

Appendix B Metering Log

This chapter explains the metering log.

Metering logs is saved in the database as Information based on bill calculations so that fees can be charged based on the resources that have been used by tenants. The Output metering log command is used to output metering logs to metering log files.

Refer to "10.2 ctchg_getmeterlog (Output Metering Logs)" in the "Reference Guide CE" for information on the Output metering log command.



Refer to "[Chapter 15 Accounting](#)" for information on the overview of the accounting, the accounting information and the calculation of usage charges.

B.1 Types of Metering Logs

There are two types of metering logs: event logs and periodic logs.

Each of these types of logs is explained below:

Event logs

Event logs are logs that are output when the status of a resource has changed, such as when an L-Platform is created or canceled or when an L-Server is started or stopped. An event log records resource attribute information such as the date and time at which the event occurred, event type, information for identifying the resource, and allocation amount.

The following table shows the timing at which event logs will be output:

Event	Event identifier	Timing of event	Resource
Adding	ADD	When a resource is added and when the resource is actually secured	- L-Platform
Changing	CHANGE	When a resource is changed	- L-Server
Deleting	DELETE	When a resource deletion is requested If an approval workflow is enabled, when an approval or assessment is performed	- Disk
Starting	START	When starting a resource is complete	- L-Platform template (*1)
Stopping	STOP	When stopping a resource is requested	- Software (*2)
			- L-Server

*1: The event log for L-Platform template is output for tenant-specific templates. The event log is not output for global templates. The CHANGE log will be output if the template name is changed. If only other basic information and configuration information are changed, the CHANGE log will not be output.

*2: The event log for software will be output based on the software information that has been registered in the image information of the L-Server. The timing of software addition or deletion events is synchronized with L-Server addition or deletion events, respectively.

Periodic logs

Periodic logs are logs that show the periodic operational status of resources.

The following table shows the timing at which periodic logs will be output:

Event	Event identifier	Timing of event	Resource
Period	PERIOD	Every day at 0:00 (default) (*1)	- L-Platform
			- L-Server
			- Disk

Event	Event identifier	Timing of event	Resource
			- L-Platform template (*2) - Software

*1: If the timing of output of the periodic log is to be changed, overwrite the metering log operational settings file and then execute the Change periodic log schedule settings command.

Refer to "8.7.3 Metering Log Settings" for information on the metering log operational settings file and refer to "10.1 ctchg_chgschedule (Change Periodic Log Schedule Settings)" in the "Reference Guide CE" for the Change periodic log schedule settings command.

*2: The periodic log for L-Platform template is output for tenant-specific templates. The periodic log is not output for global templates.

Note

'Create' processing for periodic logs and 'delete' processing for metering logs are implemented periodically.

The processing results of 'create' processing for periodic logs and 'delete' processing for metering logs will be output to the following files as operation logs:

- 'Create' processing for periodic logs

[Windows Manager]

```
<installation_folder>\RCXCTMG\Charging\log\metering_period.log
```

[Linux Manager]

```
/var/opt/FJSVctchg/log/metering_period.log
```

- 'Delete' processing for metering logs

[Windows Manager]

```
<installation_folder>\RCXCTMG\Charging\log\metering_log_db_delete.log
```

[Linux Manager]

```
/var/opt/FJSVctchg/log/metering_log_db_delete.log
```

Refer to "Chapter 14 Messages Starting with meter" in the "Messages CE" to check whether processing is operating normally. Check 'create' processing for periodic logs every day at 0:00 or at least 5 minutes after the changed time. 'Delete' processing for metering logs is implemented at 0:35 every day, so check at that time or later.

B.2 Output Contents of Metering Logs

The contents that are output to metering logs will vary according to the resource.

The following tables show the log contents that are output in common for all resources as well as the log contents that are output for each resource:

Common

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
version	Yes	Yes	Yes	Yes	Yes	Yes	Version	Fixed at 2.0
event_time	Yes	Yes	Yes	Yes	Yes	Yes	Time event occurred	String YYYY-MM-DDThh:mm:ss.SSSZ
event	Yes	Yes	Yes	Yes	Yes	Yes	Event	ADD: Deploy CHANGE: Change

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
								DELETE: Delete START: Start STOP: Stop PERIOD: Period
resource_type	Yes	Yes	Yes	Yes	Yes	Yes	Configured resource type	vsys: L-Platform vserver: Virtual L-Server pserver: Physical L-Server vdisk: Expansion disk template: L-Platform template software: Software

Yes: Output; No: Not output

L-Platform

In addition to the common items output, the following items will be output:

Item ID	Output for each event				Item name	Description
	ADD	CHANGE	DELETE	PERIOD		
org_id	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform
vsys_id	Yes	Yes	Yes	Yes	L-Platform ID	ASCII: 1 to 32 characters ID identifying the L-Platform
system_name	Yes	Yes	No	Yes	L-Platform name	UTF-8: 1 to 256 characters Name of the L-Platform (comment)
base_template_id	Yes	Yes	No	Yes	L-Platform template ID	ASCII: 1 to 32 characters Template ID of the L-Platform creation source

Yes: Output; No: Not output

Virtual L-Server

In addition to the common items output, the following items will be output:

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
org_id	Yes	Yes	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform
vsys_id	Yes	Yes	Yes	Yes	Yes	Yes	L-Platform ID	ASCII: 1 to 32 characters ID identifying the L-Platform

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
server_id	Yes	Yes	Yes	Yes	Yes	Yes	L-Server ID	ASCII: 1 to 64 characters ID identifying the L-Server
system_name	Yes	Yes	No	No	No	Yes	L-Platform name	UTF-8: 1 to 256 characters Name of the L-Platform (comment)
server_name	Yes	Yes	No	No	No	Yes	L-Server name	UTF-8: 1 to 256 characters Name of the L-Server (comment)
image_name	Yes	Yes	No	Yes	Yes	Yes	Image name	ASCII: 1 to 32 characters
vm_pool	Yes	Yes	No	No	No	Yes	VM pool name	Variable-length string (unlimited)
cpu_num	Yes	Yes	No	No	No	Yes	Number of CPUs	1 to 999999
cpu_perf	Yes	Yes	No	No	No	Yes	CPU performance	1 to 999999 (Unit: 0.1 GHz) Maximum 99999.9 GHz
cpu_reserve	Yes	Yes	No	No	No	Yes	Reserve value of CPU performance	0 to 999999 (Unit: 0.1 GHz) Maximum 99999.9 GHz
memory_size	Yes	Yes	No	No	No	Yes	Memory capacity	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
memory_reserve	Yes	Yes	No	No	No	Yes	Reserve value of memory capacity	0 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
storage_pool	Yes	Yes	No	No	No	Yes	Storage pool name	Variable-length string (unlimited)
disk_size	Yes	Yes	No	No	No	Yes	System disk size	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
server_template_name	Yes	Yes	No	No	No	Yes	L-Server template name	ASCII: 1 to 32 characters
status	No	No	No	No	No	Yes	Status	RUNNING: Active STOPPED: Stopped

Yes: Output; No: Not output

Physical L-Server

In addition to the common items output, the following items will be output:

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
org_id	Yes	Yes	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform

Item ID	Output for each event						Item name	Description
	ADD	CHANGE	DELETE	START	STOP	PERIOD		
vsys_id	Yes	Yes	Yes	Yes	Yes	Yes	L-Platform ID	ASCII: 1 to 32 characters ID identifying the L-Platform
server_id	Yes	Yes	Yes	Yes	Yes	Yes	L-Server ID	ASCII: 1 to 64 characters ID identifying the L-Server
system_name	Yes	Yes	No	No	No	Yes	L-Platform name	UTF-8: 1 to 256 characters Name of the L-Platform (comment)
server_name	Yes	Yes	No	No	No	Yes	L-Server name	UTF-8: 1 to 256 characters Name of the L-Server (comment)
image_name	Yes	Yes	No	Yes	Yes	Yes	Image name	ASCII: 1 to 32 characters
server_pool	Yes	Yes	No	No	No	Yes	Server pool name	Variable-length string (unlimited)
cpu_num	Yes	Yes	No	No	No	Yes	Value entered for number of CPUs	1 to 999999
cpu_input_num	Yes	Yes	No	No	No	Yes	Value entered for number of CPUs	1 to 999999
cpu_perf	Yes	Yes	No	No	No	Yes	Value entered for CPU performance	1 to 999999 (Unit: 0.1 GHz) Maximum 99999.9 GHz
cpu_input_perf	Yes	Yes	No	No	No	Yes	Value entered for CPU performance	1 to 999999 (Unit: 0.1 GHz) Maximum 99999.9 GHz
memory_size	Yes	Yes	No	No	No	Yes	Value entered for memory capacity	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
memory_input_size	Yes	Yes	No	No	No	Yes	Value entered for memory capacity	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
storage_pool	Yes	Yes	No	No	No	Yes	Storage pool name	Variable-length string (unlimited)
disk_size	Yes	Yes	No	No	No	Yes	System disk size	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB
server_template_name	Yes	Yes	No	No	No	Yes	L-Server template ID	ASCII: 1 to 32 characters
status	No	No	No	No	No	Yes	Status	RUNNING: Active STOPPED: Stopped

Yes: Output; No: Not output

Disk

In addition to the common items output, the following items will be output:

Item ID	Output for each event				Item name	Description
	ADD	CHANGE	DELETE	PERIOD		
org_id	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform
vsys_id	Yes	Yes	Yes	Yes	L-Platform ID	ASCII: 1 to 32 characters ID identifying the L-Platform
server_id	Yes	Yes	Yes	Yes	L-Server ID	ASCII: 1 to 32 characters ID identifying the L-Server
disk_id	Yes	Yes	Yes	Yes	Disk ID	ASCII: 1 to 32 characters ID identifying the disk
system_name	Yes	Yes	No	Yes	L-Platform name	UTF-8: 1 to 256 characters Name of the L-Platform (comment)
disk_name	Yes	Yes	No	Yes	Disk name	UTF-8: 1 to 256 characters Name of the disk
storage_pool	Yes	Yes	No	Yes	Storage pool name	Variable-length string (unlimited)
disk_size	Yes	Yes	No	Yes	Disk size	1 to 999999 (Unit: 0.1 GB) Maximum 99999.9 GB

Yes: Output; No: Not output

L-Platform template

In addition to the common items output, the following items will be output:

Item ID	Output for each event				Item name	Description
	ADD	CHANGE	DELETE	PERIOD		
org_id	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform
template_id	Yes	Yes	Yes	Yes	L-Platform template ID	ASCII: 1 to 32 characters ID identifying the L-Platform template
template_name	Yes	Yes	No	Yes	L-Platform template name	UTF-8: 1 to 256 characters Name of the L-Platform template

Yes: Output; No: Not output

Software

In addition to the common items output, the following items will be output:

Item ID	Output for each event				Item name	Description
	ADD	CHANGE	DELETE	PERIOD		
org_id	Yes	Yes	Yes	Yes	Tenant name	ASCII: 1 to 32 characters Name of the tenant folder
user_id	Yes	Yes	Yes	Yes	User account	ASCII: 1 to 32 characters User that owns the L-Platform
vsys_id	Yes	Yes	Yes	Yes	L-Platform ID	ASCII: 1 to 32 characters ID identifying the L-Platform
server_id	Yes	Yes	Yes	Yes	L-Server ID	ASCII: 1 to 32 characters ID identifying the L-Server
software_id	Yes	Yes	Yes	Yes	Software ID	ASCII: 1 to 32 characters ID identifying the software
system_name	Yes	Yes	No	Yes	L-Platform name	UTF-8: 1 to 256 characters Name of the L-Platform (comment)

Yes: Output; No: Not output

B.3 Formats of Metering Log Files

Metering logs are output to CSV format files or XML format files.

Use the options of the Output metering log command to specify the format in which metering logs are to be output. Refer to "10.2 cthg_getmeterlog (Output Metering Logs)" in the "Reference Guide CE" for information on the Output metering log command.

This section explains each of the file formats.

CSV format files

The format of CSV format files is as follows:

- The item ID is output with a one-byte hash (#) sign added to the first character of the first row.
- Items are output with commas used as delimiters between each item.
- String data is output enclosed by double quotation marks and numeric data is output as it is.
- If an item is not output using string data, "" is output.
- If an item is not output using numeric data, nothing is output. (A comma is output immediately after the previous item.)
- For a Reserved item, "" is output.

The order of the items that are output to a CSV format file is as follows:

No.	Item ID	Item name	Data type
1	version	Version	Numeric
2	event_time	Time of event	String
3	Reserved		
4	vsys_id	L-Platform ID	String
5	org_id	Tenant name	String
6	event	Event	String
7	resource_type	Configured resource type	String
8	status	Status	String

No.	Item ID	Item name	Data type
9	user_id	User account	String
10	server_id	L-Server ID	String
11	disk_id	Disk ID	String
12	software_id	Software ID	String
13	system_name	L-Platform name	String
14	server_name	L-Server name	String
15	disk_name	Disk name	String
16	template_id	Template ID	String
17	Reserved		
18	base_template_id	Used template ID	String
19	image_name	Image name	String
20	storage_pool	Storage pool name	String
21	disk_size	Disk size	Numeric
22	vm_pool	VM pool name	String
23	cpu_num	Number of CPUs	Numeric
24	cpu_perf	CPU performance	Numeric
25	memory_size	Memory capacity	Numeric
26	cpu_reserve	Reserve value of CPU performance	Numeric
27	memory_reserve	Reserve value of memory capacity	Numeric
28	server_template_name	L-Server template name	String
29	server_pool	Server pool name	String
30	cpu_input_num	Value entered for number of CPUs	Numeric
31	cpu_input_perf	Value entered for CPU frequency	Numeric
32	memory_input_size	Value entered for memory capacity	Numeric
33	template_name	Template name	String

An output example of a CSV format file is shown below:

```
#version,event_time,Reserved,vsys_id,org_id,event,resource_type,status,user_id,server_id,disk_id,software_id,system_name,server_name,disk_name,template_id,Reserved,base_template_id,image_name,storage_pool,disk_size,vm_pool,cpu_num,cpu_perf,memory_size,cpu_reserve,memory_reserve,server_template_name,server_pool,cpu_input_num,cpu_input_perf,memory_input_size,template_name
2.0,"2011-07-02T00:00:00.000+0900","",,"vsysId001","orgId001","ADD","pserver","",,"userId001","serverId001","",,"systemName001","ServerName001","",,"image001","/StoragePool001",100,"",1,3,6,,,serverTemplateName001,serverPool001,2,5,8,
2.0,"2011-08-08T10:20:10.000+0900","",,"orgId001","PERIOD","template","",,"userId001","",,"",,"",,"id001","",,"",,,,,,,,,,,,,,name001
2.0,"2011-08-08T10:20:10.000+0900","",,"vsysId001","orgId001","PERIOD","software","",,"userId001","serverId001","",,"softwareId001","systemName001","",,"",,,,,,,,,,,,,,
```

```

2.0,"2011-08-08T10:20:10.000+0900","","","vsysId001","orgId001","PERIOD","vserver","RUNNING","userId001",
,"serverId001","","","systemName001","serverName002","","","","","imageInfoName001","/
StoragePool002",100,"/VMPool001",2,30,60,10,50,serverType001,,,,,
2.0,"2011-08-08T10:20:10.000+0900","","","vsysId001","orgId001","PERIOD","vdisk","","","userId001","server
Id001","diskId001","","","systemName001","","","diskName001","","","","","/StoragePool002",
200,"",,,,,,,,,,,,,,
2.0,"2011-08-08T10:20:10.000+0900","","","vsysId001","orgId001","PERIOD","vsys","","","userId001","","","","",
,"systemName001","","","","","baseTemplateId001","","","","",,,,,,,,,,,,,,

```

XML format files

The format of XML format files is as follows:

```

<?xml version="1.0" encoding="UTF-8"?>
<meterlog>
  <entry><Item ID>Value</Item ID>...</entry>
  <entry><Item ID>Value</Item ID>...</entry>
  ...
</meterlog>

```

- The first row of the CSV format corresponds to the <entry> element.
- The first column of the CSV format corresponds to the <Item ID> element.
- If an item is not output, the <Item ID> tag itself is not output.

An output example of an XML format file is shown below:

```

<?xml version="1.0" encoding="UTF-8"?>
<meterlog>
  <entry>
    <version>2.0</version>
    <event_time>2011-07-02T00:00:00.000+0900</event_time>
    <vsys_id>vsysId001</vsys_id>
    <org_id>orgId001</org_id>
    <event>ADD</event>
    <resource_type>pserver</resource_type>
    <user_id>userId001</user_id>
    <server_id>serverId001</server_id>
    <system_name>systemName001</system_name>
    <server_name>serverName001</server_name>
    <image_name>image001</image_name>
    <storage_pool>storagePool001</storage_pool>
    <disk_size>1</disk_size>
    <cpu_num>1</cpu_num>
    <cpu_perf>3</cpu_perf>
    <memory_size>6</memory_size>
    <server_template_name>serverTemplateName001</server_template_name>
    <server_pool>serverPool001</server_pool>
    <cpu_input_num>2</cpu_input_num>
    <cpu_input_perf>5</cpu_input_perf>
    <memory_input_size>8</memory_input_size>
  </entry>
  <entry>
    ...
  </entry>
  ...
</meterlog>

```



- If a change of tenant has been performed for an L-Platform, an event log with CHANGE as the event will be output.

- If snapshot restore has been performed, an event log with CHANGE as the event will be output even if there was no change.
- At execution of the Import L-Server command of the L-Platform Management function, the following event log will be output:
 - If a stopped L-Server has been imported
Event log with ADD as the event
 - If an active L-Server has been imported
Event log with ADD and START as the events

 **Note**

- An event indicating a stop of an L-Server (STOP) occurs for a stop or a forced stop of an L-Server. The forced stop of an L-Server can be performed even if the L-Server has a stopped status (STOPPED). Therefore, take into account that even if an L-Server has a stopped status, an event indicating a stop of the L-Server (STOP) may exist.
 - When starting virtual L-Servers using RHEL-KVM as virtualization software, the amount of memory used by L-Servers is set to the upper limit first, and then it is reduced to the value specified to L-Servers by the RHEL-KVM management application. Therefore metering logs will be output in the following order if a RHEL-KVM L-Server is started.
 1. L-Server starting (START)
 2. L-Server changing (CHANGE) : Memory capacity = The upper limit
 3. L-Server changing (CHANGE) : The upper limit > Memory capacity > The value specified to the L-Server (*)
 4. L-Server changing (CHANGE) : Memory capacity = The value specified to the L-Server
- *) The changing log 3. may not be output sometimes.

Refer to "C.6.10 Overcommit" in the "Setup Guide CE" for the RHEL-KVM memory amount.

B.4 Deleting Metering Logs

Metering logs are periodically deleted from the database.

Delete processing is implemented every day at 0:35 and the logs for which the log entry retention period that was set in the metering operational settings file has passed will be deleted.

When metering logs are deleted, accounting can no longer be calculated, so set the log entry retention period so that only the metering logs for which accounting calculations are complete will be deleted.

Refer to "[8.7.3 Metering Log Settings](#)" for information on the metering log operational settings file.

Glossary

access path

A logical path configured to enable access to storage volumes from servers.

active mode

The state where a managed server is performing operations.

Managed servers must be in active mode in order to use Auto-Recovery.

Move managed servers to maintenance mode in order to perform backup or restoration of system images, or collection or deployment of cloning images.

active server

A physical server that is currently operating.

admin client

A terminal (PC) connected to an admin server, which is used to operate the GUI.

admin LAN

A LAN used to manage resources from admin servers.

It connects managed servers, storage, and network devices.

admin server

A server used to operate the manager software of Resource Orchestrator.

affinity group

A grouping of the storage volumes allocated to servers. A function of ETERNUS.

Equivalent to the LUN mapping of EMC.

agent

The section (program) of Resource Orchestrator that operates on managed servers.

aggregate

A unit for managing storage created through the aggregation of a RAID group.

Aggregates can contain multiple FlexVols.

alias name

A name set for each ETERNUS LUN to distinguish the different ETERNUS LUNs.

Auto Deploy

A function for deploying VMware ESXi 5.0 to servers using the PXE boot mechanism.

Automatic Storage Layering

A function that optimizes performance and cost by automatically rearranging data in storage units based on the frequency of access.

Auto-Recovery

A function which continues operations by automatically switching over the system image of a failed server to a spare server and restarting it in the event of server failure.

This function can be used when managed servers are in a local boot configuration, SAN boot configuration, or a configuration such as iSCSI boot where booting is performed from a disk on a network.

- When using a local boot configuration

The system is recovered by restoring a backup of the system image of the failed server onto a spare server.

- When booting from a SAN or a disk on a LAN

The system is restored by having the spare server inherit the system image on the storage.

Also, when a VLAN is set for the public LAN of a managed server, the VLAN settings of adjacent LAN switches are automatically switched to those of the spare server.

backup site

An environment prepared in a different location, which is used for data recovery.

BACS (Broadcom Advanced Control Suite)

An integrated GUI application (comprised from applications such as BASP) that creates teams from multiple NICs, and provides functions such as load balancing.

Basic Mode

A function that can be used by configuring a Cloud Edition license after installing ROR VE.

BASP (Broadcom Advanced Server Program)

LAN redundancy software that creates teams of multiple NICs, and provides functions such as load balancing and failover.

blade server

A compact server device with a thin chassis that can contain multiple server blades, and has low power consumption.

As well as server blades, LAN switch blades, management blades, and other components used by multiple server blades can be mounted inside the chassis.

blade type

A server blade type.

Used to distinguish the number of server slots used and servers located in different positions.

BladeViewer

A GUI that displays the status of blade servers in a style similar to a physical view and enables intuitive operation.

BladeViewer can also be used for state monitoring and operation of resources.

BMC (Baseboard Management Controller)

A Remote Management Controller used for remote operation of servers.

boot agent

An OS for disk access that is distributed from the manager to managed servers in order to boot them when the network is started during image operations.

CA (Channel Adapter)

An adapter card that is used as the interface for server HBAs and fibre channel switches, and is mounted on storage devices.

CCM (ETERNUS SF AdvancedCopy Manager Copy Control Module)

This is a module that does not require installation of the ETERNUS SF AdvancedCopy Manager agent on the server that is the source of the backup, but rather uses the advanced copy feature of the ETERNUS disk array to make backups.

chassis

A chassis used to house server blades and partitions.

Sometimes referred to as an enclosure.

cloning

Creation of a copy of a system disk.

cloning image

A backup of a system disk, which does not contain server-specific information (system node name, IP address, etc.), made during cloning.

When deploying a cloning image to the system disk of another server, Resource Orchestrator automatically changes server-specific information to that of the target server.

Cloud Edition

The edition which can be used to provide private cloud environments.

data center

A facility that manages client resources (servers, storage, networks, etc.), and provides internet connections and maintenance/operational services.

directory service

A service for updating and viewing the names (and associated attributes) of physical/logical resource names scattered across networks, based on organizational structures and geographical groups using a systematic (tree-shaped structure) management methodology.

disk resource

The unit for resources to connect to an L-Server. An example being a virtual disk provided by LUN or VM management software.

DN (Distinguished Name)

A name defined as a line of an RDN, which contains an entry representing its corresponding object and higher entry.

Domain

A system that is divided into individual systems using partitioning. Also used to indicate a partition.

DR Option

The option that provides the function for remote switchover of servers or storage in order to perform disaster recovery.

Dual-Role Administrators

The administrators with both infrastructure administrator's and tenant administrator's role.

dynamic LUN mirroring

This is a feature whereby a mirror volume is generated at the remote site when a volume is generated at the local site, and copies are maintained by performing REC.

dynamic memory

A function that optimizes physical memory allocation for virtual machines, depending on their execution status on Hyper-V.

end host mode

This is a mode where the uplink port that can communicate with a downlink port is fixed at one, and communication between uplink ports is blocked.

environmental data

Measured data regarding the external environments of servers managed using Resource Orchestrator.

Measured data includes power data collected from power monitoring targets.

ESC (ETERNUS SF Storage Cruiser)

Software that supports stable operation of multi-vendor storage system environments involving SAN, DAS, or NAS. Provides configuration management, relation management, trouble management, and performance management functions to integrate storage related resources such as ETERNUS.

ETERNUS SF AdvancedCopy Manager

This is storage management software that makes highly reliable and rapid backups, restorations and replications using the advanced copy feature of the ETERNUS disk array.

Express

The edition which provides server registration, monitoring, and visualization.

FC switch (Fibre Channel Switch)

A switch that connects Fibre Channel interfaces and storage devices.

Fibre Channel

A method for connecting computers and peripheral devices and transferring data.

Generally used with servers requiring high-availability, to connect computers and storage systems.

Fibre Channel port

The connector for Fibre Channel interfaces.

When using ETERNUS storage, referred to as an FC-CA port, when using NetApp storage, referred to as an FC port, when using EMC CLARiON, referred to as an SP port, when using EMC Symmetrix DMX or EMC Symmetrix VMAX, referred to as a DIRECTOR port.

fibre channel switch blade

A fibre channel switch mounted in the chassis of a blade server.

FlexVol

A function that uses aggregates to provide virtual volumes.

Volumes can be created in an instant.

FTRP

The pool for physical disks created by Automatic Storage Layering for ETERNUS.

In Resource Orchestrator, FTRPs are used as virtual storage resources on which Thin Provisioning attributes are configured.

FTV

The virtual volumes created by Automatic Storage Layering for ETERNUS.

In Resource Orchestrator, FTVs are used as disk resources on which Thin Provisioning attributes are configured.

global pool

A resource pool that contains resources that can be used by multiple tenants.

It is located in a different location from the tenants.

By configuring a global pool with the attributes of a tenant, it becomes possible for tenant administrators to use the pool.

global zone

The actual OS that is used for a Solaris container.

A Solaris environment that has been installed on a physical server.

GLS (Global Link Services)

Fujitsu network control software that enables high availability networks through the redundancy of network transmission channels.

GSPB (Giga-LAN SAS and PCI_Box Interface Board)

A board which mounts onboard I/O for two partitions and a PCIe (PCI Express) interface for a PCI box.

GUI (Graphical User Interface)

A user interface that displays pictures and icons (pictographic characters), enabling intuitive and easily understandable operation.

HA (High Availability)

The concept of using redundant resources to prevent suspension of system operations due to single problems.

hardware initiator

A controller which issues SCSI commands to request processes.
In iSCSI configurations, NICs fit into this category.

hardware maintenance mode

In the maintenance mode of PRIMEQUEST servers, a state other than Hot System Maintenance.

HBA (Host Bus Adapter)

An adapter for connecting servers and peripheral devices.
Mainly used to refer to the FC HBAs used for connecting storage devices using Fibre Channel technology.

HBA address rename setup service

The service that starts managed servers that use HBA address rename in the event of failure of the admin server.

HBAAR (HBA address rename)

I/O virtualization technology that enables changing of the actual WWN possessed by an HBA.

host affinity

A definition of the server HBA that is set for the CA port of the storage device and the accessible area of storage.
It is a function for association of the Logical Volume inside the storage which is shown to the host (HBA) that also functions as security internal to the storage device.

Hyper-V

Virtualization software from Microsoft Corporation.
Provides a virtualized infrastructure on PC servers, enabling flexible management of operations.

I/O virtualization option

An optional product that is necessary to provide I/O virtualization.
The WWNN address and MAC address provided is guaranteed by Fujitsu Limited to be unique.
Necessary when using HBA address rename.

IBP (Intelligent Blade Panel)

One of operation modes used for PRIMERGY switch blades.
This operation mode can be used for coordination with ServerView Virtual I/O Manager (VIOM), and relations between server blades and switch blades can be easily and safely configured.

ICT governance

A collection of principles and practices that encourage desirable behavior in the use of ICT (Information and Communication Technology) based on an evaluation of the impacts and risks posed in the adoption and application of ICT within an organization or community.

ILOM (Integrated Lights Out Manager)

The name of the Remote Management Controller for SPARC Enterprise T series servers.

image file

A system image or a cloning image. Also a collective term for them both.

infrastructure administrator

A user who manages the resources comprising a data center.

infra_admin is the role that corresponds to the users who manage resources.

Infrastructure administrators manage all of the resources comprising a resource pool (the global pool and local pools), provide tenant administrators with resources, and review applications by tenant users to use resources.

IPMI (Intelligent Platform Management Interface)

IPMI is a set of common interfaces for the hardware that is used to monitor the physical conditions of servers, such as temperature, power voltage, cooling fans, power supply, and chassis.

These functions provide information that enables system management, recovery, and asset management, which in turn leads to reduction of overall TCO.

IQN (iSCSI Qualified Name)

Unique names used for identifying iSCSI initiators and iSCSI targets.

iRMC (integrated Remote Management Controller)

The name of the Remote Management Controller for Fujitsu's PRIMERGY servers.

iSCSI

A standard for using the SCSI protocol over TCP/IP networks.

iSCSI boot

A configuration function that enables the starting and operation of servers via a network.

The OS and applications used to operate servers are stored on iSCSI storage, not the internal disks of servers.

iSCSI storage

Storage that uses an iSCSI connection.

LAG (Link Aggregation Group)

A single logical port created from multiple physical ports using link aggregation.

LAN switch blades

A LAN switch that is mounted in the chassis of a blade server.

LDAP (Lightweight Directory Access Protocol)

A protocol used for accessing Internet standard directories operated using TCP/IP.

LDAP provides functions such as direct searching and viewing of directory services using a web browser.

license

The rights to use specific functions.

Users can use specific functions by purchasing a license for the function and registering it on the manager.

link aggregation

Function used to multiplex multiple ports and use them as a single virtual port.

By using this function, it becomes possible to use a band equal to the total of the bands of all the ports.

Also, if one of the multiplexed ports fails its load can be divided among the other ports, and the overall redundancy of ports improved.

local pool

A resource pool that contains resources that can only be used by a specific tenant.

They are located in tenants.

logical volume

A logical disk that has been divided into multiple partitions.

L-Platform

A resource used for the consolidated operation and management of systems such as multiple-layer systems (Web/AP/DB) comprised of multiple L-Servers, storage, and network devices.

L-Platform template

A template that contains the specifications for servers, storage, network devices, and images that are configured for an L-Platform.

LSB (Logical System Board)

A system board that is allocated a logical number (LSB number) so that it can be recognized from the domain, during domain configuration.

L-Server

A resource defined using the logical specifications (number of CPUs, amount of memory, disk capacity, number of NICs, etc.) of the servers, and storage and network devices connected to those servers.

An abbreviation of Logical Server.

L-Server template

A template that defines the number of CPUs, memory capacity, disk capacity, and other specifications for resources to deploy to an L-Server.

LUN (Logical Unit Number)

A logical unit defined in the channel adapter of a storage unit.

MAC address (Media Access Control address)

A unique identifier that is assigned to Ethernet cards (hardware).

Also referred to as a physical address.

Transmission of data is performed based on this identifier. Described using a combination of the unique identifying numbers managed by/assigned to each maker by the IEEE, and the numbers that each maker assigns to their hardware.

maintenance mode

The state where operations on managed servers are stopped in order to perform maintenance work.

In this state, the backup and restoration of system images and the collection and deployment of cloning images can be performed.

However, when using Auto-Recovery it is necessary to change from this mode to active mode. When in maintenance mode it is not possible to switch over to a spare server if a server fails.

managed server

A collective term referring to a server that is managed as a component of a system.

management blade

A server management unit that has a dedicated CPU and LAN interface, and manages blade servers. Used for gathering server blade data, failure notification, power control, etc.

Management Board

The PRIMEQUEST system management unit. Used for gathering information such as failure notification, power control, etc. from chassis.

manager

The section (program) of Resource Orchestrator that operates on admin servers. It manages and controls resources registered with Resource Orchestrator.

master slot

A slot that is recognized as a server when a server that occupies multiple slots is mounted.

member server

A collective term that refers to a server in a Windows network domain that is not a domain controller.

migration

The migration of a VM guest to a different VM host. The following two types of migration are available:

- Cold migration
Migration of an inactive (powered-off) VM guest.
- Live migration
Migration of an active (powered-on) VM guest.

multi-slot server

A server that occupies multiple slots.

NAS (Network Attached Storage)

A collective term for storage that is directly connected to a LAN.

network device

The unit used for registration of network devices. L2 switches and firewalls fit into this category.

network map

A GUI function for graphically displaying the connection relationships of the servers and LAN switches that compose a network.

network view

A window that displays the connection relationships and status of the wiring of a network map.

NFS (Network File System)

A system that enables the sharing of files over a network in Linux environments.

NIC (Network Interface Card)

An interface used to connect a server to a network.

non-global zone

A virtual machine environment that has been prepared in a global zone. Its OS kernel is shared with the global zone. Non-global zones are completely separate from each other.

OS

The OS used by an operating server (a physical OS or VM guest).

overcommit

A function to virtually allocate more resources than the actual amount of resources (CPUs and memory) of a server. This function is used to enable allocation of more disk resources than are mounted in the target server.

PDU (Power Distribution Unit)

A device for distributing power (such as a power strip). Resource Orchestrator uses PDUs with current value display functions as Power monitoring devices.

physical LAN segment

A physical LAN that servers are connected to. Servers are connected to multiple physical LAN segments that are divided based on their purpose (public LANs, backup LANs, etc.). Physical LAN segments can be divided into multiple network segments using VLAN technology.

physical network adapter

An adapter, such as a LAN, to connect physical servers or VM hosts to a network.

physical OS

An OS that operates directly on a physical server without the use of server virtualization software.

physical server

The same as a "server". Used when it is necessary to distinguish actual servers from virtual servers.

pin-group

This is a group, set with the end host mode, that has at least one uplink port and at least one downlink port.

Pool Master

On Citrix XenServer, it indicates one VM host belonging to a Resource Pool. It handles setting changes and information collection for the Resource Pool, and also performs operation of the Resource Pool. For details, refer to the Citrix XenServer manual.

port backup

A function for LAN switches which is also referred to as backup port.

port VLAN

A VLAN in which the ports of a LAN switch are grouped, and each LAN group is treated as a separate LAN.

port zoning

The division of ports of fibre channel switches into zones, and setting of access restrictions between different zones.

power monitoring devices

Devices used by Resource Orchestrator to monitor the amount of power consumed. PDUs and UPSs with current value display functions fit into this category.

power monitoring targets

Devices from which Resource Orchestrator can collect power consumption data.

pre-configuration

Performing environment configuration for Resource Orchestrator on another separate system.

primary server

The physical server that is switched from when performing server switchover.

primary site

The environment that is usually used by Resource Orchestrator.

private cloud

A private form of cloud computing that provides ICT services exclusively within a corporation or organization.

public LAN

A LAN used for operations by managed servers.
Public LANs are established separately from admin LANs.

rack

A case designed to accommodate equipment such as servers.

rack mount server

A server designed to be mounted in a rack.

RAID (Redundant Arrays of Inexpensive Disks)

Technology that realizes high-speed and highly-reliable storage systems using multiple hard disks.

RAID management tool

Software that monitors disk arrays mounted on PRIMERGY servers.
The RAID management tool differs depending on the model or the OS of PRIMERGY servers.

RDM (Raw Device Mapping)

A function of VMware. This function provides direct access from a VMware virtual machine to a LUN.

RDN (Relative Distinguished Name)

A name used to identify the lower entities of a higher entry.
Each RDN must be unique within the same entry.

Remote Management Controller

A unit used for managing servers.
Used for gathering server data, failure notification, power control, etc.

- For Fujitsu PRIMERGY servers
 - iRMC2
- For SPARC Enterprise
 - ILOM (T series servers)
 - XSCF (M series servers)

- For HP servers
 - iLO2 (integrated Lights-Out)
- For Dell/IBM servers
 - BMC (Baseboard Management Controller)

Remote Server Management

A PRIMEQUEST feature for managing partitions.

Reserved SB

Indicates the new system board that will be embedded to replace a failed system board if the hardware of a system board embedded in a partition fails and it is necessary to disconnect the failed system board.

resource

General term referring to the logical definition of the hardware (such as servers, storage, and network devices) and software that comprise a system.

resource folder

An arbitrary group of resources.

resource pool

A unit for management of groups of similar resources, such as servers, storage, and network devices.

resource tree

A tree that displays the relationships between the hardware of a server and the OS operating on it using hierarchies.

role

A collection of operations that can be performed.

ROR console

The GUI that enables operation of all functions of Resource Orchestrator.

ruleset

A collection of script lists for performing configuration of network devices, configured as combinations of rules based on the network device, the purpose, and the application.

SAN (Storage Area Network)

A specialized network for connecting servers and storage.

SAN boot

A configuration function that enables the starting and operation of servers via a SAN.

The OS and applications used to operate servers are stored on SAN storage, not the internal disks of servers.

SAN storage

Storage that uses a Fibre Channel connection.

script list

Lists of scripts for the automation of operations such as status and log display, and definition configuration of network devices.

Used to execute multiple scripts in one operation. The scripts listed in a script list are executed in the order that they are listed.

As with individual scripts, they can be created by the infrastructure administrator, and can be customized to meet the needs of tenant administrators.

They are used to configure virtual networks for VLANs on physical networks, in cases where it is necessary to perform auto-configuration of multiple switches at the same time, or to configure the same rules for network devices in redundant configurations. The script lists contain the scripts used to perform automatic configuration.

There are the following eight types of script lists:

- script lists for setup
- script lists for setup error recovery
- script lists for modification
- script lists for modification error recovery
- script lists for setup (physical server added)
- script lists for setup error recovery (physical server added)
- script lists for deletion (physical server deleted)
- script lists for deletion

server

A computer (operated with one operating system).

server blade

A server blade has the functions of a server integrated into one board. They are mounted in blade servers.

server management unit

A unit used for managing servers.

A management blade is used for blade servers, and a Remote Management Controller is used for other servers.

server name

The name allocated to a server.

server NIC definition

A definition that describes the method of use for each server's NIC.

For the NICs on a server, it defines which physical LAN segment to connect to.

server virtualization software

Basic software which is operated on a server to enable use of virtual machines. Used to indicate the basic software that operates on a PC server.

ServerView Deployment Manager

Software used to collect and deploy server resources over a network.

ServerView Operations Manager

Software that monitors a server's (PRIMERGY) hardware state, and notifies of errors by way of the network.

ServerView Operations Manager was previously known as ServerView Console.

ServerView RAID

One of the RAID management tools for PRIMERGY.

ServerView Update Manager

This is software that performs jobs such as remote updates of BIOS, firmware, drivers, and hardware monitoring software on servers being managed by ServerView Operations Manager.

ServerView Update Manager Express

Insert the ServerView Suite DVD1 or ServerView Suite Update DVD into the server requiring updating and start it.
This is software that performs batch updates of BIOS, firmware, drivers, and hardware monitoring software.

Single Sign-On

A system among external software which can be used without login operations, after authentication is executed once.

slave slot

A slot that is not recognized as a server when a server that occupies multiple slots is mounted.

SMB (Server Message Block)

A protocol that enables the sharing of files and printers over a network.

SNMP (Simple Network Management Protocol)

A communications protocol to manage (monitor and control) the equipment that is attached to a network.

software initiator

An initiator processed by software using OS functions.

Solaris container resource pool

The Solaris Containers resource pool used in the global zone and the non-global zone.

Solaris Containers

Solaris server virtualization software.
On Solaris servers, it is possible to configure multiple virtual Solaris servers that are referred to as a Solaris Zone.

Solaris Zone

A software partition that virtually divides a Solaris OS space.

SPARC Enterprise Partition Model

A SPARC Enterprise model which has a partitioning function to enable multiple system configurations, separating a server into multiple areas with operating OS's and applications in each area.

spare server

A server which is used to replace a failed server when server switchover is performed.

storage blade

A blade-style storage device that can be mounted in the chassis of a blade server.

storage management software

Software for managing storage units.

storage resource

Collective term that refers to virtual storage resources and disk resources.

storage unit

Used to indicate the entire secondary storage as one product.

surrogate pair

A method for expressing one character as 32 bits.

In the UTF-16 character code, 0xD800 - 0xDBFF are referred to as "high surrogates", and 0xDC00 - 0xDFFF are referred to as "low surrogates". Surrogate pairs use "high surrogate" + "low surrogate".

switchover state

The state in which switchover has been performed on a managed server, but neither failback nor continuation have been performed.

system administrator

The administrator who manages the entire system. They perform pre-configuration and installation of Resource Orchestrator.

Administrator privileges for the operating system are required. Normally the roles of the infrastructure administrator and system administrator are performed concurrently.

System Board

A board which can mount up to 2 Xeon CPUs and 32 DIMMs.

system disk

The disk on which the programs (such as the OS) and files necessary for the basic functions of servers (including booting) are installed.

system image

A copy of the contents of a system disk made as a backup.

Different from a cloning image as changes are not made to the server-specific information contained on system disks.

tenant

A unit for the division and segregation of management and operation of resources based on organizations or operations.

tenant administrator

A user who manages the resources allocated to a tenant.

tenant_admin is the role for performing management of resources allocated to a tenant.

Tenant administrators manage the available space on resources in the local pools of tenants, and approve or reject applications by tenant users to use resources.

tenant folder

A resource folder that is created for each tenant, and is used to manage the resources allocated to a tenant.

L-Servers and local pools are located in tenant folders. Also, it is possible to configure a global pool that tenant administrators can use.

tenant user

A user who uses the resources of a tenant, or creates and manages L-Platforms, or a role with the same purpose.

Thick Provisioning

Allocation of the actual requested capacity when allocating storage resources.

Thin Provisioning

Allocating of only the capacity actually used when allocating storage resources.

tower server

A standalone server with a vertical chassis.

TPP (Thin Provisioning Pool)

One of resources defined using ETERNUS. Thin Provisioning Pools are the resource pools of physical disks created using Thin Provisioning.

TPV (Thin Provisioning Volume)

One of resources defined using ETERNUS. Thin Provisioning Volumes are physical disks created using the Thin Provisioning function.

UNC (Universal Naming Convention)

Notational system for Windows networks (Microsoft networks) that enables specification of shared resources (folders, files, shared printers, shared directories, etc.).



Example

.....
\\hostname\dir_name
.....

UPS (Uninterruptible Power Supply)

A device containing rechargeable batteries that temporarily provides power to computers and peripheral devices in the event of power failures.

Resource Orchestrator uses UPSs with current value display functions as power monitoring devices.

URL (Uniform Resource Locator)

The notational method used for indicating the location of information on the Internet.

VIOM (ServerView Virtual-IO Manager)

The name of both the I/O virtualization technology used to change the MAC addresses of NICs and the software that performs the virtualization.

Changes to values of WWNs and MAC addresses can be performed by creating a logical definition of a server, called a server profile, and assigning it to a server.

Virtual Edition

The edition that can use the server switchover function.

Virtual I/O

Technology that virtualizes the relationship of servers and I/O devices (mainly storage and network) thereby simplifying the allocation of and modifications to I/O resources to servers, and server maintenance.

For Resource Orchestrator it is used to indicate HBA address rename and ServerView Virtual-IO Manager (VIOM).

virtual server

A virtual server that is operated on a VM host using a virtual machine.

virtual storage resource

This refers to a resource that can dynamically create a disk resource.

An example being RAID groups or logical storage that is managed by server virtualization software (such as VMware datastores).

In Resource Orchestrator, disk resources can be dynamically created from ETERNUS RAID groups, NetApp aggregates, and logical storage managed by server virtualization software.

virtual switch

A function provided by server virtualization software to manage networks of VM guests as virtual LAN switches.

The relationships between the virtual NICs of VM guests and the NICs of the physical servers used to operate VM hosts can be managed using operations similar to those of the wiring of normal LAN switches.

A function provided by server virtualization software in order to manage L-Server (VM) networks as virtual LAN switches. Management of relationships between virtual L-Server NICs, and physical server NICs operating on VM hosts, can be performed using an operation similar to the connection of a normal LAN switch.

VLAN (Virtual LAN)

A splitting function, which enables the creation of virtual LANs (seen as differing logically by software) by grouping ports on a LAN switch.

Using a Virtual LAN, network configuration can be performed freely without the need for modification of the physical network configuration.

VLAN ID

A number (between 1 and 4,095) used to identify VLANs.

Null values are reserved for priority tagged frames, and 4,096 (FFF in hexadecimal) is reserved for mounting.

VM (Virtual Machine)

A virtual computer that operates on a VM host.

VM guest

A virtual server that operates on a VM host, or an OS that is operated on a virtual machine.

VM Home Position

The VM host that is home to VM guests.

VM host

A server on which server virtualization software is operated, or the server virtualization software itself.

VM maintenance mode

One of the settings of server virtualization software, that enables maintenance of VM hosts.

For example, when using high availability functions (such as VMware HA) of server virtualization software, by setting VM maintenance mode it is possible to prevent the moving of VM guests on VM hosts undergoing maintenance.

For details, refer to the manuals of the server virtualization software being used.

VM management software

Software for managing multiple VM hosts and the VM guests that operate on them.

Provides value adding functions such as movement between the servers of VM guests (migration).

VMware

Virtualization software from VMware Inc.

Provides a virtualized infrastructure on PC servers, enabling flexible management of operations.

VMware DPM (VMware Distributed Power Management)

A function of VMware. This function is used to reduce power consumption by automating power management of servers in VMware DRS clusters.

VMware DRS (VMware Distributed Resource Scheduler)

A function of VMware. This function is used to monitor the load conditions on an entire virtual environment and optimize the load dynamically.

VMware Teaming

A function of VMware. By using VMware Teaming it is possible to perform redundancy by connecting a single virtual switch to multiple physical network adapters.

Web browser

A software application that is used to view Web pages.

WWN (World Wide Name)

A 64-bit address allocated to an HBA.
Refers to a WWNN or a WWPN.

WWNN (World Wide Node Name)

A name that is set as a common value for the Fibre Channel ports of a node. However, the definitions of nodes vary between manufacturers, and may also indicate devices or adapters. Also referred to as a node WWN.

WWPN (World Wide Port Name)

A name that is a unique value and is set for each Fibre Channel port (HBA, CA, fibre channel switch ports, etc.), and is the IEEE global MAC address.

As the Fibre Channel ports of the same WWPN are unique, they are used as identifiers during Fibre Channel port login. Also referred to as a port WWN.

WWPN zoning

The division of ports into zones based on their WWPN, and setting of access restrictions between different zones.

Xen

A type of server virtualization software.

XSB (eXtended System Board)

Unit for domain creation and display, composed of physical components.

XSCF (eXtended System Control Facility)

The name of the Remote Management Controller for SPARC Enterprise M series servers.

zoning

A function that provides security for Fibre Channels by grouping the Fibre Channel ports of a Fibre Channel switch into zones, and only allowing access to ports inside the same zone.